

BEFORE USE

Thank you for choosing M-System. Before use, please check contents of the package you received as outlined below.

If you have any problems or questions with the product, please contact M-System's Sales Office or representatives.

■ PACKAGE INCLUDES:

Analog I/O module(1)
Terminating resistor (110 Ω, 0.25 W).....(1)

■ MODEL NO.

Confirm Model No. marking on the product to be exactly what you ordered.

■ INSTRUCTION MANUAL

This manual describes necessary points of caution when you use this product, including installation, connection and basic maintenance procedures.

POINTS OF CAUTION**■ POWER INPUT RATING & OPERATIONAL RANGE**

- Locate the power input rating marked on the product and confirm its operational range as indicated below:
85 – 132V AC rating: 85 – 132V, 47 – 66 Hz, approx. 4VA
24V DC rating: 24V ±10%, approx. 4W, approx. 160mA

■ GENERAL PRECAUTIONS

- Before you remove the unit or mount it, turn off the power supply, input signal and output signal for safety.

■ ENVIRONMENT

- Indoor use.
- When heavy dust or metal particles are present in the air, install the unit inside proper housing with sufficient ventilation.
- Do not install the unit where it is subjected to continuous vibration. Do not subject the unit to physical impact.
- Environmental temperature must be within -5 to +55°C (23 to 131°F) with relative humidity within 30 to 90% RH in order to ensure adequate life span and operation.

■ WIRING

- Do not install cables close to noise sources (relay drive cable, high frequency line, etc.).
- Do not bind these cables together with those in which noises are present. Do not install them in the same duct.


■ AND

- The unit is designed to function as soon as power is supplied, however, a warm up for 10 minutes is required for satisfying complete performance described in the data sheet.


INSTALLATION

Use the Installation Base (model: MxBS2).

COMPONENT IDENTIFICATION



FRONT PANEL CONFIGURATION




	NAME	FUNCTIONS					
A	Modular jack for factory calibration	Used only for factory calibration.					
B	Power indicator LED	green LED, ON when power is supplied.					
C	Node address setting	Selectable within 01 – F7. (factory set to: 00)					
D	Transmission setting	Baud rate	SW	BAUD RATE (bps)			
				38.4 k	19.2 k	9600	4800
			1	ON	OFF	ON	OFF
		2	ON	ON	OFF	OFF	
		3	OFF	OFF	OFF	OFF	
		Parity	SW	PARITY			
	NONE		ODD	EVEN	N/A		
4	ON		OFF	ON	OFF		
Data	SW	DATA					
		RTU (Binary)	ASCII				
	6	ON	OFF				
E	Status indicator LED	MARKING (color)	FUNCTIONS				
		L RUN (red)	ON for 10 sec. when the modules receives data.				
		L ERR. (red)	ON at errors in parity, framing, overrun, CRC, LRC				
		SD (red)	ON when transmitting				
	RD (red)	ON when receiving					
F	Euro type connector terminal for Modbus	For wiring to Modbus					


TERMINAL CONNECTIONS

Connect the unit as in the diagram below.

EXTERNAL DIMENSIONS unit: mm (inch)



CONNECTION DIAGRAM



*Attach the terminating resistor when the module is at the termination of a transmission line.


WIRING INSTRUCTIONS

EURO TYPE CONNECTOR TERMINAL (Modbus)

Applicable wire size: 0.2 to 2.5 mm² (AWG24 to 12)

Stripped length: 7 mm

COMMUNICATION CABLE CONNECTIONS



MODBUS FUNCTION CODES & SUPPORTED CODES

■ Data and Control Functions

CODE	NAME		
01	Read Coil Status	X	Digital output from the slave
02	Read Input Status	X	Status of digital inputs to the slave
03	Read Holding Registers	X	General purpose register within the slave
04	Read Input Registers	X	Collected data from the field by the slave
05	Force Single Coil	X	Digital output from the slave
06	Preset Single Registers	X	General purpose register within the slave
07	Read Exception Status		
08	Diagnostics	X	
09	Program 484		
10	Poll 484		
11	Fetch Comm. Event Counter		Fetch a status word and an event counter
12	Fetch Comm. Event Log		A status word, an event counter, a message count and a field of event bytes
13	Program Controller		
14	Poll Controller		
15	Force Multiple Coils	X	Digital output from the slave
16	Preset Multiple Registers	X	General purpose register within the slave
17	Report Slave ID		Slave type / 'RUN' status
18	Program 884/M84		
19	Reset Comm. Link		
20	Read General Reference		
21	Write General Reference		
22	Mask Write 4X Register		
23	Read/Write 4X Register		
24	Read FIFO Queue		

■ Exception Codes

CODE	NAME		
01	Illegal Function	X	Function code is not allowable for the slave
02	Illegal Data Address	X	Address is not available within the slave
03	Illegal Data Value	X	Data is not valid for the function
04	Slave Device Failure		
05	Acknowledge		
06	Slave Device Busy		
07	Negative Acknowledge		
08	Memory Parity Error		

■ Diagnostic Subfunctions

CODE	NAME		
00	Return Query Data	X	Loop back test
01	Restart Comm. Option	X	Reset the slave and clear all counters
02	Return Diagnostic Register	X	Contents of the diagnostic data (2 bytes)
03	Change ASCII Input Delimiter	X	Delimiter character of ASCII message
04	Force Listen Only Mode	X	Force the slave into Listen Only Mode

MODBUS I/O ASSIGNMENTS

	ADDRESS	61M TYPE		DATA TYPE	DATA
		1	2		
Coil (0X)	1 – 16	X			Averaging SW *
	17 – 32	X			Sampling rate SW **
Inputs (1X)	1 – 16	X	X		Analog channel status (active channel)
	17 – 32	X	X		Analog status (out of range)
Input Registers (3X)	1 – 16	X		I	Analog input
	17 – 48	X		F	Analog input
Holding Registers (4X)	1 – 16		X	I	Analog output
	17 – 48		X	F	Analog output
	49 – 80	X	X	F	Full scale
	81 – 112	X	X	F	Zero scale

■ 61M Type

- 1: Analog input
2: Analog output

■ Data Type

- F: Floating
I : Int 0 – 10000 (0 – 100%)

* Averaging SW

- 1: 4 samples
2: 2 samples
3: None

** Sampling rate SW

- 17: 400 millisecc.
18: 240 millisecc.
19: 160 millisecc.

LIGHTNING SURGE PROTECTION

M-System offers a series of lightning surge protectors for protection against induced lightning surges. Please contact M-System to choose appropriate models.