

BEFORE USE

Thank you for choosing M-System. Before use, please check contents of the package you received as outlined below.

If you have any problems or questions with the product, please contact M-System's Sales Office or representatives.

■ PACKAGE INCLUDES:

DC current input module.....(1)

■ MODEL NO.

Confirm Model No. marking on the product to be exactly what you ordered.

■ INSTRUCTION MANUAL

This manual describes necessary points of caution when you use this product, including installation, connection and basic maintenance procedures.

POINTS OF CAUTION**■ CONFORMITY WITH EU DIRECTIVES**

- The equipment must be mounted inside the instrument panel of a metal enclosure.
- The actual installation environments such as panel configurations, connected devices, connected wires, may affect the protection level of this unit when it is integrated in a panel system. The user may have to review the CE requirements in regard to the whole system and employ additional protective measures to ensure the CE conformity.

■ HOT SWAPPABLE MODULES

- Replacing the module does not affect other modules on the same base. Thus, the module can be replaced while the power is ON. However, replacing multiple modules at once may greatly change live voltage levels. We highly recommend to replace them one by one.

■ GENERAL PRECAUTIONS

- DO NOT set the switches on the module while the power is supplied. The switches are used only for maintenance without the power.

■ ENVIRONMENT

- Indoor use.
- When heavy dust or metal particles are present in the air, install the unit inside proper housing with sufficient ventilation.
- Do not install the unit where it is subjected to continuous vibration. Do not subject the unit to physical impact.
- Environmental temperature must be within -10 to +55°C (14 to 131°F) with relative humidity within 30 to 90% RH in order to ensure adequate life span and operation.

■ WIRING

- Do not install cables close to noise sources (relay drive cable, high frequency line, etc.).
- Do not bind these cables together with those in which noises are present. Do not install them in the same duct.

■ UNUSED INPUT CHANNELS

- Set the unused channels to "Unused" with PC Configurator software: R3CON. Unused channels left open may be equal to the input lower than -15%, which sets a data abnormality at the PLC or the host device.

■ AND


- The unit is designed to function as soon as power is supplied, however, a warm up for 10 minutes is required for satisfying complete performance described in the data sheet.

INSTALLATION


Use the Installation Base (model: R3-BSx)

COMPONENT IDENTIFICATION

■ FRONT VIEW



■ SIDE VIEW



■ STATUS INDICATOR LED

RUN indicator: Bi-color (red/green) LED;

Red when the bus A operates normally;
Green when the bus B operates normally;
Amber when both buses operate normally.

ERR indicator: Bi-color (red/green) LED;

Red with input circuit abnormality (AD converter response failure);
Green in normal operating conditions.

■ SIDE DIP SW

• **Conversion Rate: SW3-1, 3-2**

| SW | CONVERSION RATE | | | |
|-------|-----------------|-------|-------|-------|
| | 160 ms (*) | 80 ms | 40 ms | 20 ms |
| SW3-1 | OFF | ON | OFF | ON |
| SW3-2 | OFF | OFF | ON | ON |

(*) Factory setting

Note: Be sure to set unused SW3-3 and 3-4 to OFF.

PC CONFIGURATOR

With configurator software, settings shown below are available.
Refer to the software manual of R3CON for detailed operation.


■ CHANNEL INDIVIDUAL SETTING

| PARAMETER | AVAILABLE RANGE | DEFAULT SETTING |
|-------------|-------------------------|-----------------|
| Zero Scale | -32000 to +32000 | 0 |
| Full Scale | -32000 to +32000 | 10000 |
| Zero Adjust | -320.00 to +320.00 | 0.00 |
| Full Adjust | -32000 to +32000 | 1.0000 |
| Unused | 0: Enable 1: Disable | 0: Enable |


TERMINAL CONNECTIONS

Connect the unit as in the diagram below.

■ EXTERNAL DIMENSIONS unit: mm (inch)



■ CONNECTION DIAGRAM



*For dual redundant communication.

INPUT CONNECTOR (40-pin)

| PIN NO. | ASSIGNMENT | PIN NO. | ASSIGNMENT |
|---------|------------|---------|------------|
| 1A | NC | 1B | NC |
| 2A | NC | 2B | NC |
| 3A | NC | 3B | NC |
| 4A | NC | 4B | NC |
| 5A | - IN8 | 5B | - IN8 |
| 6A | - IN4 | 6B | - IN4 |
| 7A | + IN8 | 7B | + IN8 |
| 8A | + IN4 | 8B | + IN4 |
| 9A | - IN7 | 9B | - IN7 |
| 10A | - IN3 | 10B | - IN3 |
| 11A | + IN7 | 11B | + IN7 |
| 12A | + IN3 | 12B | + IN3 |
| 13A | - IN6 | 13B | - IN6 |
| 14A | - IN2 | 14B | - IN2 |
| 15A | + IN6 | 15B | + IN6 |
| 16A | + IN2 | 16B | + IN2 |
| 17A | - IN5 | 17B | - IN5 |
| 18A | - IN1 | 18B | - IN1 |
| 19A | + IN5 | 19B | + IN5 |
| 20A | + IN1 | 20B | + IN1 |