



Programmable Controller

MELSEC iQ-F
series

MELSEC iQ-F
FX5 User's Manual (CC-Link IE)

SAFETY PRECAUTIONS

(Read these precautions before use.)

Before using this product, please read this manual and the relevant manuals introduced in this manual carefully and pay full attention to safety in order to handle the product correctly.

This manual classifies the safety precautions into two categories: [ WARNING] and [ CAUTION].

| | |
|--|---|
|  WARNING | Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury. |
|  CAUTION | Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage. |

Depending on the circumstances, procedures indicated by [ CAUTION] may also cause severe injury.

It is important to follow all precautions for personal safety.

Store this manual in a safe place so that it can be read whenever necessary. Always forward it to the end user.

[DESIGN PRECAUTIONS]

WARNING

- Make sure to set up the following safety circuits outside the PLC to ensure safe system operation even during external power supply problems or PLC failure. Otherwise, malfunctions may cause serious accidents.
 - Most importantly, set up the following: an emergency stop circuit, a protection circuit, an interlock circuit for opposite movements (such as normal vs. reverse rotation), and an interlock circuit to prevent damage (to the equipment at the upper and lower positioning limits).
 - Note that when the CPU module detects an error, such as a watchdog timer error, during self-diagnosis, all outputs are turned off. Also, when an error that cannot be detected by the CPU module occurs in an input/output control block, output control may be disabled. External circuits and mechanisms should be designed to ensure safe machinery operation in such a case.
 - Note that when an error occurs in a relay or transistor or triac of an output circuit, the output might stay on or off. For output signals that may lead to serious accidents, external circuits and mechanisms should be designed to ensure safe machinery operation in such a case.
 - In an output circuit, when a load current exceeding the current rating or an overcurrent caused by a load short-circuit flows for a long time, it may cause smoke and fire. To prevent this, configure an external safety circuit, such as a fuse.
 - For the operating status of each station after a communication failure of the network, refer to relevant manuals for the network. Incorrect output or malfunction may result in an accident.
 - Construct an interlock circuit in the program so that the whole system always operates on the safe side before executing the control (for data change) of the PLC in operation.

Read the manual thoroughly and ensure complete safety before executing other controls (for program change, parameter change, forcible output and operation status change) of the PLC in operation. Otherwise, the machine may be damaged and accidents may occur due to erroneous operations.
 - Especially, in the case of a control from an external device to a remote programmable controller, immediate action cannot be taken for a problem on the programmable controller due to a communication failure. Determine the handling method as a system when communication failure occurs along with configuration of interlock circuit on a program, by considering the external equipment and CPU module.
-

WARNING

- Do not write any data to the "system area" and "write-protect area" of the buffer memory in the module. Executing data writing to the "system area" or "write protect area" may cause malfunction of the programmable controller alarm. For the "system area" or "write-protect area", refer to  Page 134 Buffer Memory.
 - If a communication cable is disconnected, the network may be unstable, resulting in a communication failure of multiple stations. Construct an interlock circuit in the program so that the system always operates on the safe side even if communications fail. Incorrect output or malfunction may result in an accident.
-

[DESIGN PRECAUTIONS]

CAUTION

- Do not bundle the control line and communication cables together with or lay them close to the main circuit or power line. As a guideline, lay the control line and communication cables at least 100 mm away from the main circuit or power line. Failure to do so may result in malfunction due to noise.
 - Simultaneously turn on and off the power supplies of the CPU module and extension modules.
-

[SECURITY PRECAUTIONS]

WARNING

- To maintain the security (confidentiality, integrity, and availability) of the programmable controller and the system against unauthorized access, denial-of-service (DoS) attacks, computer viruses, and other cyberattacks from unreliable networks and devices via network, take appropriate measures such as firewalls, virtual private networks (VPNs), and antivirus solutions.
-

[INSTALLATION PRECAUTIONS]

WARNING

- Make sure to cut off all phases of the power supply externally before attempting installation or wiring work. Failure to do so may cause electric shock or damage to the product.
 - Use the product within the generic environment specifications described in the User's Manual (Hardware) of the CPU module used.
Never use the product in areas with excessive dust, oily smoke, conductive dusts, corrosive gas (salt air, Cl₂, H₂S, SO₂ or NO₂), flammable gas, vibration or impacts, or expose it to high temperature, condensation, or rain and wind.
If the product is used in such conditions, electric shock, fire, malfunctions, deterioration or damage may occur.
-

[INSTALLATION PRECAUTIONS]

CAUTION

- Do not touch the conductive parts of the product directly. Doing so may cause device failures or malfunctions.
 - When drilling screw holes or wiring, make sure that cutting and wiring debris do not enter the ventilation slits of the PLC. Failure to do so may cause fire, equipment failures or malfunctions.
 - For the product supplied together with a dust proof sheet, the sheet should be affixed to the ventilation slits before the installation and wiring work to prevent foreign objects such as cutting and wiring debris.
However, when the installation work is completed, make sure to remove the sheet to provide adequate ventilation. Failure to do so may cause fire, equipment failures or malfunctions.
 - Install the product on a flat surface. If the mounting surface is rough, undue force will be applied to the PC board, thereby causing nonconformities.
 - Install the product securely using a DIN rail or mounting screws.
 - Work carefully when using a screwdriver such as installation of the product. Failure to do so may cause damage to the product or accidents.
 - Connect the extension cables, peripheral device cables, input/output cables and battery connecting cable securely to their designated connectors. Loose connections may cause malfunctions.
 - Turn off the power to the PLC before attaching or detaching the following devices. Failure to do so may cause device failures or malfunctions.
 - Peripheral devices, expansion board, expansion adapter, and connector conversion adapter
 - Extension modules, bus conversion module, and connector conversion module
 - Battery
-

[WIRING PRECAUTIONS]

WARNING

- Make sure to cut off all phases of the power supply externally before attempting installation or wiring work. Failure to do so may cause electric shock or damage to the product.
 - Make sure to attach the terminal cover, provided as an accessory, before turning on the power or initiating operation after installation or wiring work. Failure to do so may cause electric shock.
 - The temperature rating of the cable should be 80°C or more.
 - Make sure to wire the screw terminal block in accordance with the following precautions. Failure to do so may cause electric shock, equipment failures, a short-circuit, wire breakage, malfunctions, or damage to the product.
 - The disposal size of the cable end should follow the dimensions described in the User's Manual (Hardware) of the CPU module used.
 - Tightening torque should follow the specifications in the User's Manual (Hardware) of the CPU module used.
 - Tighten the screws using a Phillips-head screwdriver No. 2 (shaft diameter 6 mm or less). Make sure that the screwdriver does not touch the partition part of the terminal block.
-

[WIRING PRECAUTIONS]

CAUTION

- Perform class D grounding (grounding resistance: 100 Ω or less) of the grounding terminal on the CPU module and extension modules with a wire 2 mm² or thicker.
Do not use common grounding with heavy electrical systems (refer to the User's Manual (Hardware) of the CPU module used).
 - Connect the power supply wiring to the dedicated terminals described in this manual. If an AC power supply is connected to a DC input/output terminal or DC power supply terminal, the PLC will burn out.
 - Do not wire vacant terminals externally. Doing so may damage the product.
 - Install module so that excessive force will not be applied to terminal blocks, power connectors, I/O connectors, communication connectors, or communication cables. Failure to do so may result in wire damage/breakage or PLC failure.
 - Make sure to observe the following precautions in order to prevent any damage to the machinery or accidents due to malfunction of the PLC caused by abnormal data written to the PLC due to the effects of noise:
 - Do not bundle the power line, control line and communication cables together with or lay them close to the main circuit, high-voltage line, load line or power line. As a guideline, lay the power line, control line and connection cables at least 100 mm away from the main circuit, high-voltage line, load line or power line.
 - Ground the shield of the shielded wire or shield cable at one point on the PLC. However, do not use common grounding with heavy electrical systems.
-

[STARTUP AND MAINTENANCE PRECAUTIONS]

WARNING

- Do not touch any terminal while the PLC's power is on. Doing so may cause electric shock or malfunctions.
 - Before cleaning or retightening terminals, cut off all phases of the power supply externally. Failure to do so in the power ON status may cause electric shock.
 - Before modifying the program in operation, forcible output, running or stopping the PLC, read through this manual carefully, and ensure complete safety. An operation error may damage the machinery or cause accidents.
 - Do not change the program in the PLC from two or more peripheral equipment devices at the same time. (i. e. from an engineering tool and a GOT) Doing so may cause destruction or malfunction of the PLC program.
-

[STARTUP AND MAINTENANCE PRECAUTIONS]

CAUTION

- Do not disassemble or modify the PLC. Doing so may cause fire, equipment failures, or malfunctions. For repair, contact your local Mitsubishi Electric representative.
 - Turn off the power to the PLC before connecting or disconnecting any extension cable. Failure to do so may cause device failures or malfunctions.
 - Turn off the power to the PLC before attaching or detaching the following devices. Failure to do so may cause device failures or malfunctions.
 - Peripheral devices, expansion board, expansion adapter, and connector conversion adapter
 - Extension modules, bus conversion module, and connector conversion module
 - Battery
-

[OPERATION PRECAUTIONS]

CAUTION

- Construct an interlock circuit in the program so that the whole system always operates on the safe side before executing the control (for data change) of the PLC in operation. Read the manual thoroughly and ensure complete safety before executing other controls (for program change, parameter change, forcible output and operation status change) of the PLC in operation. Otherwise, the machine may be damaged and accidents may occur by erroneous operations.
 - Note that the whole system may not be reset by the RUN/STOP/RESET switch when the CPU module or intelligent function module detects an error, such as a watchdog timer error, during self-diagnosis. In that case, turn off and on the power.
-

[DISPOSAL PRECAUTIONS]

CAUTION

- Please contact a certified electronic waste disposal company for the environmentally safe recycling and disposal of your device.
-

[TRANSPORTATION PRECAUTIONS]

CAUTION

- The PLC is a precision instrument. During transportation, avoid impacts larger than those specified in the general specifications of the User's Manual (Hardware) of the CPU module used by using dedicated packaging boxes and shock-absorbing pallettes. Failure to do so may cause failures in the PLC. After transportation, verify operation of the PLC and check for damage of the mounting part, etc.
-

INTRODUCTION

This manual contains text, diagrams and explanations which will guide the reader in the correct installation, safe use and operation of the CC-Link IE Field Network module of MELSEC iQ-F series and should be read and understood before attempting to install or use the module.

Always forward it to the end user.

Regarding use of this product

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult Mitsubishi Electric.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

Note

- If in doubt at any stage during the installation of the product, always consult a professional electrical engineer who is qualified and trained in the local and national standards. If in doubt about the operation or use, please consult the nearest Mitsubishi Electric representative.
- Since the examples indicated by this manual, technical bulletin, catalog, etc. are used as a reference, please use it after confirming the function and safety of the equipment and system. Mitsubishi Electric will accept no responsibility for actual use of the product based on these illustrative examples.
- This manual content, specification etc. may be changed, without a notice, for improvement.
- The information in this manual has been carefully checked and is believed to be accurate; however, if you notice a doubtful point, an error, etc., please contact the nearest Mitsubishi Electric representative. When doing so, please provide the manual number given at the end of this manual.

MEMO

CONTENTS

| | |
|--|-----------|
| SAFETY PRECAUTIONS | 1 |
| INTRODUCTION | 6 |
| RELEVANT MANUALS | 11 |
| TERMS | 11 |
| CHAPTER 1 OUTLINE | 13 |
| CHAPTER 2 SPECIFICATIONS | 15 |
| 2.1 General Specifications | 15 |
| 2.2 Power Supply Specifications | 15 |
| 2.3 Performance Specifications | 15 |
| 2.4 Part Names | 16 |
| LED display | 17 |
| CHAPTER 3 PROCEDURES BEFORE OPERATION | 18 |
| CHAPTER 4 FUNCTIONS | 20 |
| 4.1 Function List | 20 |
| 4.2 Cyclic Transmission | 21 |
| Data flow and link device assignment | 21 |
| Link refresh | 23 |
| Cyclic data integrity assurance | 24 |
| Input and output status settings when failure occurs | 28 |
| Output status setting for CPU STOP | 29 |
| Output status setting for CPU stop error | 29 |
| Cyclic transmission stop and restart | 29 |
| 4.3 Transient Transmission | 30 |
| Communications within the same network | 30 |
| Communications with different networks | 30 |
| 4.4 Interrupt Request to CPU Module | 31 |
| CHAPTER 5 SYSTEM CONFIGURATION | 32 |
| 5.1 CC-Link IE Field Network Configuration | 32 |
| 5.2 Precautions for System Configuration | 34 |
| CHAPTER 6 WIRING | 35 |
| 6.1 Power Supply Wiring | 35 |
| Grounding | 35 |
| 6.2 Wiring of CC-Link IE Field Network | 36 |
| CHAPTER 7 PARAMETER SETTINGS | 38 |
| 7.1 Setting Parameters | 38 |
| 7.2 Required Settings | 38 |
| Network Number | 39 |
| Station Number | 39 |
| Parameter Setting Method | 39 |
| 7.3 Basic Settings | 40 |
| Refresh setting | 40 |

| | | |
|--|--|------------|
| 7.4 | Application Settings | 42 |
| | Supplementary Cyclic Settings | 42 |
| | Interrupt Settings | 43 |
| | Parameter Name | 45 |
| | Module Operation Mode | 45 |
| CHAPTER 8 DEDICATED INSTRUCTION | | 46 |
| 8.1 | Precautions for Dedicated Instructions | 48 |
| 8.2 | Link Dedicated Instructions | 49 |
| | Reading data from the programmable controller on another station | 49 |
| | Reading data from the programmable controller on another station (with notification) | 57 |
| | Writing data to the programmable controller on another station | 63 |
| | Writing data to the programmable controller on another station (with notification) | 72 |
| | Sending data to the programmable controller on another station | 79 |
| | Receiving data from the programmable controller on another station | 90 |
| 8.3 | Other Instructions | 96 |
| | Setting parameters | 96 |
| | Setting the station number to own station | 102 |
| CHAPTER 9 PROGRAMMING | | 107 |
| 9.1 | Procedure for Creating Programs | 107 |
| CHAPTER 10 TROUBLESHOOTING | | 112 |
| 10.1 | Checking with LEDs | 112 |
| 10.2 | Checking the Module Status | 115 |
| 10.3 | Checking the Network Status | 116 |
| 10.4 | Troubleshooting for Each Symptom | 120 |
| 10.5 | List of Error Codes | 122 |
| 10.6 | List of Parameter Numbers | 131 |
| APPENDIX | | 132 |
| Appendix 1 Standards | | 132 |
| | Certification of UL, cUL standards | 132 |
| | Compliance with EC Directive (CE marking) | 132 |
| | Requirement for compliance with EMC Directive | 132 |
| | Caution for compliance with EC Directive | 133 |
| | Compliance with UKCA marking | 133 |
| Appendix 2 Buffer Memory | | 134 |
| | List of buffer memory addresses | 134 |
| | Details of buffer memory addresses | 135 |
| Appendix 3 List of Link Special Relay (SB) | | 137 |
| Appendix 4 List of Link Special Register (SW) | | 141 |
| Appendix 5 Processing Time | | 144 |
| | I/O response time | 144 |
| | FROM/TO processing time | 144 |
| Appendix 6 Added and Changed Functions | | 145 |
| INDEX | | 146 |

| | |
|------------------|-----|
| REVISIONS | 148 |
| WARRANTY | 149 |
| TRADEMARKS | 150 |

RELEVANT MANUALS

| Manual name <manual number> | Description |
|---|---|
| MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware) <SH-082452ENG> | Describes the details of hardware of the FX5 CPU module, including performance specifications, wiring, installation, and maintenance. |
| MELSEC iQ-F FX5 User's Manual (Application) <JY997D55401> | Describes the basic knowledge required for program design, functions of the CPU module, devices/labels, and parameters. |
| MELSEC iQ-F FX5 Programming Manual (Program Design) <JY997D55701> | Describes the specifications of ladder, ST, FBD/LD, and SFC programs, and labels. |
| MELSEC iQ-F FX5 Programming Manual (Instructions, Standard Functions/Function Blocks) <JY997D55801> | Describes the specifications of instructions and functions that can be used in programs. |
| MELSEC iQ-F FX5 User's Manual (CC-Link IE) <JY997D64201> (This manual) | Describes the CC-Link IE field network module. |
| GX Works3 Operating Manual <SH-081215ENG> | Describes the system configuration, parameter settings, and online operations of GX Works3. |

TERMS

Unless otherwise specified, this manual uses the following terms.

For details on the FX3 devices that can be connected with the FX5, refer to the User's Manual (Hardware) of the CPU module to be used.

| Terms | Description |
|---|--|
| ■Devices | |
| FX5 | Generic term for FX5S, FX5UJ, FX5U, and FX5UC PLCs |
| FX3 | Generic term for FX3S, FX3G, FX3GC, FX3U, and FX3UC PLCs |
| FX5 CPU module | Generic term for FX5S CPU module, FX5UJ CPU module, FX5U CPU module, and FX5UC CPU module |
| FX5S CPU module | Generic term for FX5S-30MR/ES, FX5S-40MR/ES, FX5S-60MR/ES, FX5S-80MR/ES ^{*1} , FX5S-30MT/ES, FX5S-40MT/ES, FX5S-60MT/ES, FX5S-80MT/ES ^{*1} , FX5S-30MT/ESS, FX5S-40MT/ESS, FX5S-60MT/ESS, and FX5S-80MT/ESS ^{*1} |
| FX5UJ CPU module | Generic term for FX5UJ-24MR/ES, FX5UJ-24MT/ES, FX5UJ-24MT/ESS, FX5UJ-40MR/ES, FX5UJ-40MT/ES, FX5UJ-40MT/ESS, FX5UJ-60MR/ES, FX5UJ-60MT/ES, and FX5UJ-60MT/ESS |
| FX5U CPU module | Generic term for FX5U-32MR/ES, FX5U-32MT/ES, FX5U-32MT/ESS, FX5U-64MR/ES, FX5U-64MT/ES, FX5U-64MT/ESS, FX5U-80MR/ES, FX5U-80MT/ES, FX5U-80MT/ESS, FX5U-32MR/DS, FX5U-32MT/DS, FX5U-64MR/DS, FX5U-64MT/DS, FX5U-64MT/DSS, FX5U-80MR/DS, FX5U-80MT/DS, and FX5U-80MT/DSS |
| FX5UC CPU module | Generic term for FX5UC-32MT/D, FX5UC-32MT/DSS, FX5UC-64MT/D, FX5UC-64MT/DSS, FX5UC-96MT/D, FX5UC-96MT/DSS, FX5UC-32MT/DS-TS, FX5UC-32MT/DSS-TS, and FX5UC-32MR/DS-TS |
| Extension module | Generic term for FX5 extension modules, FX3 function modules, Extension modules (extension cable type) and Extension module (extension connector type) |
| FX5 extension module | Generic term for I/O modules, FX5 extension power supply modules, FX5 intelligent function modules, and FX5 safety extension modules |
| FX3 extension module | Generic term for FX3 extension power supply module and FX3 intelligent function module |
| Extension module (extension cable type) | Generic term for Input modules (extension cable type), Output modules (extension cable type), Input/output modules (extension cable type), Powered input/output module, High-speed pulse input/output module, Extension power supply module (extension cable type), Connector conversion module (extension cable type), Intelligent function modules, Safety extension modules, and Bus conversion module (extension cable type) |
| Extension module (extension connector type) | Generic term for Input modules (extension connector type), Output modules (extension connector type), Input/output modules (extension connector type), Extension power supply module (extension connector type), Connector conversion module (extension connector type), and Bus conversion module (extension connector type) |
| I/O module | Generic term for Input modules, Output modules, Input/output modules, Powered input/output modules, and High-speed pulse input/output modules |
| Input module | Generic term for Input modules (extension cable type) and Input modules (extension connector type) |
| Input module (extension cable type) | Generic term for FX5-8EX/ES and FX5-16EX/ES |
| Input module (extension connector type) | Generic term for FX5-C16EX/D, FX5-C16EX/DS, FX5-C32EX/D, FX5-C32EX/DS, and FX5-C32EX/DS-TS |
| Output module | Generic term for Output modules (extension cable type) and Output modules (extension connector type) |
| Output module (extension cable type) | Generic term for FX5-8EYR/ES, FX5-8EYT/ES, FX5-8EYT/ESS, FX5-16EYR/ES, FX5-16EYT/ES, and FX5-16EYT/ESS |

| Terms | Description |
|--|---|
| Output module (extension connector type) | Generic term for FX5-C16EYT/D, FX5-C16EYT/DSS, FX5-C16EYR/D-TS, FX5-C32EYT/D, FX5-C32EYT/DSS, FX5-C32EYT/D-TS, and FX5-C32EYT/DSS-TS |
| Input/output module | Generic term for Input/output modules (extension cable type) and Input/output modules (extension connector type) |
| Input/output module (extension cable type) | Generic term for FX5-16ER/ES, FX5-16ET/ES, and FX5-16ET/ESS |
| Input/output module (extension connector type) | Generic term for FX5-C32ET/D, FX5-C32ET/DSS, FX5-C32ET/DS-TS, and FX5-C32ET/DSS-TS |
| Powered input/output module | Generic term for FX5-32ER/ES, FX5-32ET/ES, FX5-32ET/ESS, FX5-32ER/DS, FX5-32ET/DS, and FX5-32ET/DSS |
| High-speed pulse input/output module | Generic term for FX5-16ET/ES-H and FX5-16ET/ESS-H |
| Extension power supply module | Generic term for FX5 extension power supply module and FX3 extension power supply module |
| FX5 extension power supply module | Generic term for FX5 extension power supply module (extension cable type) and FX5 extension power supply module (extension connector type) |
| FX5 extension power supply module (extension cable type) | Different name for FX5-1PSU-5V |
| FX5 extension power supply module (extension connector type) | Different name for FX5-C1PS-5V |
| FX3 extension power supply module | Different name for FX3U-1PSU-5V |
| Intelligent module | The abbreviation for intelligent function modules |
| Intelligent function module | Generic term for FX5 intelligent function modules and FX3 intelligent function modules |
| FX5 intelligent function module | Generic term for FX5-4AD, FX5-4DA, FX5-8AD, FX5-4LC, FX5-20PG-P, FX5-20PG-D, FX5-40SSC-G, FX5-80SSC-G, FX5-40SSC-S, FX5-80SSC-S, FX5-ENET, FX5-ENET/IP, FX5-CCLGN-MS, FX5-CCLIEF, FX5-CCL-MS, FX5-ASL-M, and FX5-DP-M |
| FX3 intelligent function module | Generic term for FX3U-4AD, FX3U-4DA, FX3U-4LC, FX3U-1PG, FX3U-2HC, FX3U-16CCL-M, FX3U-64CCL, FX3U-128ASL-M, and FX3U-32DP |
| FX5 safety extension module | Generic term for safety main modules and safety expansion modules |
| Safety main module | Different name for FX5-SF-MU4T5 |
| Safety expansion module | Generic term for expansion modules installed to a safety main module |
| Safety input expansion module | Different name for FX5-SF-8DI4 |
| Expansion board | Generic term for board for FX5S CPU module, FX5UJ CPU module, and FX5U CPU module |
| Communication board | Generic term for FX5-232-BD, FX5-485-BD, and FX5-422-BD-GOT |
| Expansion adapter | Generic term for adapter for FX5 CPU module |
| Communication adapter | Generic term for FX5-232ADP and FX5-485ADP |
| Analog adapter | Generic term for FX5-4AD-ADP, FX5-4DA-ADP, FX5-4AD-PT-ADP, FX5-4AD-TC-ADP, and FX5-4A-ADP |
| Bus conversion module | Generic term for Bus conversion module (extension cable type) and Bus conversion module (extension connector type) |
| Bus conversion module (extension cable type) | Different name for FX5-CNV-BUS |
| Bus conversion module (extension connector type) | Different name for FX5-CNV-BUSC |
| Connector conversion module | Generic term for Connector conversion module (extension cable type) and Connector conversion module (extension connector type) |
| Connector conversion module (extension cable type) | Different name for FX5-CNV-IF |
| Connector conversion module (extension connector type) | Different name for FX5-CNV-IFC |
| Extended extension cable | Generic term for FX5-30EC and FX5-65EC |
| Connector conversion adapter | Different name for FX5-CNV-BC |
| Battery | Different name for FX3U-32BL |
| Peripheral device | Generic term for engineering tools and GOTs |
| GOT | Generic term for Mitsubishi Electric Graphic Operation Terminal GOT1000 and GOT2000 series |
| ■Software packages | |
| Engineering tool | The product name of the software package for the MELSEC programmable controllers |
| GX Works3 | The product name of the software package, SWnDND-GXW3, for the MELSEC programmable controllers (The 'n' represents a version.) |

*1 Area-specific model


1 OUTLINE

- CC-Link IE Field Network is a high-speed (1 Gbps) and large-capacity open field network using Ethernet (1000BASE-T).
- The FX5-CCLIEF is the intelligent function module to connect the FX5 CPU module as an intelligent device station of CC-Link IE Field Network.
- Wiring of CC-Link IE Field Network supports line topology, star topology, and ring topology.
- Data between the FX5 CPU module and FX5-CCLIEF can be sent/received through the buffer memory using the FROM/TO instructions. Also, data can be replaced with an internal device (such as X, Y, B, W, SB, or SW) and used in a program when using the auto refresh function.

Data communication


■Cyclic transmission

Data can be periodically communicated with the master station on the same network.



■Transient transmission

Another station programmable controller can be accessed using dedicated instructions.



MEMO

2 SPECIFICATIONS

This chapter describes the FX5-CCLIEF specifications.

2.1 General Specifications

The general specifications other than below are the same as those for the FX5 CPU module to be connected.

For general specifications, refer to the following.

📖 MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware)

| Items | Specifications | |
|------------------------------|--|---|
| Dielectric withstand voltage | 500 V AC for 1 minute | Between all terminals and ground terminal |
| Insulation resistance | 10 MΩ or higher by 500 V DC insulation resistance tester | |

2.2 Power Supply Specifications

The following table lists the power supply specifications.

| Items | | Specifications |
|-----------------------|--|--|
| External power supply | Power supply voltage | 24 V DC +20%/-15% |
| | Allowable instantaneous power failure time | Operation continues when the instantaneous power failure is shorter than 1 ms. |
| | Current consumption | 230 mA |
| Internal power supply | Power supply voltage | 5 V DC |
| | Current consumption | 10 mA |

2.3 Performance Specifications

The following table lists the performance specifications.

| Items | | Specifications |
|---|-----|---|
| Station type | | Intelligent device station |
| Station number | | 1 to 120 (set by parameter or program) |
| Communication speed | | 1 Gbps |
| Network topology | | Line topology, star topology (coexistence of line topology and star topology is also possible), and ring topology |
| Maximum station-to-station distance | | 100 m (conforms to ANSI/TIA/EIA-568-B (Category 5e)) |
| Cascade connection | | Max. 20 stages |
| Communication method | | Token passing |
| Maximum number of link points ^{*1} | RX | 384 points, 48 bytes |
| | RY | 384 points, 48 bytes |
| | RWr | 1024 points, 2048 bytes ^{*2} |
| | RWw | 1024 points, 2048 bytes ^{*2} |
| Number of occupied I/O points | | 8 points |
| Applicable CPU module | | <ul style="list-style-type: none"> FX5UJ CPU module (From the first) FX5U CPU module (Ver. 1.030 or later) FX5UC CPU module^{*3} (Ver. 1.030 or later) |
| Applicable engineering tool | | <ul style="list-style-type: none"> FX5UJ CPU module: GX Works3 (Ver.1.060N or later) FX5U/FX5UC CPU module: GX Works3 (Ver.1.025B or later) |


*1 The maximum number of points that a master station can assign to one FX5-CCLIEF unit.

*2 256 points (512 bytes) when the mode of the master station is online (high-speed mode).

*3 FX5-CNV-IFC or FX5-C1PS-5V is necessary to connect FX5-CCLIEF to the FX5UC CPU module.

2.4 Part Names

This section describes the names of each part of the FX5-CCLIEF.



| No. | Name | Description |
|------|---|---|
| [1] | Modular jack for P2 (RJ-45) (with cap) | PORT2 connector for CC-Link IE Field Network. Connect an Ethernet cable. |
| [2] | Modular jack for P1 (RJ-45) (with cap) | PORT1 connector for CC-Link IE Field Network. Connect an Ethernet cable. |
| [3] | Extension cable | Cable for connecting the module when adding the FX5-CCIEF |
| [4] | Dot matrix LED | Displays the station number set in the module and the module communication test result. For display of the module communication test result, refer to the following. (☞ Page 115 Module communication test) |
| [5] | Direct mounting hole | Screw holes (2-φ4.5, mounting screw: M4 screw) for direct installation |
| [6] | Operation status display LEDs | Indicates the operating status of the module. For details, refer to the following. (☞ Page 17 LED display) |
| [7] | Extension connector | Connector for connecting the extension cable of an extension module. |
| [8] | Nameplate | The product model name, manufacturer's serial number, power supply specifications, and MAC address are shown. |
| [9] | DIN rail mounting groove | The module can be installed on DIN46277 rail (35 mm wide). |
| [10] | DIN rail mounting hook | Hook for mounting the module on a DIN rail of DIN46277 (35 mm wide). |
| [11] | Pullout tab | They are used when drawing out an extension cable. |
| [12] | Power connector | Connector for connecting the power cable. |

LED display

The following table lists the LED display.

| LED display | LED color | Description |
|-----------------------|-----------|---|
| D. LINK ^{*1} | Green | Indicates the data link status. On: Data link (cyclic transmission being performed) Flashing: Data link (cyclic transmission stopped) Off: Data link not performed (disconnection) |
| SD | Green | Indicates the data sending status. On: Data being sent Off: Data not sent |
| RD | Green | Indicates the data receiving status. On: Data being received Off: Data not received |
| L. ERR | Red | Indicates the line error status. On: Error data received Off: Normal data received |
| POWER | Green | Indicates whether the module is powered or not. On: Power-on Off: Power-off |
| RUN | Green | Indicates the operating status. On: Normal operation Off: Error |
| ERROR ^{*1} | Red | Indicates the error status. On: Minor error (major error when the RUN LED turns off) Flashing: Moderate error (major error when the RUN LED turns off) Off: Normal operation |
| P1 | LER | Red Indicates the port status of P1. On: Error data received Off: Normal data received |
| | LINK | Green Indicates the link status of P1. On: Link-up Off: Link-down |
| P2 | LER | Red Indicates the port status of P2. On: Error data received Off: Normal data received |
| | LINK | Green Indicates the link status of P2. On: Link-up Off: Link-down |
| Dot matrix LED | Orange | Displays the station number set in the module and the module communication test result. |

*1 The LED is always off in offline mode.

3 PROCEDURES BEFORE OPERATION

This chapter describes the procedures before operation.

1. Checking the specifications of the FX5-CCLIEF

Check the specifications of the FX5-CCLIEF. (☞ Page 15 SPECIFICATIONS)

2. Installation of the FX5-CCLIEF

Connect the FX5-CCLIEF to the FX5 CPU module. For details, refer to the following.

📖 MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware)

3. Wiring

Connect an Ethernet cable to the FX5-CCLIEF.

4. Checking the cable

Perform a cable test on the FX5-CCLIEF.

5. Network construction

Configure the system and set the parameters which are required for start-up.

- Wiring (☞ Page 35 WIRING)
- Parameter setting (☞ Page 38 PARAMETER SETTINGS)

6. Network diagnostics

Using network diagnostics, check if the cables are connected properly and communication is performed normally with the configured parameters.

For details, refer to the following.

(☞ Page 116 Checking the Network Status)

7. Programming

Create a program. For details, refer to the following.

(☞ Page 46 DEDICATED INSTRUCTION)

8. Debug

Debug the program by using CC-Link IE Field Network diagnostics.

4 FUNCTIONS

4.1 Function List

The following table lists the function available for the FX5-CCLIEF.

Cyclic transmission

| Function | | Description | Reference |
|---|----------------------------------|---|-----------|
| Communications with the master station | Communications using RX and RY | Communicates I/O data in units of bits between the own station and master station. | Page 21 |
| | Communications using RWr and RWw | Communicates I/O data in units of words between the own station and master station. | |
| Access to devices and link devices (Link refresh) | | Automatically transfers data between the link device of the FX5-CCLIEF and the device of the FX5 CPU module. | Page 23 |
| Cyclic data integrity assurance | | Assures the cyclic data integrity in units of 32 bits or station-based units. | Page 24 |
| Mode selection for cyclic transmission | | Selects the mode for optimizing the performance of cyclic transmission based on the cyclic transmission and transient transmission frequency. The mode is selected from "Normal" or "High Speed". This setting is available on the master station. | — |
| Input status setting for data link error | | Selects whether input data from the master station when a data link error occurs is cleared or held. | Page 28 |
| Output status setting for CPU STOP | | Selects whether cyclic transmission output is held or cleared when the FX5 CPU module connected to the FX5-CCLIEF is set to STOP. | Page 29 |
| Output status setting for CPU stop error | | Selects whether cyclic transmission output is held or cleared when a stop error occurs in the FX5 CPU module which the FX5-CCLIEF is connected to. | Page 29 |
| Cyclic transmission stop and restart | | Stops the cyclic data transmission during debugging and other operations. (Data reception from the master station and data sending from the own station are stopped.) Also, the stopped cyclic transmission can be restarted. Transient transmission does not stop. | Page 29 |

Transient transmission

| Function | Description | Reference |
|--|--|-----------|
| Communications within the same network | Performs transient transmission to other stations using dedicated instructions and the engineering tool. | Page 30 |
| Communications with different networks | Performs transient transmission seamlessly to stations on different networks using dedicated instructions. | Page 30 |
| SLMP communication | Reads/writes a device data or program file of the FX5 CPU module from/to upper system. | — |

RAS

| Function | Description | Reference |
|------------------|--|-----------|
| Automatic return | Automatically returns the station disconnected from the network due to a data link error to the network when it recovers and restarts data link. | — |

Diagnostics

| Function | | Description | Reference |
|--------------------------------------|---------------------------|---|-----------|
| CC-Link IE Field Network diagnostics | | Checks the status of the FX5-CCLIEF using the engineering tool. The cause of error and corrective actions can be checked in the engineering tool. | Page 116 |
| Diagnostics of the module | Module communication test | Checks the hardware of the FX5-CCLIEF. This test should be conducted when the communication is unstable. | Page 115 |
| Diagnostics of own network | Cable Test | Checks the connection status of the Ethernet cables. | Page 119 |

Others

| Function | Description | Reference |
|--|--|---|
| Interrupt request to CPU module | Checks interrupt conditions every link scan, and makes an interrupt request to the FX5 CPU module to start the interrupt program if the interrupt conditions are met. | Page 31 |
| Station number setting using a program | Sets the station number of the FX5-CCLIEF (own station) using a program. When there are systems with the same program and network parameters (excluding the station numbers), setting the station numbers using a program allows project data items other than the station number to be the same, leading to reduced development work hours. | Page 102 |
| Firmware update function | Updates the firmware version of the FX5-CCLIEF. | MELSEC iQ-F FX5 User's Manual (Application) |


4.2 Cyclic Transmission

This function allows data to be periodically exchanged among stations on the same network using link devices.

Data flow and link device assignment

Master station and device stations (except for local stations)

One-to-one communication is possible between the master and device stations. The status data of the link devices (RY, RWw) of the master station is output to the external device of the device station, and the input status information from the external device of the device station is stored in the link devices (RX, RWr) of the master station.



• Output from the master station


- ① The device of the CPU module turns on.
- ② The status data of the device of the CPU module are stored in the link devices (RY, RWw) of the master station by link refresh.
- ③ The status data of the link devices (RY, RWw) of the master station are stored in the link devices (RY, RWw) of each device station by link scan.
- ④ The status data of the link devices (RY, RWw) of the device station are output to the external device.

• Input from the device station

- ⑤ The status data of the external device are stored in the link devices (RX, RWr) of the device station.
- ⑥ The status data of the link devices (RX, RWr) of the device station are stored in the link devices (RX, RWr) of the master station by link scan.
- ⑦ The status data of the link devices (RX, RWr) of the master station are stored in the devices of the CPU module by link refresh.

Coexistence of local stations and the other device stations (other than local stations)

The data of all device stations are also stored in the local stations in the same way as the master station.




Setting method

The link refresh is assigned in "Refresh Setting" under "Basic Settings". (Page 40 Refresh setting)


Link refresh

This function automatically transfers data between the link devices of the FX5-CCLIEF and the devices of the CPU module.



Concept of the link refresh range (number of points)

The link refresh is performed to the area set with the refresh parameters.



Shortening the link refresh time and transmission delay time

The link refresh time and transmission delay time can be shortened by reducing the number of link refresh points to the CPU module. To reduce the number of the link refresh points, set only the link devices used in the FX5 CPU module as the link refresh range in the refresh parameters setting. (Page 40 Refresh setting)

Setting method

The link refresh is assigned in "Refresh Setting" under "Basic Settings". (Page 40 Refresh setting)

Precautions

■ Latched devices of the FX5 CPU module

If data in latched devices of the FX5 CPU module are cleared to zero on a program when the FX5 CPU module is powered off and on or reset, the data may be output without being cleared to zero, depending on the timing of the link scan and link refresh. Take the following actions not to output the data in the latched devices.

| FX5 CPU module device | How to disable the device data |
|--|---|
| Latch relay (L) | Use the initial device value of the FX5 CPU module to clear the device to zero.*1 |
| Internal relay (M), Link relay (B), Data register (D), Link register (W), File register (R), device in the latch range | Delete all the latch range settings.*2 |

*1 For the initial device value setting of the FX5 CPU module, refer to the following.

📖 MELSEC iQ-F FX5 User's Manual (Application)

*2 Only FX5U/FX5UC CPU module is supported.

Cyclic data integrity assurance

This function assures the cyclic data integrity in units of 32 bits or station-based units.

○: Assured, ×: Not assured

| Method | Description | Availability | |
|------------------------------------|--|--------------|-------------------------|
| | | Link refresh | Access to buffer memory |
| 32-bit data assurance | Assures data in 32-bit units. | ○ | ○ |
| Station-based block data assurance | Assures data in station-based units. Data is assured by enabling the station-based block data assurance in the parameter setting. | ○ | × |
| Interlock program | Assures data of more than 32 bits. Data is assured by performing interlocks on programs. | ○ | ○ |


32-bit data assurance

The RWr and RWw data can be assured in 32-bit units.

■Data integrity assurance at the time of access to buffer memory

The integrity of 32-bit data can be assured by satisfying the following conditions.

- Access using the DMOV instruction
- The head address of the buffer memory is multiples of 2.



Point

For data assurance of more than 32 bits, use station-based block data assurance or interlock programs.

Station-based block data assurance

Integrity of the cyclic data is assured for each station by handshake between the FX5 CPU module and FX5-CCLIEF for a link refresh.

■Setting


Enable "Station-based Block Data Assurance per Station" in the parameter settings of the master station.

Once this setting is enabled on the master station, integrity of the data for all stations is assured for each station.

For the setting method, refer to the manual for the master station module used.

■ Access to link devices

During a link refresh, data are assured for each station as shown below.




Interlock program

Data of more than 32 bits can be assured with the station-based block data assurance setting disabled. Use either of the following methods.


- Interlock using RX and RY
- Interlock using RWr and RWw (when RX, RY cannot be used as an interlock device)

■ Example of interlock using RX and RY

An example of sending data in W0 to W3 of the master station (station No. 0) to W1000 to W1003 of the device station (station No. 1) is shown below. (B0 and B1000 are used for a handshake to the CPU module.)




• Data flow




• Program

Sending station: Master station (station No. 0)



Receiving station: Device station (station No. 1)




• Program flow


- ① Sending station: 'Start direction' (M0) is turned on.
- ② Sending station: The contents of 'Transfer source' (D0 to D3) are stored in W0 to W3.
- ③ Sending station: Upon completion of storage in W0 to W3, turn on B0 of the sending station for a handshake.
- ④ Receiving station: Cyclic transmission sends RWw followed by RY, and B1000 of the receiving station turns on.
- ⑤ Receiving station: The contents of W1000 to W1003 are stored in 'Transfer destination' (D0 to D3).
- ⑥ Receiving station: Upon completion of storage in 'Transfer destination' (D0 to D3), turn on B0 of the receiving station for a handshake.
- ⑦ Sending station: When B1000 of the sending station turns on, turn off B0 of the sending station.
- ⑧ Receiving station: When B1000 of the receiving station turns off, turn off B0 of the receiving station.

■ Example of interlock using RWr and RWw

An example of sending data in W0 to W3 of the master station (station No. 0) to W1000 to W1003 of the device station (station No. 1) is shown below. This is a method used when RX and RY cannot be used as interlock devices. (B0 and B1000 are used for a handshake to the CPU module.)




• Data flow




• Program

Sending station: Master station (station No. 0)



Receiving station: Device station (station No. 1)




• Program flow

- ① Sending station: 'Start direction' (M0) is turned on.
- ② Sending station: The contents of 'Transfer source' (D0 to D3) are stored in W0 to W3.
- ③ Sending station: Upon completion of storage in W0 to W3, turn on B0 of the sending station for a handshake.
- ④ Receiving station: Cyclic transmission sends RWw0 to RWw3EF followed by RWw3F0, RWw0 to RWw3EF is stored firstly and RWw3F0 is stored secondly in the receiving station, and B1000 of the receiving station turns on.
- ⑤ Receiving station: The contents of W1000 to W1003 are stored in 'Transfer destination' (D0 to D3).
- ⑥ Receiving station: Upon completion of storage in 'Transfer destination' (D0 to D3), turn on B0 of the receiving station for a handshake.
- ⑦ Sending station: When B1000 of the sending station turns on, turn off B0 of the sending station.
- ⑧ Receiving station: When B1000 of the receiving station turns off, turn off B0 of the receiving station.

Input and output status settings when failure occurs

For the FX5-CCLIEF, status of input from the master station when a data link error occurs and output status of cyclic data if a stop error occurs in the FX5 CPU module can be set.

| Status | Description |
|--|---|
| Input status for data link error | Whether input data from the master station when a data link error occurs is cleared or held can be selected. The RWw data are held regardless of the setting. |
| Cyclic data output status when a stop error occurs in the CPU module | When a stop error occurs in the FX5 CPU module, whether the RX of the FX5-CCLIEF is held or cleared can be selected. The RWr data are held regardless of the setting. |



Setting method

■ Input status of data link faulty station

Set the input status of data link faulty stations under "Supplementary Cyclic Settings" in "Application Settings". (Page 42 Supplementary Cyclic Settings)

■Cyclic data output when a stop error occurs in the FX5 CPU module

Under "Supplementary Cyclic Settings" in "Application Settings", set the cyclic data output status for when a stop error occurs in the FX5 CPU module. ( Page 42 Supplementary Cyclic Settings)

Precautions

■When data link is stopped by user

When cyclic transmission is stopped using the link special relay (SB), the input status of the faulty station is held. ( Page 137 List of Link Special Relay (SB))

■Setting on a station with a data link error

When the following settings are set to "Hold" on the station where a data link error has occurred, the input status of the own station upon error is held, regardless of setting.

- "Output Hold/Clear Setting during CPU STOP" under "I/O Maintenance Settings" under "Supplementary Cyclic Settings" in "Application Settings"
- "Output Mode upon CPU Error" under "I/O Maintenance Settings" of "Supplementary Cyclic Settings" in "Application Settings"

Output status setting for CPU STOP

When the FX5 CPU module connected to the FX5-CCLIEF is set to STOP, whether cyclic data output is held or cleared can be selected.

Setting method

Under "Supplementary Cyclic Settings" in "Application Settings", set the output status for the case where the FX5 CPU module is set to STOP. ( Page 42 Supplementary Cyclic Settings)

Precautions

■When the setting is disabled

For RWr, the cyclic data output is held regardless of the device of the link refresh source, even if the output setting for CPU STOP is set to be cleared.

■When the output status setting for CPU STOP is set to clear

When the FX5 CPU module is in the STOP state, the forced output to other stations cannot be executed using the engineering tool.

Output status setting for CPU stop error

When a stop error occurs in the FX5 CPU module connected to the FX5-CCLIEF, whether cyclic data output is held or cleared can be selected.

Setting method

Under "Supplementary Cyclic Settings" in "Application Settings", set the output status for the case when a stop error occurs in the FX5 CPU module. ( Page 42 Supplementary Cyclic Settings)

Cyclic transmission stop and restart

This function stops the cyclic transmission during debugging and other operations. (Data reception from the master station and data sending from the own station are stopped.) Also, the stopped cyclic transmission can be restarted. Transient transmission does not stop.

Cyclic transmission is stopped and restarted using the link start/stop of the link special relay (SB). ( Page 137 List of Link Special Relay (SB))

4.3 Transient Transmission

This function allows communications with other stations when a request is made by a method such as a dedicated instruction or engineering tool. Communications with different networks is also possible.


Communications within the same network

This function performs transient transmission to other stations using dedicated instructions and the engineering tool. For details on dedicated instructions, refer to the following.

(👉 Page 46 DEDICATED INSTRUCTION)


Ex.

Accessing another station programmable controller using the dedicated instruction (GP.READ instruction)



Communications with different networks

This function performs transient transmission seamlessly to stations on different networks using dedicated instructions.



Communications can be made with stations up to eight networks apart (number of relay stations: 7).
 (☞ Page 46 Link dedicated instructions)

When the relay station of own network is a local station, communications can be made with stations up to seven networks apart (number of relay stations: 6).


Setting communication paths allows communication with the following networks.

- Ethernet*¹
- CC-Link IE Controller Network*¹
- MELSECNET/H*¹
- MELSECNET/10*¹

*1 The network cannot be relayed by the FX5.

4.4 Interrupt Request to CPU Module

This function checks interrupt conditions in every link scan and makes an interrupt request to the FX5 CPU module to start the interrupt program if the interrupt conditions are met.



Setting method

Set the interrupt request to the FX5 CPU module in "Interrupt Settings" under "Application Settings". (☞ Page 43 Interrupt Settings)

5 SYSTEM CONFIGURATION

This chapter describes the system configuration of CC-Link IE Field Network.


5.1 CC-Link IE Field Network Configuration



CC-Link IE Field Network is configured using Ethernet cables.

Network topology

Configure the network in star topology, line topology, or ring topology using Ethernet cables.

Star topology and line topology can be combined in a network. Ring topology cannot be combined with star or line topology.




| Item | Description |
|---------------|--|
| Star topology | The network is configured into a star shape using a switching hub and Ethernet cables. Device stations can be easily added to the network using this topology. ^{*1} When an error occurs in a device station, data link can be continued with the stations that are operating normally. |
| Line topology | The network is configured into a line using Ethernet cables. A switching hub is not required. ^{*1} When an error occurs in a device station, the stations connected after the faulty station will be disconnected.  (1) Master station (station No. 0) |
| Ring topology | The network is configured into a ring using Ethernet cables. A switching hub is not required. ^{*1} When an error occurs in a device station, data link can be continued with the stations that are operating normally.  (1) Master station (station No. 0) |

*1 Add/remove device stations one by one. If multiple device stations are added/removed at a time, all stations on the network will be reconnected, and an error may momentarily occur in all the stations.

Station number and connection position


Modules can be connected in any order regardless of the station number.



- (1) Station No. 1
- (2) Station No. 0 (master station)
- (3) Station No. 3
- (4) Station No. 2

Cascade connection

Cascade connection is available up to 20 stages.



Precautions

■ Addition of device stations (including submaster station)

Do not connect 121 or more device stations (including submaster station). If a device station is added to a system having 120 device stations (including submaster station), all stations will fail and data link cannot be performed.

■ Configuration in which data link cannot be performed (illegal ring connection)

Do not use a switching hub for ring topology.

■ Ring topology

When using ring topology, set the network topology to "Ring" in the parameter settings for the master station.

For the setting method, refer to the manual for the master station module used.

■ Connecting/disconnecting a cable and powering off/on a device

When the operations listed below are performed, all stations on the network may be reconnected. At this time, a data link error may momentarily occur in all the stations and outputs of the connected device stations may turn off.

| Network configuration | Operation |
|------------------------------|---|
| Star topology | <ul style="list-style-type: none">• Powering off and on a device station or switching hub• Connecting/disconnecting an Ethernet cable connected to the switching hub• Disconnecting an Ethernet cable from a device station and connecting it to another device station or a switching hub• Disconnecting more than 9 stations, or half the number of device stations or more in the system• Changing the network topology when adding a device station |
| Line topology, ring topology | <ul style="list-style-type: none">• Simultaneously powering off/on multiple stations• Simultaneously connecting/disconnecting Ethernet cables to/from multiple stations (When a data link faulty station returns, a data link error will occur in all the stations.)• Disconnecting more than 9 stations, or half the number of device stations or more in the system• Changing the network topology when adding a device station |

To hold the outputs as a measure when a data link error occurs, set the following to "Hold".

Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Target module ⇒ [Module Parameter] ⇒ [Application Settings] ⇒ [Supplementary Cyclic Settings] ⇒ [I/O Maintenance Settings] ⇒ [Data Link Error Station Setting]

■ Connected station numbers

Do not duplicate station numbers. Data link may be stopped when the station number is duplicated.

5.2 Precautions for System Configuration

Connecting devices to the same network

For the device connection, observe the following. Failure to do so may cause the disconnection of all stations.


- Do not connect a non CC-Link IE Field Network device in CC-Link IE Field Network. If the device is connected, communications may not be normally performed.
- Do not connect a 100M/10M device or 1 Gbps device which does not support CC-Link IE Field Network to the switching hub (1 Gbps) used in CC-Link IE Field Network. If the device is connected, an error may be detected in the master station and data link may be stopped.

6 WIRING


This chapter describes the wiring methods, wiring products, and wiring precautions when the FX5-CCLIEF is used.

6.1 Power Supply Wiring

Wiring of power connector




Power supply wiring



Grounding

Perform the following.

- Perform class D grounding (Grounding resistance: 100 Ω or less).
- Ground the programmable controller independently when possible.
- If the programmable controller cannot be grounded independently, perform the "Shared grounding" shown below.



- Bring the grounding point close to the PLC as much as possible so that the ground cable can be shortened.

6.2 Wiring of CC-Link IE Field Network

This section describes the wiring when CC-Link IE Field Network is used.

Wiring methods

The following describes connection and disconnection of the Ethernet cable.

■Connecting the cable

1. Power off the FX5-CCLIEF and external device.
2. Push the Ethernet cable connector into the FX5-CCLIEF until it clicks. Pay attention to the connector's direction.
3. Lightly pull it to check that it is securely connected.
4. Power on the FX5-CCLIEF and external device.
5. Check whether the LINK LED of the port connected with an Ethernet cable is on.*1

*1 The time between the cable connection and the LINK LED turning on may vary. The LINK LED usually turns on in a few seconds. Note, however, that the time may be extended further if the link-up processing is repeated depending on the status of the device on the line. If the LINK LED does not turn on, refer to the following and take corrective actions.


(☞ Page 112 TROUBLESHOOTING)

Point


Both P1 connector and P2 connector can be used.

- When only one connector is used in star topology, either P1 connector or P2 connector is applicable.
- When two connectors are used in line topology and ring topology, the cable can be connected between P1 and P1, P2 and P2, or between P1 and P2.

Connection between P1s or P2s



Connection between P1 and P2



■Disconnecting the cable

1. Power off the FX5-CCLIEF.
2. Press the latch down and unplug the Ethernet cable.

■Precautions

- Place the Ethernet cable in a duct or clamp them. If not, dangling cable may swing or inadvertently be pulled, resulting in damage to the module or cables or malfunction due to poor contact.
- Do not touch the core of the cable-side or module-side connector, and protect it from dirt or dust. If oil from your hand, dirt or dust is attached to the core, it can increase transmission loss, causing a problem in data link.
- Check that the Ethernet cable is not disconnected or not shorted and there is no problem with the connector connection.
- Do not use Ethernet cables with broken latches. Doing so may cause the cable to unplug or malfunction.
- Hold the connector part when connecting and disconnecting the Ethernet cable. Pulling the cable connected to the module may result in malfunction or damage to the module or cable.
- For connectors without Ethernet cable, attached cap should be placed to prevent foreign matter such as dirt or dust.
- The maximum station-to-station distance of the Ethernet cable is 100 m. However, the length may be shorter depending on the operating environment of the cable. For details, contact your cable manufacturer.
- The bend radius of the Ethernet cable is limited. For details, check the specifications of the Ethernet cable to be used.

Wiring products

The following describes the devices used for CC-Link IE Field Network.

■Ethernet cable

Use Ethernet cable that meets the following standards.

| Ethernet cable | Connector | Type |
|---------------------------------------|----------------|--|
| Double shielded STP Straight cable | RJ45 connector | • IEEE802.3 (1000BASE-T) • ANSI/TIA/EIA-568-B (Category 5e) |

Cables for CC-Link IE Field Network are available from Mitsubishi Electric System & Service Co., Ltd. (Catalogs for cable are also available.)

In addition, the connector processing of your preferred cable length is available. Consult your local Mitsubishi Electric representative.

| Type | Model (Manufacturer) |
|---------------------------------------|---|
| Straight cable (double shielded, STP) | SC-E5EW series (Mitsubishi Electric System & Service Co., Ltd.) |

■Hub

Use hubs that meet all the conditions listed below. Operation is not guaranteed if the hubs do not meet these conditions.

- Compliance with the IEEE802.3 (1000BASE-T)
- Support of the auto MDI/MDI-X function
- Support of the auto-negotiation function
- Switching hub (layer 2 switch) ^{*1}

*1 A repeater hub is not available.

| Type | Model (Manufacturer) |
|--------------------------|--|
| Industrial switching hub | • NZ2EHG-T8N (Mitsubishi Electric Corporation) • NZ2EHG-T8 (Mitsubishi Electric Corporation) (discontinued) |

7 PARAMETER SETTINGS


This chapter describes the parameter settings required for communications between the FX5-CCLIEF and other stations.

7.1 Setting Parameters

1. Add the intelligent function module in the engineering tool.
 - Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Right-click ⇒ [Add New Module]
2. The required settings, basic settings, and application settings are included in the parameter settings. Select one of the settings from the tree on the window shown below.
 - [Navigation window] ⇒ [Parameter] ⇒ [Module Information] ⇒ Target module ⇒ [Module Parameter]
3. After setting parameters, click the [Apply] button.
4. Write the settings to the FX5 CPU module using the engineering tool.
 - [Online] ⇒ [Write to PLC]
5. The settings are reflected by resetting the FX5 CPU module or powering off and on the system.

7.2 Required Settings

Set the station type, network number, or other parameters for the FX5-CCLIEF.



| Item | Description | Reference |
|--------------------------|--|-----------|
| Station Type | Set the station type. (Fixed to "Intelligent Device Station") | — |
| Network Number | Set the network number of the FX5-CCLIEF. | Page 39 |
| Station Number | Set the station number setting method and station number of the FX5-CCLIEF. | Page 39 |
| Parameter Setting Method | Select whether to set "Basic Settings" and "Application Settings" items of the FX5-CCLIEF in parameter editor or in program. | Page 39 |

Point

When the parameters of required settings are not set, the module operates as an intelligent device station of network No. 1 and station No. 1.

Network Number

Set the network number of the FX5-CCLIEF.

| Item | Description | Setting range |
|----------------|---|--------------------------|
| Network Number | Set the network number of the FX5-CCLIEF. | 1 to 239 (Default: 1) |

Station Number

Set the station number of the FX5-CCLIEF.

| Item | Description | Setting range |
|----------------|---|---|
| Setting Method | Select whether to set the station number in parameter editor or in program (G(P).UINI instruction). When selecting "Program", use the G(P).UINI instruction to set the number. ( Page 102 G(P).UINI) | <ul style="list-style-type: none"> Parameter Editor Program (Default: Parameter Editor) |
| Station No. | Set the station number of the FX5-CCLIEF. Set a station number different from those used in the same network. To set the station number in this setting, set "Setting Method" to "Parameter Editor". | 1 to 120 (Default: 1) |

Parameter Setting Method

Select whether to set "Basic Settings" and "Application Settings" items of the FX5-CCLIEF in parameter editor or in program.

| Item | Description | Setting range |
|--|--|---|
| Setting Method of Basic/ Application Settings | <ul style="list-style-type: none"> Parameter Editor Select this item to set the parameter using the engineering tool. The following are advantages. <ul style="list-style-type: none"> Parameters can be easily set in the window without creating a program for setting. Parameters will be automatically transferred to the devices of the FX5 CPU module and the link special relay (SB), link special register (SW), and link devices of the FX5-CCLIEF. Program Select this item to set the parameter using the dedicated instruction (G(P).CCPASET instruction). The following are advantages. <ul style="list-style-type: none"> Parameters can be changed without resetting the FX5 CPU module. | <ul style="list-style-type: none"> Parameter Editor Program (Default: Parameter Editor) |

Station number setting

The station number can be also set using the G(P).UINI instruction. This allows project data items other than the station number to be the same. ( Page 102 G(P).UINI)

■When using the engineering tool for the parameter setting

The procedure for setting the station number of the intelligent device station is shown below.

1. Set "Setting Method" under "Station Number" in "Required Settings" to "Program".
2. Set "Setting Method of Basic/Application Settings" under "Parameter Setting Method" in "Required Settings" to "Parameter Editor".
3. Set the station number using the G(P).UINI instruction.


■When using the G(P).CCPASET instruction for the parameter setting

The procedure for setting the station number of the intelligent device station is shown below.

1. Set "Station Type" under "Station Type" in "Required Settings" and "Network Number" under "Network Number" in "Required Settings".
2. Set "Setting Method" under "Station Number" in "Required Settings" to "Program".
3. Set "Setting Method of Basic/Application Settings" under "Parameter Setting Method" in "Required Settings" to "Program".
4. Set the network parameters using the G(P).CCPASET instruction.
5. Set the station number using the G(P).UINI instruction.

7.3 Basic Settings

Set the refresh settings of the FX5-CCLIEF.



| Item | Description | Reference |
|-----------------|--|-----------|
| Refresh Setting | Set link refresh ranges between the devices of the FX5 CPU module and the link special relay (SB), link special register (SW), and link devices of the FX5-CCLIEF. | Page 40 |

Refresh setting

Set link refresh ranges between the devices of the FX5 CPU module and link devices of the FX5-CCLIEF.

Setting method

The procedure for the refresh settings is shown below.



1. Set the required items.
2. Click the [Apply] button and close "Refresh Setting".

Setting items

The setting items for refresh settings are as follows:

| No. | Link Side | | | | | CPU Side | | | | |
|-----|-------------|--------|-------|-------|---|----------|-------------|--------|-------|-------|
| | Device Name | Points | Start | End | | Target | Device Name | Points | Start | End |
| - | SB | 512 | 00000 | 001FF | ↔ | Device | SB | 512 | 00000 | 001FF |
| - | SW | 512 | 00000 | 001FF | ↔ | Device | SW | 512 | 00000 | 001FF |
| 1 | | | | | ↔ | | | | | |
| 2 | | | | | ↔ | | | | | |
| 3 | | | | | ↔ | | | | | |
| 4 | | | | | ↔ | | | | | |
| 5 | | | | | ↔ | | | | | |

| Item | Description | Setting range |
|--------------------------|---|--|
| Device Assignment Method | Right-click in the "Refresh Setting" window and select a link device assignment method. <ul style="list-style-type: none"> • Start/End: Enter the start and end numbers of link devices. • Points/Start: Enter the points and start numbers of link devices. | <ul style="list-style-type: none"> • Start/End • Points/Start (Default: Start/End) |

| Item | Description | Setting range | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|---|---------------|-------|-------|--------------|-------------|----------|-------|-------|--|--|-----|-------------|--------|-------|-----|--------|-------------|--------|-------|-----|---|----|-----|-------|-------|--------------|----|-----|-------|-------|---|----|-----|-------|-------|--------------|----|-----|-------|-------|--|----|-----|-------|-------|--------------|---|-----|------|------|---|----|-----|-------|-------|--------------|---|-----|------|------|---|----|-----|-------|-------|--------------|---|-----|-------|-------|---|-----|-----|-------|-------|--------------|---|-----|-------|-------|---|
| <p>—</p> <p>Link Side</p> <p>CPU Side</p> | <p>Set the link refresh ranges of SB and SW. One range can be set for each of SB and SW. (☞ Page 23 Link refresh)</p> <p>Ex.</p> <table border="1" data-bbox="336 293 959 376"> <thead> <tr> <th colspan="5">Link Side</th> <th colspan="5">CPU Side</th> </tr> <tr> <th>No.</th> <th>Device Name</th> <th>Points</th> <th>Start</th> <th>End</th> <th>Target</th> <th>Device Name</th> <th>Points</th> <th>Start</th> <th>End</th> </tr> </thead> <tbody> <tr> <td>—</td> <td>SB</td> <td>512</td> <td>00000</td> <td>001FF</td> <td>Device</td> <td>SB</td> <td>512</td> <td>00000</td> <td>001FF</td> </tr> <tr> <td>—</td> <td>SW</td> <td>512</td> <td>00000</td> <td>001FF</td> <td>Device</td> <td>SW</td> <td>512</td> <td>00000</td> <td>001FF</td> </tr> </tbody> </table>  <p>FX5-CCLIEF</p> <p>FX5 CPU module</p> | Link Side | | | | | CPU Side | | | | | No. | Device Name | Points | Start | End | Target | Device Name | Points | Start | End | — | SB | 512 | 00000 | 001FF | Device | SB | 512 | 00000 | 001FF | — | SW | 512 | 00000 | 001FF | Device | SW | 512 | 00000 | 001FF | <p>Device Name</p> <ul style="list-style-type: none"> • SB (fixed) • SW (fixed) <p>Points</p> <ul style="list-style-type: none"> • SB: 16 to 512 • SW: 1 to 512 <p>(Default: 512)</p> <p>Start</p> <ul style="list-style-type: none"> • SB: 0H to 1F0H (set in increments of 16 points) • SW: 0H to 1FFH (set in increments of 1 point) <p>(Default: 0H)</p> <p>End</p> <ul style="list-style-type: none"> • SB: FH to 1FFH (set in increments of 16 points) • SW: 0H to 1FFH (set in increments of 1 point) <p>(Default: 1FFH)</p> <p>Target</p> <ul style="list-style-type: none"> • Device <p>(Default: Device)</p> <p>Device Name</p> <ul style="list-style-type: none"> • Device (when link side is SB): SB, M, L, B, D, R • Device (when link side is SW): SW, M, L, B, D, R <p>Points, Start, End</p> <ul style="list-style-type: none"> • Range of the device in the FX5 CPU module • Set bit devices in increments of 16 points and word devices in increments of 1 points. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Link Side | | | | | CPU Side | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| No. | Device Name | Points | Start | End | Target | Device Name | Points | Start | End | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| — | SB | 512 | 00000 | 001FF | Device | SB | 512 | 00000 | 001FF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| — | SW | 512 | 00000 | 001FF | Device | SW | 512 | 00000 | 001FF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <p>1 to 256</p> <p>Link Side</p> <p>CPU Side</p> | <p>Set the link refresh ranges of RX, RY, RWr, and RWw. Up to 256 ranges can be set. (☞ Page 23 Link refresh)</p> <p>Ex.</p> <table border="1" data-bbox="336 976 959 1122"> <thead> <tr> <th colspan="5">Link Side</th> <th colspan="5">CPU Side</th> </tr> <tr> <th>No.</th> <th>Device Name</th> <th>Points</th> <th>Start</th> <th>End</th> <th>Target</th> <th>Device Name</th> <th>Points</th> <th>Start</th> <th>End</th> </tr> </thead> <tbody> <tr> <td>—</td> <td>SB</td> <td>512</td> <td>00000</td> <td>001FF</td> <td>Specify Devi</td> <td>SB</td> <td>512</td> <td>00000</td> <td>001FF</td> </tr> <tr> <td>—</td> <td>SW</td> <td>512</td> <td>00000</td> <td>001FF</td> <td>Specify Devi</td> <td>SW</td> <td>512</td> <td>00000</td> <td>001FF</td> </tr> <tr> <td>1</td> <td>RX</td> <td>256</td> <td>00000</td> <td>000FF</td> <td>Specify Devi</td> <td>X</td> <td>256</td> <td>1000</td> <td>1377</td> </tr> <tr> <td>2</td> <td>RY</td> <td>256</td> <td>00000</td> <td>000FF</td> <td>Specify Devi</td> <td>Y</td> <td>256</td> <td>1000</td> <td>1377</td> </tr> <tr> <td>3</td> <td>RW</td> <td>256</td> <td>00000</td> <td>000FF</td> <td>Specify Devi</td> <td>W</td> <td>256</td> <td>00000</td> <td>000FF</td> </tr> <tr> <td>4</td> <td>RWw</td> <td>256</td> <td>00000</td> <td>000FF</td> <td>Specify Devi</td> <td>W</td> <td>256</td> <td>01000</td> <td>010FF</td> </tr> </tbody> </table>  <p>FX5-CCLIEF</p> <p>FX5 CPU module</p> | Link Side | | | | | CPU Side | | | | | No. | Device Name | Points | Start | End | Target | Device Name | Points | Start | End | — | SB | 512 | 00000 | 001FF | Specify Devi | SB | 512 | 00000 | 001FF | — | SW | 512 | 00000 | 001FF | Specify Devi | SW | 512 | 00000 | 001FF | 1 | RX | 256 | 00000 | 000FF | Specify Devi | X | 256 | 1000 | 1377 | 2 | RY | 256 | 00000 | 000FF | Specify Devi | Y | 256 | 1000 | 1377 | 3 | RW | 256 | 00000 | 000FF | Specify Devi | W | 256 | 00000 | 000FF | 4 | RWw | 256 | 00000 | 000FF | Specify Devi | W | 256 | 01000 | 010FF | <p>Device Name</p> <ul style="list-style-type: none"> • RX, RY, RWr, RWw <p>(Default: Blank)</p> <p>Points</p> <ul style="list-style-type: none"> • RX, RY: 16 to 384 • RWr, RWw: 4 to 1024 <p>(Default: Blank)</p> <p>Start</p> <ul style="list-style-type: none"> • RX, RY: 0H to 170H (set in increments of 16 points) • RWr, RWw: 0 to 3FCH (set in increments of 4 points) <p>(Default: Blank)</p> <p>End</p> <ul style="list-style-type: none"> • RX, RY: FH to 17FH (set in increments of 16 points) • RWr, RWw: 3H to 3FFH (set in increments of 4 points) <p>(Default: Blank)</p> <p>Target</p> <ul style="list-style-type: none"> • Device <p>(Default: Blank)</p> <p>Device Name</p> <ul style="list-style-type: none"> • Device (when link side is RX): X, M, L, B, D, W, R • Device (when link side is RY): Y, M, L, B, D, W, R • Device (when link side is RWr): M, L, B, D, W, R • Device (when link side is RWw): M, L, B, D, W, R <p>(Default: Blank)</p> <p>Points, Start, End</p> <ul style="list-style-type: none"> • Range of the device in the FX5 CPU module • Set bit devices in increments of 16 points and word devices in increments of 4 points. <p>(Default: Blank)</p> |
| Link Side | | | | | CPU Side | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| No. | Device Name | Points | Start | End | Target | Device Name | Points | Start | End | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| — | SB | 512 | 00000 | 001FF | Specify Devi | SB | 512 | 00000 | 001FF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| — | SW | 512 | 00000 | 001FF | Specify Devi | SW | 512 | 00000 | 001FF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | RX | 256 | 00000 | 000FF | Specify Devi | X | 256 | 1000 | 1377 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | RY | 256 | 00000 | 000FF | Specify Devi | Y | 256 | 1000 | 1377 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | RW | 256 | 00000 | 000FF | Specify Devi | W | 256 | 00000 | 000FF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | RWw | 256 | 00000 | 000FF | Specify Devi | W | 256 | 01000 | 010FF | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

Precautions

■Device set to "CPU Side"

Set a device range not to overlap with the one used for the following:


- "Refresh Setting" of intelligent function modules

■Link refresh range

Set only link devices used in the FX5 CPU module for link refresh range. Doing so will reduce link refresh points, resulting in a shorter link refresh time.

7.4 Application Settings

Set the supplementary cyclic settings, interrupt settings, or other parameters for the FX5-CCLIEF.



| Item | Description | Reference |
|-------------------------------|--|-----------|
| Supplementary Cyclic Settings | Set the I/O maintenance settings. | Page 42 |
| Interrupt Settings | Set conditions for sending an interrupt request to the FX5 CPU module. | Page 43 |
| Parameter Name | Set a name for the module parameter if desired. | Page 45 |
| Module Operation Mode | Set the mode of the FX5-CCLIEF. | Page 45 |

Supplementary Cyclic Settings

Set the I/O maintenance settings.

| Item | Description | Setting range |
|--------------------------|---|--|
| I/O Maintenance Settings | Output Hold/Clear Setting during CPU STOP | Select whether cyclic data output is held or cleared when the FX5 CPU module connected to the FX5-CCLIEF is set to STOP state. (☞ Page 29 Output status setting for CPU STOP) |
| | Data Link Error Station Setting | Select whether input data from the master station when a data link error occurs is cleared or held. (☞ Page 28 Input and output status settings when failure occurs) |
| | Output Mode upon CPU Error | When a stop error occurs in the FX5 CPU module connected to the FX5-CCLIEF, whether cyclic transmission output data is held or cleared can be selected. (☞ Page 28 Input and output status settings when failure occurs) |
| | | <ul style="list-style-type: none"> • Hold • Clear (Default: Hold) |
| | | <ul style="list-style-type: none"> • Clear • Hold (Default: Clear) |
| | | <ul style="list-style-type: none"> • Clear • Hold (Default: Clear) |

Interrupt Settings

Set conditions for sending an interrupt request to the FX5 CPU module.

Setting method

The procedure for the interrupt settings is shown below.

1. Set the interrupt conditions.

Up to 16 interrupt conditions can be set.

| No. | Device Code | Device No. | Detection Method | Condition Type | Condition Value | Interrupt Pointer | Comment |
|-------|-------------|------------|------------------|----------------|-----------------|-------------------|---------|
| SI 00 | | | | | | | |
| SI 01 | | | | | | | |
| SI 02 | | | | | | | |
| SI 03 | | | | | | | |
| SI 04 | | | | | | | |
| SI 05 | | | | | | | |
| SI 06 | | | | | | | |
| SI 07 | | | | | | | |
| SI 08 | | | | | | | |
| SI 09 | | | | | | | |
| SI 10 | | | | | | | |
| SI 11 | | | | | | | |
| SI 12 | | | | | | | |
| SI 13 | | | | | | | |
| SI 14 | | | | | | | |
| SI 15 | | | | | | | |

2. Click the [Apply] button and close "Interrupt Settings".

Setting items

| Item | Description | Setting range |
|--|---|---|
| Word Device Setting Value Input Format | Right click in the "Interrupt Settings" window and select from "Word Device Setting Value Input Format". | <ul style="list-style-type: none"> Decimal Hexadecimal (Default: Decimal) |
| Device Code | Set an interrupt condition device. | Refer to the following table. |
| Device No. | | |
| Detection Method | Select the detection timing of an interrupt generated by the device set in "Device" and "Device No.". | |
| Condition Type | | |
| Condition Value | When "RWw", "RWr", or "SW" is selected in "Device", enter a word device value that triggers an interrupt. | |
| Interrupt Pointer | Set an interrupt pointer (I) to be used for a interrupt program. | |
| Comment | Set a comment for the interrupt pointer used. | — |

(Setting range)

| Device | Device No. | Detection Method | Condition Type | Condition Value | Interrupt Pointer |
|--------|------------|--|--------------------------|-----------------|---------------------|
| RX | 0H to 17FH | Level + ON: Interrupt occurs by turning on the device. Level + OFF: Interrupt occurs by turning off the device. Edge + ON: Interrupt occurs at the rising edge of the device. Edge + OFF: Interrupt occurs at the falling edge of the device. | | — | Device: I50 to I177 |
| RY | 0H to 17FH | | | | |
| SB | 0H to 1FFH | | | | |
| RWr | 0H to 3FFH | Level + Values Match: Interrupt occurs when values match. Level + Values Mismatch: Interrupt occurs when values do not match. Edge + Values Match: Interrupt occurs when values match (first time only). Edge + Values Mismatch: Interrupt occurs when values do not match (first time only). | 0 to 65535 (0H to FFFFH) | | |
| RWw | 0H to 3FFH | | | | |
| SW | 0H to 1FFH | | | | |
| | | | | | |

Point

Using an interrupt program will eliminate the need for describing a start condition in a program. This leads to reduction in the number of steps and sequence scan time.

Precautions

■When "Detection Method" is set to "Level" and the interrupt condition is always met

If the sequence scan takes much longer than the link scan, since interrupt processing is activated in each link scan, sequence scan time may greatly increase, resulting in a watchdog timer error of the FX5 CPU module.

When "Detection Method" is set to "Level" and the interrupt condition is always met, do not use interrupt settings and correct the interrupt condition in the program.

■When multiple interrupts have simultaneously occurred

The operation may be delayed.

■When the mode of the FX5-CCLIEF is "Module Communication Test" or "Offline"

The master/local module can send an interrupt request to the FX5 CPU module when the mode is "Online". The module cannot send the request when the mode is "Module Communication Test" and "Offline".

■An interrupt cannot be generated

Changes in the interrupt condition device cannot be detected if the change is shorter than the transmission delay time.

■When the link refresh setting is performed


Even if the link refresh setting is performed, the buffer memory needs to be referred in the interrupt program because link refresh is not performed to FX5 CPU module devices at the execution timing of an interrupt program.

Setting examples

■Starting the interrupt program of the device station (station No. 1) when RY100 turns on

Ex.

The following is a setting example to execute the interrupt program corresponding to the interrupt pointer I50 when RY100 turns on by turning on the corresponding switch on the master station side.



Set the interrupt setting parameters for the FX5-CCLIEF (station No. 1) in "Interrupt Settings" as shown below.

| No. | Device Code | Device No. | Detection Method | Condition Type | Condition Value | Interrupt Pointer | Comment |
|-------|-------------|------------|------------------|----------------|-----------------|-------------------|---------|
| SI 00 | RY | 00100 | Edge | ON | | I50 | |
| SI 01 | | | | | | | |
| SI 02 | | | | | | | |

Point

By using link special relay (SB) and link special register (SW) as an interrupt condition device, an interrupt program can be started in case of data link error. (Page 137 List of Link Special Relay (SB), Page 141 List of Link Special Register (SW))

Parameter Name

Set a name for the module parameter if desired.

| Item | Description | Setting range |
|----------------|---|---|
| Parameter Name | Set a name for the module parameter if desired. | Up to 8 one-byte or two-byte characters (Default: Blank) |

Module Operation Mode

Set the mode of the FX5-CCLIEF.

For details on module communication test mode, refer to the following.

( Page 115 Module communication test)

| Item | Description | Setting range |
|-----------------------|--|--|
| Module Operation Mode | <p>Online</p> <ul style="list-style-type: none">• Select this mode to connect the FX5-CCLIEF to the network for performing data link with other stations. <p>Offline</p> <ul style="list-style-type: none">• Select this mode to disconnect the FX5-CCLIEF from the network for stopping data link with other stations. <p>Module Communication Test</p> <ul style="list-style-type: none">• Select this mode to check the hardware of the FX5-CCLIEF. Select this mode to check the module hardware when communication is unstable. | <ul style="list-style-type: none">• Online• Offline• Module Communication Test (Default: Online) |

Restriction

The following functions are disabled when "Module Operation Mode" is set to "Offline" or "Module Communication Test". ( Page 20 FUNCTIONS)

- Cyclic transmission
- Transient transmission
- RAS (Automatic return)
- Interrupt request to CPU module

8 DEDICATED INSTRUCTION

This chapter describes dedicated instructions that can be used in the FX5-CCLIEF.

Link dedicated instructions

The following table lists the instructions used for transient transmission to or from programmable controllers on other stations. Each link dedicated instruction allows access to a station on a network other than CC-Link IE Field Network.

■Instruction list

| Instruction | Description | Reference |
|-------------|--|-------------------|
| GP.READ | Reads data from a device in another station programmable controller. | Page 49 GP.READ |
| GP.SREAD | Reads data from a device in another station programmable controller. After the data reading is completed by the GP.SREAD instruction, a device of the other station is turned on. The other station can recognize that data has been read by the GP.SREAD instruction. | Page 57 GP.SREAD |
| GP.WRITE | Writes data to a device in another station programmable controller. | Page 63 GP.WRITE |
| GP.SWRITE | Writes data to a device in another station programmable controller. After the data writing is completed by the GP.SWRITE instruction, a device of the other station is turned on. The other station can recognize that data has been written by the GP.SWRITE instruction. | Page 72 GP.SWRITE |
| GP.SEND | Sends data to another station programmable controller. | Page 79 GP.SEND |
| GP.RECV | Reads data received from another station programmable controller. | Page 90 GP.RECV |

■Transient transmission range

In a single network system, communication with all stations on the network is possible.

In multi-network system, communications can be made with stations up to eight networks apart.

■Target networks and target station types

Each link dedicated instruction allows access to a station on a network other than the own station network.

The following table lists the target stations of each instruction.

| Instruction symbol | Target station (another station) | |
|-----------------------|--|--|
| | Target network | Target station type |
| GP.READ GP.SREAD | <ul style="list-style-type: none"> • Ethernet • CC-Link IE Controller Network • CC-Link IE Field Network • MELSECNET/H • MELSECNET/10 | <ul style="list-style-type: none"> • QCPU • LCPU • QSCPU • QnACPU • FX5CPU • Intelligent device station |
| GP.WRITE GP.SWRITE | <ul style="list-style-type: none"> • Ethernet • CC-Link IE Controller Network • CC-Link IE Field Network • MELSECNET/H • MELSECNET/10 | <ul style="list-style-type: none"> • QCPU • LCPU • QnACPU • FX5CPU • Intelligent device station |
| GP.SEND GP.RECV | <ul style="list-style-type: none"> • Ethernet • CC-Link IE Controller Network • CC-Link IE Field Network • MELSECNET/H • MELSECNET/10 | <ul style="list-style-type: none"> • QCPU • LCPU • QnACPU • FX5CPU • Interface board for personal computer*¹ |

*1 These instructions can access the following personal computer interface boards having the SEND/RECV functions.
CC-Link IE Field Network interface board, CC-Link IE Controller Network interface board, MELSECNET/H interface board, and MELSECNET/10 interface board

■ Specifications of character string data specified by link dedicated instructions

Some operands specified in link dedicated instructions are specified in character strings. The following table summarizes the specifications of character string data specified.

| Instruction symbol | Applicable operand | Specifications of character string data |
|--------------------|--------------------|--|
| GP.READ | (s2) | <ul style="list-style-type: none"> ■ Specification method |
| GP.SREAD | (s2) | Specify a character string by enclosing it in single quotes ('). |
| GP.WRITE | (d1) | <ul style="list-style-type: none"> ■ Specifiable device types • Word device: D, W, SW, SD, T, C, ST, ZR, R • Nibble-specified bit device: X, Y, M, L, B, F, SB, SM |
| GP.SWRITE | (d1) | <ul style="list-style-type: none"> ■ ASCII string specifications • An ASCII string can consist of a maximum of 32 characters. (Specify NULL as the termination character.) • ASCII strings are zero-suppressed. (Example: D1 and D001 are handled the same.) • ASCII strings are case-sensitive. ■ Precautions Nibble-specified bit devices can be specified only when the following conditions are all satisfied. <ul style="list-style-type: none"> • The device number is a multiple of 16 (10H). • The number of specified nibbles is 4 (K4). An instruction specifying bit devices by nibble can be executed only when the target station is FX5CPU, RCP, basic model QCPU, universal model QCPU, or LCP. If an instruction uses nibble specification for other types of CPU modules, an abnormal response is returned from the target station and the instruction is completed with an error. (The network module does not detect an error during execution of the instruction.) The target device of an instruction executed in index modification mode is determined by the value of the index register of the own station. When specifying X and Y devices, specify the device number in hexadecimal. |
| GP.SREAD | (d3) | <ul style="list-style-type: none"> ■ Specification method |
| GP.SWRITE | (d3) | Specify a character string by enclosing it in single quotes ('). |
| | | <ul style="list-style-type: none"> ■ Specifiable device types • Bit specification of word device: D, W, SW, SD, ZR, R • Bit device: X, Y, M, L, B, F, SB, SM • Bit device index modification: Z ■ ASCII string specifications • An ASCII string can consist of a maximum of 32 characters. (Specify NULL as the termination character.) • ASCII strings are zero-suppressed. (Example: D1 and D001 are handled the same.) • ASCII strings are case-sensitive. ■ Precautions The target device of an instruction executed in index modification mode is determined by the value of the index register of the own station. When specifying X and Y devices, specify the device number in hexadecimal. |

Other dedicated instructions

Set the parameters to the intelligent device station (own station).

■ Instruction list

| Instruction | Description | Reference |
|--------------|---|----------------------|
| G(P).CCPASET | Set the parameters to the FX5-CCLIEF. | Page 96 G(P).CCPASET |
| G(P).UINI | Set the station number to the FX5-CCLIEF. | Page 102 G(P).UINI |

8.1 Precautions for Dedicated Instructions

This section describes precautions when using dedicated instructions.

Precautions for dedicated instructions (common)

■When changing data specified by dedicated instructions

Do not change any data (such as control data) until execution of the dedicated instruction is completed.

■When the dedicated instruction is not completed

Check whether the mode of the FX5-CCLIEF is online.

A dedicated instruction cannot be executed when the mode is offline or module communication test.

Precautions for link dedicated instructions

The following describes precautions when executing multiple link dedicated instructions simultaneously.

■Channel of the link dedicated instructions

When executing multiple link dedicated instructions simultaneously, check that the channels for the instructions are not duplicated. Multiple link dedicated instructions specifying the same channel cannot be used concurrently. To use the same channel for multiple link dedicated instructions, configure an interlock so that one instruction is executed after completion of another.

■If the link dedicated instruction is simultaneously executed


If executed, the instruction that is requested later is skipped. If skipped, the dedicated instruction skip flag (SM699) turns on.

8.2 Link Dedicated Instructions


Reading data from the programmable controller on another station

GP.READ

This instruction reads data from a device in another station programmable controller. (In units of words)

| Ladder | ST |
|---|---|
|  | <pre>ENO:=GP_READ(EN,Un,s1,s2,d1,d2);</pre> |

FBD/LD



("GP_READ" enters □.)

Setting data

■Description, range, data type

| Operand | Description | Range | Data type | Data type (label) |
|-------------------|---|--|--------------------------------|--|
| (U) ^{*1} | Position number of the module connected | <ul style="list-style-type: none"> ■FX5UJ CPU module 1H to 8H ■FX5U/FX5UC CPU module 1H to 10H | 16-bit unsigned binary | ANY16 |
| (s1) | Own station head device where control data is stored | Refer to  Page 50 Control data. | Device name | ANY16 ^{*4} |
| (s2) | Target station head device where the data to be read is stored | — | Character string ^{*2} | ANYSTRING_SINGL E ^{*2} |
| (d1) | Own station head device for storing the read data ^{*3} | — | Device name | ANY16 ^{*4} |
| (d2) | Own station device to be turned on for one scan when the instruction completes. (d2)+1 also turns on when the instruction completes with an error. | — | Bit | ANYBIT_ARRAY (Number of elements: 2) |
| EN | Execution condition | — | Bit | BOOL |
| ENO | Execution result | — | Bit | BOOL |

*1 In the case of the ST language and the FBD/LD language, U displays as Un.

*2 For the specifications of the string data to be specified, refer to the following.
( Page 47 Specifications of character string data specified by link dedicated instructions)

*3 The continuous area specified by the read data length (s1)+9 is required.

*4 Digit specified bit type label cannot be used.

■Applicable devices

| Operand | Bit | Word | | | Double word | | Indirect specification | Constant | | | Others (U) |
|---------|-----------------------------|---------------------------|-------|---|-------------|----|------------------------|----------|---|----|------------|
| | X, Y, M, L, SM, F, B, SB, S | T, ST, C, D, W, SD, SW, R | U□\G□ | Z | LC | LZ | | K, H | E | \$ | |
| (U) | — | ○ | — | — | — | — | ○ | ○ | — | — | ○ |
| (s1) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (s2) | — | — | — | — | — | — | — | — | — | ○ | — |
| (d1) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (d2) | ○*1 | ○*2 | — | — | — | — | — | — | — | — | — |

*1 S cannot be used.

*2 T, ST, and C cannot be used.

■Control data

| Device | Item | Description | Setting range | Set by | | | |
|---------|-------------------------|---|--|-----------------|---|----------------|------|
| (s1)+0 | Error completion type | b15 ... b8 b7 b6 ... b0 <table border="1" style="margin-left: 40px;"> <tr> <td style="width: 40px;">0</td> <td style="width: 10px;">(1)</td> <td style="width: 40px;">0</td> </tr> </table> (1) Error completion type (bit 7) Specify whether to set data at completion with an error. • 0: Do not set data in (s1)+11 and later at completion with an error. • 1: Set data in (s1)+11 and later at completion with an error. | 0 | (1) | 0 | 0000H 0080H | User |
| 0 | (1) | 0 | | | | | |
| (s1)+1 | Completion status | The instruction completion status is stored. • 0: Normal • Other than 0: Error (error code) | — | System | | | |
| (s1)+2 | Own station channel | Specify the channel to be used by own station. | 1, 2 | User | | | |
| (s1)+3 | Target station CPU type | Specify the CPU type of the target station. • 0000H: Addressed to target station CPU (control CPU) • 03D0H: Addressed to control system CPU • 03D1H: Addressed to standby system CPU • 03D2H: Addressed to system A CPU • 03D3H: Addressed to system B CPU • 03E0H: Addressed to multiple CPU No. 1 • 03E1H: Addressed to multiple CPU No. 2 • 03E2H: Addressed to multiple CPU No. 3 • 03E3H: Addressed to multiple CPU No. 4 • 03FFH: Addressed to target station CPU (control CPU) | 0000H 03D0H to 03D3H 03E0H to 03E3H 03FFH | User | | | |
| (s1)+4 | Target network number | Specify the network number (1 to 239) of the target station. | 1 to 239 | User | | | |
| (s1)+5 | Target station number | Specify the station number of the target station. • 125: Master station • 126: Master operating station • 1 to 120: Local station, intelligent device station, submaster station | 1 to 120, 125, 126 | User | | | |
| (s1)+6 | Not used | — | — | — | | | |
| (s1)+7 | Number of resends | ■Before instruction execution Specify the number of resends to be performed if the instruction is not completed within the monitoring time specified by (s1)+8. ■At completion of instruction The number of resends performed (result) is stored. | 0 to 15 | User/ system | | | |
| (s1)+8 | Arrival monitoring time | Specify the monitoring time until completion of processing. If processing is not completed within the monitoring time, the request is resent by the number of resends specified in (s1)+7. • 0: 10 seconds • 1 to 32767: 1 to 32767 seconds | 0 to 32767 | User | | | |
| (s1)+9 | Read data length | Specify the number of words to be read. • 1 to 960 (words) (When reading data from QnACPU: 1 to 480 (words)) | 1 to 960 | User | | | |
| (s1)+10 | Not used | — | — | — | | | |
| (s1)+11 | Clock setting flag | The validity status (valid or invalid) of the data in (s1)+12 and later is stored. Note that the data in (s1)+12 and later is not cleared even when the instruction is completed successfully. • 0: Invalid • 1: Valid | — | System | | | |

| Device | Item | Description | Setting range | Set by |
|---------|---|--|---------------|--------|
| (s1)+12 | Clock data (Set only in an abnormal state) | Upper 8 bits: Month (01H to 12H) Lower 8 bits: Lower 2 digits of year (00H to 99H) | — | System |
| (s1)+13 | | Upper 8 bits: Hour (00H to 23H) Lower 8 bits: Day (01H to 31H) | — | System |
| (s1)+14 | | Upper 8 bits: Second (00H to 59H) Lower 8 bits: Minute (00H to 59H) | — | System |
| (s1)+15 | | Upper 8 bits: Upper 2 digits of the year (00H to 99H) Lower 8 bits: Day of the week (00H (Sun.) to 06H (Sat.)) | — | System |
| (s1)+16 | Error detection network number*1 | The network number of the station in which an error was detected is stored. (No information is stored if an error is detected in the own station.) • 1 to 239 (Network number) | — | System |
| (s1)+17 | Error-detected station number*1 | The station number of the station where an error was detected is stored. (No information is stored if an error is detected in the own station.) • 125: Master station • 1 to 120: Local station, intelligent device station, submaster station | — | System |

*1 If completion status ((s1)+1) is "Channel in use (dedicated instruction) (error codes: D25AH and D25BH)", data is not stored.


Point

The number of resends (s1)+7 must be set every time the instruction is executed.

Processing details

- The instruction reads data by the specified number of words ((s1)+9) from the target station head device (s2) into the own station head device (after (d1)). Specify the target stations in control data ((s1)+4) and ((s1)+5). Upon completion of reading the device data specified by (s2), the completion device specified by (d2) turns on.
- For the target stations that can be specified, refer to the following.

Page 46 Target networks and target station types




- When executing multiple link dedicated instructions concurrently, be careful not to overlap the channels of the link dedicated instructions. Multiple link dedicated instructions specifying the same channel cannot be used concurrently.
- The execution of the GP.READ instruction and whether it has been completed normally or completed with an error can be checked with the completion device (d2) or completion status indication device (d2)+1.


| Device | Operation |
|--|--|
| Completion device (d2) | The device turns on during the END processing for the scan in which the GP.READ instruction is completed, and turns off during the next END processing. |
| Completion status indication device (d2)+1 | The device turns on or off depending on the completion status of the GP.READ instruction. When completed normally: The device does not change (remains off). When completed with an error: The device turns on during the END processing for the scan in which the GP.READ instruction is completed, and turns off during the next END processing. |

• The following figure shows the execution timing of the GP.READ instruction.

■ When completed normally



■ When completed with an error




Operation error

| Error code ((s1)+1) | Description |
|---------------------|---|
| D000H to DFFFH | Refer to Page 122 List of Error Codes. |

Program example

The following program is for reading data of D250 to D254 of station No. 4 (target station) into D700 to D704 of station No. 1 (own station) when M102 is turned on.

- System configuration



- Devices used


| Device | Description |
|--------------|---|
| SB0047 | Baton pass status of own station |
| M100 | Control data set command |
| M102 | Start contact |
| M105 | Completion device |
| M106 | Completion status indication device |
| D200 to D217 | Control data of the GP.READ instruction (For the set value, refer to the following figure.) |
| D700 to D704 | Read data storage device (station No. 1) |

- Control data

| Device | Item | Set value |
|--------------------|--------------|---|
| (s1)+0 | D200 | Error completion type 0080H Set data for error completion. |
| (s1)+1 | D201 | Completion status Setting not required |
| (s1)+2 | D202 | Own station channel 1 |
| (s1)+3 | D203 | Target station CPU type 0000H Addressed to target station CPU (control CPU) |
| (s1)+4 | D204 | Target network number 1 |
| (s1)+5 | D205 | Target station number 4 |
| (s1)+6 | D206 | Not used — |
| (s1)+7 | D207 | Number of resends 5 times |
| (s1)+8 | D208 | Arrival monitoring time 0 (10 seconds) |
| (s1)+9 | D209 | Read data length 5 words |
| (s1)+10 | D210 | Not used — |
| (s1)+11 | D211 | Clock set flag Setting not required |
| (s1)+12 to (s1)+15 | D212 to D215 | Clock data (Set only in an abnormal state) |
| (s1)+16 | D216 | Error detection network number |
| (s1)+17 | D217 | Error-detected station number |

• Program

Write the following program to the FX5 CPU module of station No. 1.



■Program using module FB

Program as follows when using the module FB.

- Devices used

| Device | Description |
|---------------------------------|--|
| SB0047 | Baton pass status of own station |
| M100 | Setting command of module FB |
| M102 | Execution command of module FB |
| M104 to M106 | Bit-type input output label for module FB (Refer to the following table for the setting.) |
| D202, D204, D205, D209 and D218 | Word-type input output label for module FB (Refer to the following table for the setting.) |
| D700 to D704 | Read data storage device (station No. 1) |

- Module FB instance name

| Name of module FB | Instance name |
|------------------------|---------------|
| M+FX5CCLIEF_DeviceRead | DeviceRead |


- FX5-CCLIEF module label

| Module label name | Module No. |
|-------------------|------------|
| FX5CCLIEF_1 | No.1 |

- Label to be used

| Label name | Item | Setting value/setting device |
|---------------------|---|------------------------------|
| ■Input label | | |
| i_bEN | Execution command | — |
| i_stModule | Module label | FX5CCLIEF_1 |
| i_u2TargetAddress | First word: target station network number | 1 (D204) |
| | Second word: target station number | 4 (D205) |
| i_uDataLength | Read data length | 5 words (D209) |
| i_s32TargetDevice | Target station read device | D250 |
| i_uChannel | Own station channel | 1 (D202) |
| ■Output label | | |
| o_bENO | Execution status | M104 |
| o_bOK | Normal completion | M105 |
| o_bErr | Abnormal end | M106 |
| o_uErrId | Error code | D218 |
| o_uReadData | Read data storage device | D700 |
| ■Public label | | |
| pbi_uCPU_Type | Target station CPU type | 0000H |
| pbi_uTimeUnit | Arrival monitoring time unit | 0 (10 seconds) |
| pbi_uResendCountMax | Maximum number of resends | 5 times |

• Program




Add the processing program when completed successfully and completed with an error after the program above.

Reading data from the programmable controller on another station (with notification)


GP.SREAD

This instruction reads data from a device in another station programmable controller. (In units of words)

After the data reading is completed by the GP.SREAD instruction, the device of the other station is turned on. The other station can recognize that data has been read by the GP.SREAD instruction.

| Ladder | ST |
|---|---|
|  | <pre>ENO:=GP_SREAD(EN,Un,s1,s2,d1,d2,d3);</pre> |

FBD/LD



("GP_SREAD" enters □.)

Setting data

■Description, range, data type

| Operand | Description | Range | Data type | Data type (label) |
|-------------------|--|--|--------------------------------|---|
| (U) ^{*1} | Position number of the module connected | <ul style="list-style-type: none"> ■FX5UJ CPU module 1H to 8H ■FX5U/FX5UC CPU module 1H to 10H | 16-bit unsigned binary | ANY16 |
| (s1) | Own station head device where control data is stored | Refer to  Page 58 Control data. | Device name | ANY16 ^{*4} |
| (s2) | Target station head device where the data to be read is stored | — | Character string ^{*2} | ANYSTRING_SINGLE ^{*2} |
| (d1) | Own station head device for storing the read data ^{*3} | — | Device name | ANY16 ^{*4} |
| (d2) | Own station device to be turned on for one scan when the instruction completes. (d2)+1 also turns on when the instruction completes with an error. | — | Bit | ANYBIT_ARRAY (Number of elements: 2) |
| (d3) | Target station device to be turned on for one scan when the instruction completes (The target station can recognize that data has been read from another station.) | — | Character string ^{*2} | ANYSTRING_SINGLE ^{*2} |
| EN | Execution condition | — | Bit | BOOL |
| ENO | Execution result | — | Bit | BOOL |

*1 In the case of the ST language and the FBD/LD language, U displays as Un.

*2 For the specifications of the string data to be specified, refer to the following.
( Page 47 Specifications of character string data specified by link dedicated instructions)

*3 The continuous area specified by the read data length (s1)+9 is required.

*4 Digit specified bit type label cannot be used.

■Applicable devices

| Operand | Bit | Word | | | Double word | | Indirect specification | Constant | | | Others (U) |
|---------|-----------------------------|---------------------------|-------|---|-------------|----|------------------------|----------|---|----|------------|
| | X, Y, M, L, SM, F, B, SB, S | T, ST, C, D, W, SD, SW, R | U□\G□ | Z | LC | LZ | | K, H | E | \$ | |
| (U) | — | ○ | — | — | — | — | ○ | ○ | — | — | ○ |
| (s1) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (s2) | — | — | — | — | — | — | — | — | — | ○ | — |
| (d1) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (d2) | ○*1 | ○*2 | — | — | — | — | — | — | — | — | — |
| (d3) | — | — | — | — | — | — | — | — | — | ○ | — |

*1 S cannot be used.

*2 T, ST, and C cannot be used.

■Control data

| Device | Item | Description | Setting range | Set by |
|---------|-------------------------|---|--|-----------------|
| (s1)+0 | Error completion type | b15 ... b8 b7 b6 ... b0 <div style="border: 1px solid black; padding: 2px; display: inline-block;"> 0 (1) 0 </div> <p>(1) Error completion type (bit 7) Specify whether to set data at completion with an error.</p> <ul style="list-style-type: none"> • 0: Do not set data in (s1)+11 and later at completion with an error. • 1: Set data in (s1)+11 and later at completion with an error. | 0000H 0080H | User |
| (s1)+1 | Completion status | The instruction completion status is stored. • 0: Normal • Other than 0: Error (error code) | — | System |
| (s1)+2 | Own station channel | Specify the channel to be used by own station. | 1, 2 | User |
| (s1)+3 | Target station CPU type | Specify the CPU type of the target station. • 0000H: Addressed to target station CPU (control CPU) • 03D0H: Addressed to control system CPU • 03D1H: Addressed to standby system CPU • 03D2H: Addressed to system A CPU • 03D3H: Addressed to system B CPU • 03E0H: Addressed to multiple CPU No. 1 • 03E1H: Addressed to multiple CPU No. 2 • 03E2H: Addressed to multiple CPU No. 3 • 03E3H: Addressed to multiple CPU No. 4 • 03FFH: Addressed to target station CPU (control CPU) | 0000H 03D0H to 03D3H 03E0H to 03E3H 03FFH | User |
| (s1)+4 | Target network number | Specify the network number (1 to 239) of the target station. | 1 to 239 | User |
| (s1)+5 | Target station number | Specify the station number of the target station. • 125: Master station • 126: Master operating station • 1 to 120: Local station, intelligent device station, submaster station | 1 to 120, 125, 126 | User |
| (s1)+6 | Not used | — | — | — |
| (s1)+7 | Number of resends | ■Before instruction execution Specify the number of resends to be performed if the instruction is not completed within the monitoring time specified by (s1)+8. ■At completion of instruction The number of resends performed (result) is stored. | 0 to 15 | User/ system |
| (s1)+8 | Arrival monitoring time | Specify the monitoring time until completion of processing. If processing is not completed within the monitoring time, the request is resent by the number of resends specified in (s1)+7. • 0: 10 seconds • 1 to 32767: 1 to 32767 seconds | 0 to 32767 | User |
| (s1)+9 | Read data length | Specify the number of words to be read. • 1 to 960 (words) (When reading data from QnACPU: 1 to 480 (words)) | 1 to 960 | User |
| (s1)+10 | Not used | — | — | — |

| Device | Item | Description | Setting range | Set by |
|---------|---|--|--|--------|
| (s1)+11 | Clock setting flag | The validity status (valid or invalid) of the data in (s1)+12 and later is stored. Note that the data in (s1)+12 and later is not cleared even when the instruction is completed successfully. • 0: Invalid • 1: Valid | — | System |
| (s1)+12 | Clock data (Set only in an abnormal state) | Upper 8 bits: Month (01H to 12H) Lower 8 bits: Lower 2 digits of year (00H to 99H) | — | System |
| (s1)+13 | | Upper 8 bits: Hour (00H to 23H) Lower 8 bits: Day (01H to 31H) | — | System |
| (s1)+14 | | Upper 8 bits: Second (00H to 59H) Lower 8 bits: Minute (00H to 59H) | — | System |
| (s1)+15 | | Upper 8 bits: Upper 2 digits of the year (00H to 99H) Lower 8 bits: Day of the week (00H (Sun.) to 06H (Sat.)) | — | System |
| (s1)+16 | | Error detection network number ^{*1} | The network number of the station in which an error was detected is stored. • 1 to 239 (Network number) | — |
| (s1)+17 | Error-detected station number ^{*1} | The station number of the station where an error was detected is stored. (No information is stored if an error is detected in the own station.) • 125: Master station • 1 to 120: Local station, intelligent device station, submaster station | — | System |

*1 If completion status ((s1)+1) is "Channel in use (dedicated instruction) (error codes: D25AH and D25BH)", data is not stored.


Point

The number of resends (s1)+7 must be set every time the instruction is executed.

Processing details

- The instruction reads data by the specified number of words ((s1)+9) from the target station head device (s2) into the own station word device (after (d1)). Specify the target stations in control data ((s1)+4) and ((s1)+5). Upon completion of reading the device data specified by (s2), the completion device specified by (d2) turns on. Upon completion of reading the device data specified by (s2), the completion device specified by (d2) turns on. In target station, upon completion of sending the device data specified by (s2), the device specified by (d3) turns on.
- For the target stations that can be specified, refer to the following.

☞ Page 46 Target networks and target station types




- When executing multiple link dedicated instructions concurrently, be careful not to overlap the channels of the link dedicated instructions. Multiple link dedicated instructions specifying the same channel cannot be used concurrently.
- The execution of the GP.SREAD instruction and whether it has been completed normally or completed with an error can be checked with the completion device (d2) or completion status indication device (d2)+1.


| Device | Operation |
|--|--|
| Completion device (d2) | The device turns on during the END processing for the scan in which the GP.SREAD instruction is completed, and turns off during the next END processing. |
| Completion status indication device (d2)+1 | The device turns on or off depending on the completion status of the GP.SREAD instruction. When completed normally: The device does not change (remains off). When completed with an error: The device turns on during the END processing for the scan in which the GP.SREAD instruction is completed, and turns off during the next END processing. |

• The following figure shows the execution timing of the GP.SREAD instruction.

■ When completed normally



■ When completed with an error




Operation error

| Error code ((s1)+1) | Description |
|---------------------|---|
| D000H to DFFFH | Refer to Page 122 List of Error Codes. |

Program example

The following program is for reading data of D250 to D254 of station No. 4 (target station) into D700 to D704 of station No. 1 (own station) when M102 is turned on and for turning on Y60 of the target station when the read notification device (d3) is turned on in the target station.

- System configuration



- Devices used


| Device | Description |
|--|--|
| ■Device used in the own station (station No. 1) | |
| SB0047 | Baton pass status of own station |
| M100 | Control data set command |
| M102 | Start contact |
| M105 | Completion device |
| M106 | Completion status indication device |
| D200 to D217 | Control data of the GP.SREAD instruction (For the set value, refer to the following figure.) |
| D700 to D704 | Read data storage device (station No. 1) |
| ■Device used in the target station (station No. 4) | |
| M107 | Read notification device used in the target station (station No. 4) |
| Y60 | Read completion device used in the target station (station No. 4) |

- Control data

| Device | Item | Set value |
|--------------------|--------------|---|
| (s1)+0 | D200 | Error completion type 0080H Set data for error completion. |
| (s1)+1 | D201 | Completion status Setting not required |
| (s1)+2 | D202 | Own station channel 1 |
| (s1)+3 | D203 | Target station CPU type 0000H Addressed to target station CPU (control CPU) |
| (s1)+4 | D204 | Target network number 1 |
| (s1)+5 | D205 | Target station number 4 |
| (s1)+6 | D206 | Not used — |
| (s1)+7 | D207 | Number of resends 5 times |
| (s1)+8 | D208 | Arrival monitoring time 0 (10 seconds) |
| (s1)+9 | D209 | Read data length 5 words |
| (s1)+10 | D210 | Not used — |
| (s1)+11 | D211 | Clock set flag Setting not required |
| (s1)+12 to (s1)+15 | D212 to D215 | Clock data (Set only in an abnormal state) |
| (s1)+16 | D216 | Error detection network number |
| (s1)+17 | D217 | Error-detected station number |

• Program

Write the following program to the FX5 CPU module of station No. 1.



Write the following program to the CPU module of the target station of station No. 4.




Writing data to the programmable controller on another station

GP.WRITE

This instruction writes data to the device in another station programmable controller. (In units of words)

| Ladder | ST |
|--------|--|
| | <pre>ENO:=GP_WRITE(EN,Un,s1,s2,d1,d2);</pre> |

FBD/LD



("GP_WRITE" enters □.)

Setting data

■Description, range, data type

| Operand | Description | Range | Data type | Data type (label) |
|-------------------|---|--|--------------------------------|---|
| (U) ^{*1} | Position number of the module connected | <ul style="list-style-type: none"> ■FX5UJ CPU module 1H to 8H ■FX5U/FX5UC CPU module 1H to 10H | 16-bit unsigned binary | ANY16 |
| (s1) | Own station head device where control data is stored | Refer to Page 64 Control data. | Device name | ANY16 ^{*4} |
| (s2) | Own station head device where the data to be written is stored | — | Device name | ANY16 ^{*4} |
| (d1) | Target station head device where data is to be written ^{*2} | — | Character string ^{*3} | ANYSTRING_SINGL E ^{*3} |
| (d2) | Own station device to be turned on for one scan when the instruction completes. (d2)+1 also turns on when the instruction completes with an error. | — | Bit | ANYBIT_ARRAY (Number of elements: 2) |
| EN | Execution condition | — | Bit | BOOL |
| ENO | Execution result | — | Bit | BOOL |

*1 In the case of the ST language and the FBD/LD language, U displays as Un.

*2 The continuous area specified by the write data length (s1)+9 is required.

*3 For the specifications of the string data to be specified, refer to the following.

(Page 47 Specifications of character string data specified by link dedicated instructions)

*4 Digit specified bit type label cannot be used.




■Applicable devices

| Operand | Bit | Word | | | Double word | | Indirect specification | Constant | | | Others (U) |
|---------|-----------------------------|---------------------------|-------|---|-------------|----|------------------------|----------|---|----|------------|
| | X, Y, M, L, SM, F, B, SB, S | T, ST, C, D, W, SD, SW, R | U□\G□ | Z | LC | LZ | | K, H | E | \$ | |
| (U) | — | ○ | — | — | — | — | ○ | ○ | — | — | ○ |
| (s1) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (s2) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (d1) | — | — | — | — | — | — | — | — | — | ○ | — |
| (d2) | ○ ^{*1} | ○ ^{*2} | — | — | — | — | — | — | — | — | — |

*1 S cannot be used.

*2 T, ST, and C cannot be used.

Control data

| Device | Item | Description | Setting range | Set by | | | | |
|--------|---------------------------------|--|--|--------|---|-----|----------------------------------|------|
| (s1)+0 | Execution/error completion type | <p>b15 ... b8 b7 ... b0</p> <table border="1" style="margin-left: 20px;"> <tr> <td style="width: 40px;">0</td> <td style="width: 40px;">(2)</td> <td style="width: 40px;">0</td> <td style="width: 40px;">(1)</td> </tr> </table> <p>(1) Execution type (bit 0)</p> <ul style="list-style-type: none"> • 0: No arrival acknowledgment <p>When the target station is in the own network: Completed when data has been sent from the own station.</p>  <p>When the target station is in another network: Completed when data has arrived the relay station of the own network.</p>  <ul style="list-style-type: none"> • 1: Arrival acknowledgment used <p>Completed when data has been written in the target station.</p>  <p>(2) Error completion type (bit 7)</p> <p>Specify whether to set data at completion with an error.</p> <ul style="list-style-type: none"> • 0: Do not set data in (s1)+11 and later at completion with an error. • 1: Set data in (s1)+11 and later at completion with an error. | 0 | (2) | 0 | (1) | 0000H 0001H 0080H 0081H | User |
| 0 | (2) | 0 | (1) | | | | | |
| (s1)+1 | Completion status | <p>The instruction completion status is stored.</p> <ul style="list-style-type: none"> • 0: Normal • Other than 0: Error (error code) | — | System | | | | |
| (s1)+2 | Own station channel | Specify the channel to be used by own station. | 1, 2 | User | | | | |
| (s1)+3 | Target station CPU type | <p>Specify the CPU type of the target station.</p> <ul style="list-style-type: none"> • 0000H: Addressed to target station CPU (control CPU) • 03D0H: Addressed to control system CPU • 03D1H: Addressed to standby system CPU • 03D2H: Addressed to system A CPU • 03D3H: Addressed to system B CPU • 03E0H: Addressed to multiple CPU No. 1 • 03E1H: Addressed to multiple CPU No. 2 • 03E2H: Addressed to multiple CPU No. 3 • 03E3H: Addressed to multiple CPU No. 4 • 03FFH: Addressed to target station CPU (control CPU) | 0000H 03D0H to 03D3H 03E0H to 03E3H 03FFH | User | | | | |
| (s1)+4 | Target network number | Specify the network number (1 to 239) of the target station. | 1 to 239 | User | | | | |

| Device | Item | Description | Setting range | Set by |
|---------|---|--|---|-------------|
| (s1)+5 | Target station number | Specify the station number of the target station. (1) Station number specification <ul style="list-style-type: none"> • 125: Master station • 126: Master operating station • 1 to 120: Local station, intelligent device station, submaster station (2) Group number specification <ul style="list-style-type: none"> • 0081H to 00A0H: All stations with group numbers 0001H to 0020H (Can be set when the execution type specified by (s1)+0 is "0: No arrival acknowledgment") (3) All-station specification <ul style="list-style-type: none"> • 00FFH: All stations of target network number (broadcast (excluding the own station)) (Can be set when the execution type specified by (s1)+0 is "0: No arrival acknowledgment") If the instruction is executed with group or all stations specification, specify "0000H" or "03FFH" for the target station's CPU type ((s1)+3). | Station No.: 1 to 120, 125, 126 Group number specification: 0081H to 00A0H All-station specification: 00FFH | User |
| (s1)+6 | Not used | — | — | — |
| (s1)+7 | Number of resends | Effective when the execution type specified by (s1)+0 is "1: Arrival acknowledgment used". <ul style="list-style-type: none"> ■ Before instruction execution Specify the number of resends to be performed if the instruction is not completed within the monitoring time specified by (s1)+8. <ul style="list-style-type: none"> ■ At completion of instruction The number of resends performed (result) is stored. | 0 to 15 | User/system |
| (s1)+8 | Arrival monitoring time | Effective when the execution type specified by (s1)+0 is "1: Arrival acknowledgment used". Specify the monitoring time until completion of processing. If processing is not completed within the monitoring time, the request is resent by the number of resends specified in (s1)+7. <ul style="list-style-type: none"> • 0: 10 seconds • 1 to 32767: 1 to 32767 seconds | 0 to 32767 | User |
| (s1)+9 | Write data length | Specify the number of words to be written. <ul style="list-style-type: none"> • 1 to 960 (words) (When writing data to QnACPU: 1 to 480 (words)) | 1 to 960 | User |
| (s1)+10 | Not used | — | — | — |
| (s1)+11 | Clock setting flag | The validity status (valid or invalid) of the data in (s1)+12 and later is stored. Note that the data in (s1)+12 and later is not cleared even when the instruction is completed successfully. <ul style="list-style-type: none"> • 0: Invalid • 1: Valid | — | System |
| (s1)+12 | Clock data (Set only in an abnormal state) | Upper 8 bits: Month (01H to 12H) Lower 8 bits: Lower 2 digits of year (00H to 99H) | — | System |
| (s1)+13 | | Upper 8 bits: Hour (00H to 23H) Lower 8 bits: Day (01H to 31H) | — | System |
| (s1)+14 | | Upper 8 bits: Second (00H to 59H) Lower 8 bits: Minute (00H to 59H) | — | System |
| (s1)+15 | | Upper 8 bits: Upper 2 digits of the year (00H to 99H) Lower 8 bits: Day of the week (00H (Sun.) to 06H (Sat.)) | — | System |
| (s1)+16 | | Error detection network number* ¹ | The network number of the station in which an error was detected is stored. (No information is stored if an error is detected in the own station.) <ul style="list-style-type: none"> • 1 to 239 (Network number) | — |
| (s1)+17 | Error-detected station number* ¹ | The station number of the station where an error was detected is stored. (No information is stored if an error is detected in the own station.) <ul style="list-style-type: none"> • 125: Master station • 1 to 120: Local station, intelligent device station, submaster station | — | System |


*1 If completion status ((s1)+1) is "Channel in use (dedicated instruction) (error codes: D25AH and D25BH)", data is not stored.

- When a number from 1 to 120 is specified for the target station number, the GP.WRITE instruction should be executed with the execution type set to "Arrival acknowledgment used" to improve data reliability. When a number from 81H to A0H or FFH is specified for the target station number, the GP.WRITE instruction should be executed with the execution type set to "No arrival acknowledgment".
- When performing device writing to the same station from multiple stations, do not overlap the write timing. When the execution type is set to "No arrival acknowledgment", successful completion results in the write source station if communication is completed successfully even when the sending data contains an error. Also, even when the sending data is normal, a timeout results in the write source station if the GP.WRITE instruction is executed for the same station from multiple stations.
- The number of resends (s1)+7 must be set every time the instruction is executed.

Processing details

- The instruction writes data by the specified number of words ((s1)+9) from the own station head device (s2) into the target station word devices. Specify the target stations in control data ((s1)+4) and ((s1)+5). Upon completion of writing device data to target station, the completion device specified by (d2) turns on.
- For the target stations that can be specified, refer to the following.

☞ Page 46 Target networks and target station types




- When executing multiple link dedicated instructions concurrently, be careful not to overlap the channels of the link dedicated instructions. Multiple link dedicated instructions specifying the same channel cannot be used concurrently.
- The execution of the GP.WRITE instruction and whether it has been completed normally or completed with an error can be checked with the completion device (d2) or completion status indication device (d2)+1.


| Device | Operation |
|--|--|
| Completion device (d2) | The device turns on during the END processing for the scan in which the GP.WRITE instruction is completed, and turns off during the next END processing. |
| Completion status indication device (d2)+1 | The device turns on or off depending on the completion status of the GP.WRITE instruction. When completed normally: The device does not change (remains off). When completed with an error: The device turns on during the END processing for the scan in which the GP.WRITE instruction is completed, and turns off during the next END processing. |

- The following figure shows the execution timing of the GP.WRITE instruction.

■ When completed normally



■ When completed with an error



- Write processing is performed only once on the rising edge when the write command turns on.


Operation error

| Error code ((s1)+1) | Description |
|---------------------|---|
| D000H to DFFFH | Refer to Page 122 List of Error Codes . |

Program example

The following program is for writing data of D750 to D753 of station No. 2 (own station) into D300 to D303 of station No. 3 (target station) when M112 is turned on.

• System configuration



• Devices used


| Device | Description |
|--------------|--|
| SB0047 | Baton pass status of own station |
| M110 | Control data set command |
| M111 | Write data setting command |
| M112 | Start contact |
| M115 | Completion device |
| M116 | Completion status indication device |
| D220 to D237 | Control data of the GP.WRITE instruction (For the set value, refer to the following figure.) |
| D750 to D753 | Write data storage device (station No. 2) |

• Control data

| Device | Item | Set value |
|--------------------|--------------|---|
| (s1)+0 | D220 | Execution/error completion type 0081H • Arrival acknowledgment used • Set data for error completion. |
| (s1)+1 | D221 | Completion status Setting not required |
| (s1)+2 | D222 | Own station channel 2 |
| (s1)+3 | D223 | Target station CPU type 0000H Addressed to target station CPU (control CPU) |
| (s1)+4 | D224 | Target network number 1 |
| (s1)+5 | D225 | Target station number 3 |
| (s1)+6 | D226 | Not used — |
| (s1)+7 | D227 | Number of resends 5 times |
| (s1)+8 | D228 | Arrival monitoring time 0 (10 seconds) |
| (s1)+9 | D229 | Write data length 4 words |
| (s1)+10 | D230 | Not used — |
| (s1)+11 | D231 | Clock set flag Setting not required |
| (s1)+12 to (s1)+15 | D232 to D235 | Clock data (Set only in an abnormal state) |
| (s1)+16 | D236 | Error detection network number |
| (s1)+17 | D237 | Error-detected station number |

• Program

Write the following program to the FX5 CPU module of station No. 2.



■Program using module FB

Program as follows when using the module FB

- Devices used

| Device | Description |
|---------------------------------|--|
| SB0047 | Baton pass status of own station |
| M110 | Setting command of module FB |
| M112 | Execution command of module FB |
| M114 to M116 | Bit-type input output label for module FB (Refer to the following table for the setting.) |
| D222, D224, D225, D229 and D238 | Word-type input output label for module FB (Refer to the following table for the setting.) |
| D750 to D753 | Write data storage device (station No. 2) |

- Module FB instance name

| Name of module FB | Instance name |
|-------------------------|---------------|
| M+FX5CCLIEF_DeviceWrite | DeviceWrite |

- FX5-CCLIEF module label

| Module label name | Module No. |
|-------------------|------------|
| FX5CCLIEF_1 | No.1 |

- Label to be used

| Label name | Item | Setting value/setting device |
|---------------------|---|------------------------------|
| ■Input label | | |
| i_bEN | Execution command | — |
| i_stModule | Module label | FX5CCLIEF_1 |
| i_u2TargetAddress | First word: target station network number | 1 (D224) |
| | Second word: Target station number | 3 (D225) |
| i_uDataLength | Write data length | 4 words (D229) |
| i_uWriteData | Write data storage device | D750 |
| i_s32TargetDevice | Target station write device | D300 |
| i_uChannel | Own station channel | 2 (D222) |
| ■Output label | | |
| o_bENO | Execution status | M114 |
| o_bOK | Normal completion | M115 |
| o_bErr | Abnormal end | M116 |
| o_uErrId | Error code | D238 |
| ■Public label | | |
| pbi_uCPU_Type | Target station CPU type | 0000H |
| pbi_uMonitorTime | Arrival monitoring time | 0 (10 seconds) |
| pbi_uResendCountMax | Maximum number of resends | 5 times |

Writing data to the programmable controller on another station (with notification)


GP.SWRITE

This instruction writes data to the device in another station programmable controller. (In units of words)

After the data writing is completed by the GP.SWRITE instruction, the device of the other station is turned on. The other station can recognize that data has been written by the GP.SWRITE instruction.

| Ladder | ST |
|--------|--|
| | <pre>ENO:=GP_SWRITE(EN,Un,s1,s2,d1,d2,d3);</pre> |

FBD/LD



("GP_SWRITE" enters □.)

Setting data

■Description, range, data type

| Operand | Description | Range | Data type | Data type (label) |
|-------------------|--|--|--------------------------------|--|
| (U) ^{*1} | Position number of the module connected | <ul style="list-style-type: none"> ■FX5UJ CPU module 1H to 8H ■FX5U/FX5UC CPU module 1H to 10H | 16-bit unsigned binary | ANY16 |
| (s1) | Own station head device where control data is stored | Refer to Page 73 Control data. | Device name | ANY16 ^{*4} |
| (s2) | Own station head device where the data to be written is stored | — | Device name | ANY16 ^{*4} |
| (d1) | Target station head device where data is to be written ^{*2} | — | Character string ^{*3} | ANYSTRING_SINGL E ^{*3} |
| (d2) | Own station device to be turned on for one scan when the instruction completes. (d2)+1 also turns on when the instruction completes with an error. | — | Bit | ANYBIT_ARRAY (Number of elements: 2) |
| (d3) | Target station device to be turned on for one scan when the instruction completes (enabling the target station to recognize that data has been written from another station) | — | Character string ^{*3} | ANYSTRING_SINGL E ^{*3} |
| EN | Execution condition | — | Bit | BOOL |
| ENO | Execution result | — | Bit | BOOL |

*1 In the case of the ST language and the FBD/LD language, U displays as Un.

*2 The continuous area specified by the write data length (s1)+9 is required.

*3 For the specifications of the string data to be specified, refer to the following.

(Page 47 Specifications of character string data specified by link dedicated instructions)

*4 Digit specified bit type label cannot be used.




■Applicable devices

| Operand | Bit | Word | | | Double word | | Indirect specification | Constant | | | Others (U) |
|---------|-----------------------------|---------------------------|-------|---|-------------|----|------------------------|----------|---|----|------------|
| | X, Y, M, L, SM, F, B, SB, S | T, ST, C, D, W, SD, SW, R | U□\G□ | Z | LC | LZ | | K, H | E | \$ | |
| (U) | — | ○ | — | — | — | — | ○ | ○ | — | — | ○ |
| (s1) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (s2) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (d1) | — | — | — | — | — | — | — | — | — | ○ | — |
| (d2) | ○*1 | ○*2 | — | — | — | — | — | — | — | — | — |
| (d3) | — | — | — | — | — | — | — | — | — | ○ | — |

*1 S cannot be used.

*2 T, ST, and C cannot be used.

■Control data

| Device | Item | Description | Setting range | Set by | | | | |
|--------|---------------------------------|--|---------------|--------|---|-----|----------------------------------|------|
| (s1)+0 | Execution/error completion type | <p>b15 b8 b7 b0</p> <table border="1" style="margin-left: 40px;"> <tr> <td style="width: 40px;">0</td> <td style="width: 40px;">(2)</td> <td style="width: 40px;">0</td> <td style="width: 40px;">(1)</td> </tr> </table> <p>(1) Execution type (bit 0)</p> <ul style="list-style-type: none"> • 0: No arrival acknowledgment <p>When the target station is in the own network: Completed when data has been sent from the own station.</p>  <p>When the target station is in another network: Completed when data has arrived the relay station of the own network.</p>  <ul style="list-style-type: none"> • 1: Arrival acknowledgment used <p>Completed when data has been written in the target station.</p>  <p>(2) Error completion type (bit 7)</p> <p>Specify whether to set data at completion with an error.</p> <ul style="list-style-type: none"> • 0: Do not set data in (s1)+11 and later at completion with an error. • 1: Set data in (s1)+11 and later at completion with an error. | 0 | (2) | 0 | (1) | 0000H 0001H 0080H 0081H | User |
| 0 | (2) | 0 | (1) | | | | | |
| (s1)+1 | Completion status | <p>The instruction completion status is stored.</p> <ul style="list-style-type: none"> • 0: Normal • Other than 0: Error (error code) | — | System | | | | |
| (s1)+2 | Own station channel | Specify the channel to be used by own station. | 1, 2 | User | | | | |

| Device | Item | Description | Setting range | Set by |
|---------|---|--|---|-----------------|
| (s1)+3 | Target station CPU type | Specify the CPU type of the target station. <ul style="list-style-type: none"> • 0000H: Addressed to target station CPU (control CPU) • 03D0H: Addressed to control system CPU • 03D1H: Addressed to standby system CPU • 03D2H: Addressed to system A CPU • 03D3H: Addressed to system B CPU • 03E0H: Addressed to multiple CPU No. 1 • 03E1H: Addressed to multiple CPU No. 2 • 03E2H: Addressed to multiple CPU No. 3 • 03E3H: Addressed to multiple CPU No. 4 • 03FFH: Addressed to target station CPU (control CPU) | 0000H 03D0H to 03D3H 03E0H to 03E3H 03FFH | User |
| (s1)+4 | Target network number | Specify the network number (1 to 239) of the target station. | 1 to 239 | User |
| (s1)+5 | Target station number | Specify the station number of the target station. (1) Station number specification <ul style="list-style-type: none"> • 125: Master station • 126: Master operating station • 1 to 120: Local station, intelligent device station, submaster station (2) Group number specification <ul style="list-style-type: none"> • 0081H to 00A0H: All stations with group numbers 0001H to 0020H (Can be set when the execution type specified by (s1)+0 is "0: No arrival acknowledgment") (3) All-station specification <ul style="list-style-type: none"> • 00FFH: All stations of target network number (broadcast (excluding the own station)) (Can be set when the execution type specified by (s1)+0 is "0: No arrival acknowledgment") If the instruction is executed with group or all stations specification, specify "0000H" or "03FFH" for the target station's CPU type ((s1)+3). | Station No.: 1 to 120, 125, 126 Group number specification: 0081H to 00A0H All-station specification: 00FFH | User |
| (s1)+6 | Not used | — | — | — |
| (s1)+7 | Number of resends | Effective when the execution type specified by (s1)+0 is "1: Arrival acknowledgment used". ■ Before instruction execution Specify the number of resends to be performed if the instruction is not completed within the monitoring time specified by (s1)+8. ■ At completion of instruction The number of resends performed (result) is stored. | 0 to 15 | User/ system |
| (s1)+8 | Arrival monitoring time | Effective when the execution type specified by (s1)+0 is "1: Arrival acknowledgment used". Specify the monitoring time until completion of processing. If processing is not completed within the monitoring time, the request is resent by the number of resends specified in (s1)+7. <ul style="list-style-type: none"> • 0: 10 seconds • 1 to 32767: 1 to 32767 seconds | 0 to 32767 | User |
| (s1)+9 | Write data length | Specify the number of words to be written. <ul style="list-style-type: none"> • 1 to 960 (words) (When writing data to QnACPU: 1 to 480 (words)) | 1 to 960 | User |
| (s1)+10 | Not used | — | — | — |
| (s1)+11 | Clock setting flag | The validity status (valid or invalid) of the data in (s1)+12 and later is stored. Note that the data in (s1)+12 and later is not cleared even when the instruction is completed successfully. <ul style="list-style-type: none"> • 0: Invalid • 1: Valid | — | System |
| (s1)+12 | Clock data (Set only in an abnormal state) | Upper 8 bits: Month (01H to 12H) Lower 8 bits: Lower 2 digits of year (00H to 99H) | — | System |
| (s1)+13 | | Upper 8 bits: Hour (00H to 23H) Lower 8 bits: Day (01H to 31H) | — | System |
| (s1)+14 | | Upper 8 bits: Second (00H to 59H) Lower 8 bits: Minute (00H to 59H) | — | System |
| (s1)+15 | | Upper 8 bits: Upper 2 digits of the year (00H to 99H) Lower 8 bits: Day of the week (00H (Sun.) to 06H (Sat.)) | — | System |
| (s1)+16 | | Error detection network number ^{*1} | The network number of the station in which an error was detected is stored. (No information is stored if an error is detected in the own station.) <ul style="list-style-type: none"> • 1 to 239 (Network number) | — |

| Device | Item | Description | Setting range | Set by |
|---------|---------------------------------|--|---------------|--------|
| (s1)+17 | Error-detected station number*1 | The station number of the station where an error was detected is stored. (No information is stored if an error is detected in the own station.) <ul style="list-style-type: none"> 125: Master station 1 to 120: Local station, intelligent device station, submaster station | — | System |

*1 If completion status ((s1)+1) is "Channel in use (dedicated instruction) (error codes: D25AH and D25BH)", data is not stored.


Point

- When a number from 1 to 120 is specified for the target station number, the GP.SWRITE instruction should be executed with the execution type set to "Arrival acknowledgment used" to improve data reliability. When a number from 81H to A0H or FFH is specified for the target station number, the GP.SWRITE instruction should be executed with the execution type set to "No arrival acknowledgment".
- When performing device writing to the same station from multiple stations, do not overlap the write timing. When the execution type is set to "No arrival acknowledgment", successful completion results in the write source station if communication is completed successfully even when the sending data contains an error. Also, even when the sending data is normal, a timeout results in the write source station if the GP.SWRITE instruction is executed for the same station from multiple stations.
- The number of resends (s1)+7 must be set every time the instruction is executed.

Processing details

- The instruction writes data by the specified number of words ((s1)+9) from the own station head device (s2) into the target station word devices. Specify the target stations in control data ((s1)+4) and ((s1)+5). Upon completion of writing device data to target station, the completion device specified by (d2) turns on. In the other station, upon completion of writing the device data specified by (s2), the device specified by (d3) turns on.
- For the target stations that can be specified, refer to the following.

☞ Page 46 Target networks and target station types




- When executing multiple link dedicated instructions concurrently, be careful not to overlap the channels of the link dedicated instructions. Multiple link dedicated instructions specifying the same channel cannot be used concurrently.
- The execution of the GP.SWRITE instruction and whether it has been completed normally or completed with an error can be checked with the completion device (d2) or completion status indication device (d2)+1.


| Device | Operation |
|--|--|
| Completion device (d2) | The device turns on during the END processing for the scan in which the GP.SWRITE instruction is completed, and turns off during the next END processing. |
| Completion status indication device (d2)+1 | The device turns on or off depending on the completion status of the GP.SWRITE instruction. When completed normally: The device does not change (remains off). When completed with an error: The device turns on during the END processing for the scan in which the GP.SWRITE instruction is completed, and turns off during the next END processing. |

• The following figure shows the execution timing of the GP.SWRITE instruction.

■ When completed normally



■ When completed with an error



• Write processing is performed only once on the rising edge when the write command turns on.


Operation error

| Error code ((s1)+1) | Description |
|---------------------|--|
| D000H to DFFFH | Refer to  Page 122 List of Error Codes. |

Program example

The following program is for writing data of D750 to D753 of station No. 2 (own station) into D300 to D303 of station No. 3 (target station) when M112 is turned on and for storing data of D300 to D303 into D500 to D503 when the write notification device (d3) is turned on in the target station.

- System configuration



- Devices used


| Device | Description |
|--|---|
| ■Device used in the own station (station No. 2) | |
| SB0047 | Baton pass status of own station |
| M110 | Control data set command |
| M111 | Write data setting command |
| M112 | Start contact |
| M115 | Completion device |
| M116 | Completion status indication device |
| D220 to D237 | Control data of the GP.SWRITE instruction (For the set value, refer to the following figure.) |
| D750 to D753 | Write data storage device (station No. 2) |
| ■Device used in the target station (station No. 3) | |
| M117 | Write notification device used in the target station (station No. 3) |
| D500 to D503 | Device for storing data of D300 to D303 used in the target station (station No. 3) |

• Control data

| Device | Item | Set value |
|--------------------|--------------|---|
| (s1)+0 | D220 | Execution/error completion type 0081H • Arrival acknowledgment used • Set data for error completion. |
| (s1)+1 | D221 | Completion status Setting not required |
| (s1)+2 | D222 | Own station channel 2 |
| (s1)+3 | D223 | Target station CPU type 0000H Addressed to target station CPU (control CPU) |
| (s1)+4 | D224 | Target network number 1 |
| (s1)+5 | D225 | Target station number 3 |
| (s1)+6 | D226 | Not used — |
| (s1)+7 | D227 | Number of resends 5 times |
| (s1)+8 | D228 | Arrival monitoring time 0 (10 seconds) |
| (s1)+9 | D229 | Write data length 4 words |
| (s1)+10 | D230 | Not used — |
| (s1)+11 | D231 | Clock set flag Setting not required |
| (s1)+12 to (s1)+15 | D232 to D235 | Clock data (Set only in an abnormal state) |
| (s1)+16 | D236 | Error detection network number |
| (s1)+17 | D237 | Error-detected station number |

• Program

Write the following program to the FX5 CPU module of station No. 2.



Write the following program to the CPU module of the target station of station No. 3.




Sending data to the programmable controller on another station

GP.SEND

This instruction sends data to another station programmable controller.

| Ladder | ST |
|--------|---|
| | <pre>ENO:=GP_SEND(EN,Un,s1,s2,d);</pre> |

FBD/LD



("GP_SEND" enters □.)

Setting data

■Description, range, data type

| Operand | Description | Range | Data type | Data type (label) |
|-------------------|--|--|------------------------|---|
| (U) ^{*1} | Position number of the module connected | ■FX5UJ CPU module 1H to 8H ■FX5U/FX5UC CPU module 1H to 10H | 16-bit unsigned binary | ANY16 |
| (s1) | Own station head device where control data is stored | Refer to Page 80 Control data. | Device name | ANY16 ^{*3} |
| (s2) | Own station head device where sending data is stored ^{*2} | — | Device name | ANY16 ^{*3} |
| (d) | Own station device to be turned on for one scan when the instruction completes. If the instruction is completed with an error, (d)+1 is also turned on. | — | Bit | ANYBIT_ARRAY (Number of elements: 2) |
| EN | Execution condition | — | Bit | BOOL |
| ENO | Execution result | — | Bit | BOOL |

*1 In the case of the ST language and the FBD/LD language, U displays as Un.

*2 The continuous area specified by the send data length (s1)+9 is required.

*3 Digit specified bit type label cannot be used.




■Applicable devices

| Operand | Bit | Word | | | Double word | | Indirect specification | Constant | | | Others (U) |
|---------|-----------------------------|---------------------------|-------|---|-------------|----|------------------------|----------|---|----|------------|
| | X, Y, M, L, SM, F, B, SB, S | T, ST, C, D, W, SD, SW, R | U□\G□ | Z | LC | LZ | | K, H | E | \$ | |
| (U) | — | ○ | — | — | — | — | ○ | ○ | — | — | ○ |
| (s1) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (s2) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (d) | ○ ^{*1} | ○ ^{*2} | — | — | — | — | — | — | — | — | — |

*1 S cannot be used.

*2 T, ST, and C cannot be used.


Control data

| Device | Item | Description | Setting range | Set by | | | | |
|--------|---------------------------------|--|---|--------|---|-----|----------------------------------|------|
| (s1)+0 | Execution/error completion type | <p>b15 ... b7 ... b0</p> <table border="1" style="margin-left: 20px;"> <tr> <td style="width: 20px;">0</td> <td style="width: 20px;">(2)</td> <td style="width: 20px;">0</td> <td style="width: 20px;">(1)</td> </tr> </table> <p>(1)? Execution type (bit 0)</p> <ul style="list-style-type: none"> • 0: No arrival acknowledgment <p>When the target station is in the same network: Completed when data has been sent from the own station.</p>  <p>When the target station is in another network: Completed when data has arrived the relay station of the own network.</p>  <ul style="list-style-type: none"> • 1: Arrival acknowledgment used <p>Completed when data has been stored in the specified channel of the target station.</p>  <p>(2) Error completion type (bit 7)</p> <p>Specify whether to set data at completion with an error.</p> <ul style="list-style-type: none"> • 0: Clock data at error occurrence is not stored in (s1)+11 and later. • 1: Clock data at error occurrence is stored in (s1)+11 and later. | 0 | (2) | 0 | (1) | 0000H 0001H 0080H 0081H | User |
| 0 | (2) | 0 | (1) | | | | | |
| (s1)+1 | Completion status | The instruction completion status is stored. | — | System | | | | |
| (s1)+2 | Own station channel | Specify the channel to be used by own station. | 1, 2 | User | | | | |
| (s1)+3 | Target station storage channel | Specify the channel of the target station for storing data. | 1 to 8 | User | | | | |
| (s1)+4 | Target network number | Specify the network number of the target station. | 1 to 239 | User | | | | |
| (s1)+5 | Target station number | Specify the station number of the target station. | Station No.: 1 to 120, 125, 126 Group number specification: 0081H to 00A0H All-station specification: 00FFH | User | | | | |
| (s1)+6 | Not used | — | — | — | | | | |


| Device | Item | Description | Setting range | Set by |
|---------|---|--|---------------|-----------------|
| (s1)+7 | Number of resends (retries) | Effective when the execution type specified by (s1)+0 is "1: Arrival acknowledgment used". ■Before instruction execution Specify the number of resends to be performed if the instruction is not completed within the monitoring time specified by (s1)+8. ■At completion of instruction The number of resends performed (result) is stored. | 0 to 15 | User/ system |
| (s1)+8 | Arrival monitoring time | Effective when the execution type specified by (s1)+0 is "1: Arrival acknowledgment used". Specify the monitoring time until completion of processing. If processing is not completed within the monitoring time, the request is resent by the number of resends specified in (s1)+7. • 0: 10 seconds • 1 to 32767: 1 to 32767 seconds | 0 to 32767 | User |
| (s1)+9 | Send data length | Specify the number of sending data from (s2) to (s2)+n. • 1 to 960 (words) (When sending data to QnACPU: 1 to 480 (words)) | 1 to 960 | User |
| (s1)+10 | Not used | — | — | — |
| (s1)+11 | Clock setting flag | The validity status (valid or invalid) of the data in (s1)+12 and later is stored. Note that the data in (s1)+12 and later is not cleared even when the instruction is completed successfully. • 0: Invalid • 1: Valid | — | System |
| (s1)+12 | Clock data (Set only in an abnormal state) | Upper 8 bits: Month (01H to 12H) Lower 8 bits: Lower 2 digits of year (00H to 99H) | — | System |
| (s1)+13 | | Upper 8 bits: Hour (00H to 23H) Lower 8 bits: Day (01H to 31H) | — | System |
| (s1)+14 | | Upper 8 bits: Second (00H to 59H) Lower 8 bits: Minute (00H to 59H) | — | System |
| (s1)+15 | | Upper 8 bits: Upper 2 digits of the year (00H to 99H) Lower 8 bits: Day of the week (00H (Sun.) to 06H (Sat.)) | — | System |
| (s1)+16 | Error detection network number ^{*1} | The network number of the station in which an error was detected is stored. • 1 to 239 (Network number) | — | System |
| (s1)+17 | Error-detected station number ^{*1} | The station number of the station where an error was detected is stored. • 125: Master station • 1 to 120: Local station, intelligent device station, submaster station | — | System |

*1 If completion status ((s1)+1) is "Channel in use (dedicated instruction) (error codes: D25AH to D25BH)", data is not stored.

- When a number from 1 to 120 is specified for the target station number, the instruction should be executed with the execution type set to "Arrival acknowledgment used" to improve data reliability. When a group number or all stations are specified, the instruction should be executed with the execution type set to "No arrival acknowledgment".
- When sending data to the same channel in the receiving station, execute the instruction after data has been read by the GP.RECV instruction in the receiving station. When the execution type is set to "No arrival acknowledgment", successful completion results in the sending station if communication is completed successfully even when the sending data contains an error. Also, even when the sending data is normal, a timeout results in the sending station if the instructions are executed for the same station from multiple stations.
- With the execution type set to "Arrival acknowledgment used", if the sending station sends data to the same channel in the receiving station before the receiving station reads data using the GP.RECV instruction, a buffer full error results in the sending station.



- When multiple network modules are mounted in the target station, specify the network number and station number of the network module that receives a request from the own station.
(Example: In the following figure, specify station No. 1 of network No. 1. (Station No. 5 of network No. 2. cannot be specified.))




- The number of resends (s1)+7 must be set every time the instruction is executed.

Processing details

- The instruction sends data by the specified number of words ((s1)+9) from the own station head device (s2) into the specified channel of a target station. The data that has been sent is stored in the channel specified by (s2) in the target station. To read the sent data in the target station, use the GP.RECV instruction. Upon completion of sending data to the target station number, the completion device specified by (d) turns on.
- For the target stations that can be specified, refer to the following.

☞ Page 46 Target networks and target station types




- Data can be sent not only to the stations connected to the own station network but also to stations connected to the specified network number of MELSECNET/H, MELSECNET/10, or Ethernet.
- When executing multiple link dedicated instructions concurrently, be careful not to overlap the channels of the link dedicated instructions. Multiple link dedicated instructions specifying the same channel cannot be used concurrently.
- The execution of the GP.SEND instruction and whether it has been completed normally or completed with an error can be checked with the completion device (d) or completion status indication device (d)+1.


| Device | Operation |
|---|--|
| Completion device (d) | The device turns on during the END processing for the scan in which the GP.SEND instruction is completed, and turns off during the next END processing. |
| Completion status indication device (d)+1 | The device turns on or off depending on the completion status of the GP.SEND instruction. When completed normally: The device does not change (remains off). When completed with an error: The device turns on during the END processing for the scan in which the GP.SEND instruction is completed, and turns off during the next END processing. |

• The following figure shows the execution timing of the SEND instruction.

■ When completed normally



■When completed with an error



- Send processing is performed only once on the rising edge when the send command turns on.


Operation error

| Error code ((s1)+1) | Description |
|---------------------|---|
| D000H to DFFFH | Refer to Page 122 List of Error Codes. |

Program example

The following program is for sending data of D750 to D753 of station No. 1 (own station) into channel 2 of station No. 2 (target station) when M152 is turned on.

- System configuration



- Devices used


| Device | Description |
|--------------|---|
| SB0047 | Baton pass status of own station |
| M150 | Control data set command |
| M151 | Send data setting command |
| M152 | Start contact |
| M155 | Completion device |
| M156 | Completion status indication device |
| D350 to D367 | Control data of the GP.SEND instruction (For the set value, refer to the following figure.) |
| D750 to D753 | Send data storage device (station No. 1) |

- Control data

| Device | Item | Set value |
|--------------------|--------------|---|
| (s1)+0 | D350 | Execution/error completion type 0081H • Arrival acknowledgment used • Set data for error completion. |
| (s1)+1 | D351 | Completion status Setting not required |
| (s1)+2 | D352 | Own station channel 1 |
| (s1)+3 | D353 | Target station storage channel 2 |
| (s1)+4 | D354 | Target network number 1 |
| (s1)+5 | D355 | Target station number 2 |
| (s1)+6 | D356 | Not used — |
| (s1)+7 | D357 | Number of resends 5 times |
| (s1)+8 | D358 | Arrival monitoring time 0 (10 seconds) |
| (s1)+9 | D359 | Send data length 4 words |
| (s1)+10 | D360 | Not used — |
| (s1)+11 | D361 | Clock set flag Setting not required |
| (s1)+12 to (s1)+15 | D362 to D365 | Clock data (Set only in an abnormal state) |
| (s1)+16 | D366 | Error detection network number |
| (s1)+17 | D367 | Error-detected station number |

• Program

Write the following program to the FX5 CPU module of station No. 1.



■Program using module FB

Program as follows when using the module FB

- Devices used

| Device | Description |
|-----------------------------|--|
| SB0047 | Baton pass status of own station |
| M150 | Setting command of module FB |
| M151 | Send data setting command |
| M152 | Execution command of module FB |
| M154 to M156 | Bit-type input output label for module FB (Refer to the following table for the setting.) |
| D352 to D355, D359 and D368 | Word-type input output label for module FB (Refer to the following table for the setting.) |
| D750 to D753 | Send data storage device (station No. 1) |

- Instance name of module FB

| Name of module FB | Instance name |
|-------------------|---------------|
| M+FX5CCLIEF_Send | Send |


- FX5-CCLIEF module label

| Module label name | Module No. |
|-------------------|------------|
| FX5CCLIEF_1 | No.1 |

- Label to be used

| Label name | Item | Setting value/setting device |
|--------------------|-------------------------------------|------------------------------|
| ■Input label | | |
| i_bEN | Execution command | — |
| i_stModule | Module label | FX5CCLIEF_1 |
| i_uTargetNetworkNo | Target network number | 1 (D354) |
| i_uTargetStationNo | Target station number | 2 (D355) |
| i_uChannel | Own station channel | 1 (D352) |
| i_uTargetChannel | Target station data storage channel | 2 (D353) |
| i_uDataLength | Send data length | 4 words (D359) |
| i_uSendData | Send Data Storage Device | D750 |
| ■Output label | | |
| o_bENO | Execution status | M154 |
| o_bOK | Normal completion | M155 |
| o_bErr | Abnormal end | M156 |
| o_uErrId | Error code | D368 |
| ■Public label | | |
| pbi_uMonitorTime | Arrival monitoring time | 0 (10 seconds) |

• Program



Add the processing program when completed successfully and completed with an error after the program above.


Receiving data from the programmable controller on another station

GP.RECV

This instruction reads data received from another station programmable controller. (For the main routine program)

| Ladder | ST |
|--------|---|
| | <pre>ENO:=GP_RECV(EN,Un,s,d1,d2);</pre> |

FBD/LD



("GP_RECV" enters □.)

Setting data

■Description, range, data type

| Operand | Description | Range | Data type | Data type (label) |
|-------------------|---|--|------------------------|---|
| (U) ^{*1} | Position number of the module connected | <ul style="list-style-type: none"> ■FX5UJ CPU module 1H to 8H ■FX5U/FX5UC CPU module 1H to 10H | 16-bit unsigned binary | ANY16 |
| (s) | Own station head device where control data is stored | Refer to Page 91 Control data. | Device name | ANY16 ^{*3} |
| (d1) | Own station head device for storing the receive data ^{*2} | — | Device name | ANY16 ^{*3} |
| (d2) | Own station device to be turned on for one scan when the instruction completes. (d2)+1 also turns on when the instruction completes with an error. | — | Bit | ANYBIT_ARRAY (Number of elements: 2) |
| EN | Execution condition | — | Bit | BOOL |
| ENO | Execution result | — | Bit | BOOL |

*1 In the case of the ST language and the FBD/LD language, U displays as Un.

*2 The continuous area (a maximum of 960 words) specified by the receive data length (s)+9 is required.

*3 Digit specified bit type label cannot be used.

■Applicable devices

| Operand | Bit | Word | | | Double word | | Indirect specification | Constant | | | Others (U) |
|---------|-----------------------------|---------------------------|-------|---|-------------|----|------------------------|----------|---|----|------------|
| | X, Y, M, L, SM, F, B, SB, S | T, ST, C, D, W, SD, SW, R | U□\G□ | Z | LC | LZ | | K, H | E | \$ | |
| (U) | — | ○ | — | — | — | — | ○ | ○ | — | — | ○ |
| (s) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (d1) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (d2) | ○ ^{*1} | ○ ^{*2} | — | — | — | — | — | — | — | — | — |

*1 S cannot be used.

*2 T, ST, and C cannot be used.

■Control data


| Device | Item | Description | Setting range | Set by |
|--------|---|--|--|--------|
| (s)+0 | Error completion type | b15 ... b7 ... b0 <div style="border: 1px solid black; padding: 2px; display: inline-block; margin: 5px 0;"> 0 (1) 0 </div> (1) Error completion type (bit 7) Specify whether to set data at completion with an error. • 0: Clock data at error occurrence is not stored in (s1)+11 and later. • 1: Clock data at error occurrence is stored in (s1)+11 and later. | 0000H 0080H | User |
| (s)+1 | Completion status | The instruction completion status is stored. • 0: Normal • Other than 0: Error (error code) | — | System |
| (s)+2 | Own station storage channel | Specify the channel to be used by own station. | 1, 2 | User |
| (s)+3 | Channel used by send station | The channel number (1 to 8) used by the sending station is stored. | — | System |
| (s)+4 | Sending station network number | The network number (1 to 239) of the sending station is stored. | — | System |
| (s)+5 | Sending-station No. | The station number of the sending station is stored. • 125: Master station, submaster station (operating as master station) • 1 to 120: Local station, intelligent device station, submaster station (operating as device) | — | System |
| (s)+6 | Not used | — | — | — |
| (s)+7 | Not used | — | — | — |
| (s)+8 | Arrival monitoring time | Specify the monitoring time until completion of processing. The instruction is completed with an error if it fails to complete within the monitoring time. • 0: 10 seconds • 1 to 32767: 1 to 32767 seconds | 0 to 32767 | User |
| (s)+9 | Receive data length | The number of data received and stored in (d1) to (d1)+n is stored. • 0: No receive data • 1 to 960: Number of words of received data | — | System |
| (s)+10 | Not used | — | — | — |
| (s)+11 | Clock setting flag | The validity status (valid or invalid) of the data in (s)+12 and later is stored. Note that the data in (s)+12 and later is not cleared even when the instruction is completed successfully. • 0: Invalid • 1: Valid | — | System |
| (s)+12 | Clock data (Set only in an abnormal state) | Upper 8 bits: Month (01H to 12H) Lower 8 bits: Lower 2 digits of year (00H to 99H) | — | System |
| (s)+13 | | Upper 8 bits: Hour (00H to 23H) Lower 8 bits: Day (01H to 31H) | — | System |
| (s)+14 | | Upper 8 bits: Second (00H to 59H) Lower 8 bits: Minute (00H to 59H) | — | System |
| (s)+15 | | Upper 8 bits: Upper 2 digits of the year (00H to 99H) Lower 8 bits: Day of the week (00H (Sun.) to 06H (Sat.)) | — | System |
| (s)+16 | | Error detection network number* ¹ | The network number of the station in which an error was detected is stored. • 1 to 239 (Network number) | — |
| (s)+17 | Error-detected station number* ¹ | The station number of the station where an error was detected is stored. • 125: Master station • 1 to 120: Local station, intelligent device station, submaster station | — | System |

*¹ If completion status ((s1)+1) is "Channel in use (dedicated instruction) (error codes: D25AH to D25BH)", data is not stored.

Processing details

- This instruction reads data, which were sent from another station by the SEND instruction, from the specified channel of the own station to the own station word device (after (d1)). When the data reading from the specified channel of the own station is completed, the completion device (d2) turns on.
- For the target stations that can be specified, refer to the following.

☞ Page 46 Target networks and target station types



- The data received from the sending station is stored in the own station channel specified by the sending station and the corresponding bit in the GP.RECV instruction execution request area corresponding to each channel is set to on. When the corresponding bit in the GP.RECV instruction execution request area is set to on, the received data is read from the receive data storage channel. The following table lists the GP.RECV instruction execution request areas.

| Name of GP.RECV instruction execution request area | Device number/address of corresponding bit |
|--|--|
| GP.RECV execution request flag Channel 1 | SB0030 |
| GP.RECV execution request flag Channel 2 | SB0031 |

- When executing multiple link dedicated instructions concurrently, be careful not to overlap the channels of the link dedicated instructions. Multiple link dedicated instructions specifying the same channel cannot be used concurrently.
- The execution of the GP.RECV instruction and whether it has been completed normally or completed with an error can be checked with the completion device (d2) or completion status indication device (d2)+1.

| Device | Operation |
|--|--|
| Completion device (d2) | The device turns on during the END processing for the scan in which the GP.RECV instruction is completed, and turns off during the next END processing. |
| Completion status indication device (d2)+1 | The device turns on or off depending on the completion status of the GP.RECV instruction. When completed normally: The device does not change (remains off). When completed with an error: The device turns on during the END processing for the scan in which the GP.RECV instruction is completed, and turns off during the next END processing. |


• The following figure shows the execution timing of the GP.RECV instruction.

■ When completed normally

For the execution timing, refer to the following instruction.

(☞ Page 79 GP.SEND)

■ When completed with an error



• Read processing is performed only once on the rising edge when the read command turns on.


Operation error

| Error code ((s)+1) | Description |
|--------------------|--|
| D000H to DFFFH | Refer to ☞ Page 122 List of Error Codes. |

Program example

The following program is for reading the data sent from station No. 1 (another station) by the SEND instruction, from channel 2 of station No. 2 (own station) to D770 to D773, when SB0031 is turned on.

- System configuration



- Devices used


| Device | Description |
|--------------|---|
| SB0031 | GP.RECV execution request flag CH2 |
| M165 | Completion device |
| M166 | Completion status indication device |
| D370 to D387 | Control data of the GP.RECV instruction (For the set value, refer to the following figure.) |
| D770 to D773 | Receive data storage device |

- Control data

| Device | Item | Set value |
|------------------|--------------|--|
| (s)+0 | D370 | Error completion type 0080H Set data for error completion. |
| (s)+1 | D371 | Completion status Setting not required |
| (s)+2 | D372 | Own station storage channel 2 |
| (s)+3 | D373 | Channel used by sending station Setting not required |
| (s)+4 | D374 | Sending station network number |
| (s)+5 | D375 | Sending station number |
| (s)+6 | D376 | Not used — |
| (s)+7 | D377 | Not used — |
| (s)+8 | D378 | Arrival monitoring time 0 (10 seconds) |
| (s)+9 | D379 | Receive data length Setting not required |
| (s)+10 | D380 | Not used — |
| (s)+11 | D381 | Clock set flag Setting not required |
| (s)+12 to (s)+15 | D382 to D385 | Clock data (Set only in an abnormal state) |
| (s)+16 | D386 | Error detection network number |
| (s)+17 | D387 | Error-detected station number |

- Program

Write the following program to the FX5 CPU module of station No. 2.



■ Program using module FB

Program as follows when using the module FB

- Devices used

| Device | Description |
|---------------------|--|
| SB0031 | GP.RECV execution request flag CH2 |
| M164 to M166 | Bit-type input output label for module FB (Refer to the following table for the setting.) |
| D372, D379 and D388 | Word-type input output label for module FB (Refer to the following table for the setting.) |
| D770 to D773 | Receive data storage device |

- Instance name of module FB

| Name of module FB | Instance name |
|-------------------|---------------|
| M+FX5CCLIEF_Recv | Recv |


- FX5-CCLIEF module label

| Module label name | Module No. |
|-------------------|------------|
| FX5CCLIEF_1 | No.1 |

- Label to be used

| Label name | Item | Setting value/setting device |
|-------------------|------------------------------|------------------------------|
| ■Input label | | |
| i_bEN | Execution command | — |
| i_stModule | Module label | FX5CCLIEF_1 |
| i_uRecvChannel | Receive data storage channel | 2 (D372) |
| ■Output label | | |
| o_bENO | Execution status | M164 |
| o_bOK | Normal completion | M165 |
| o_bErr | Abnormal end | M166 |
| o_uErrId | Error code | D388 |
| o_uRecvDataLength | Receive data length | D379 |
| o_uRecvData | Receive Data Storage Device | D770 |
| ■Public label | | |
| pbi_uMonitorTime | Arrival monitoring time | 0 (10 seconds) |

- Program




Add the processing program when completed successfully and completed with an error after the program above.

8.3 Other Instructions


Setting parameters

G(P).CCPASET

Set the parameters to the FX5-CCLIEF.

| Ladder | ST |
|---|---|
|  | <pre>ENO:=G_CCPASET(EN,Un,s1,s2,s3,s4,d); ENO:=GP_CCPASET(EN,Un,s1,s2,s3,s4,d);</pre> |

FBD/LD



("G_CCPASET", "GP_CCPASET" enters □.)

Setting data

■Description, range, data type

| Operand | Description | Range | Data type | Data type (label) |
|-------------------|--|--|------------------------|---|
| (U) ^{*1} | Position number of the module connected | <ul style="list-style-type: none"> ■FX5UJ CPU module 1H to 8H ■FX5U/FX5UC CPU module 1H to 10H | 16-bit unsigned binary | ANY16 |
| (s1) | Own station head device where control data is stored | Refer to  Page 97 Control data. | Device name | ANY16 ^{*3} |
| (s2) | Dummy device ^{*2} | — | Device name | ANY16 ^{*3} |
| (s3) | Dummy device ^{*2} | — | Device name | ANY16 ^{*3} |
| (s4) | Dummy device ^{*2} | — | Device name | ANY16 ^{*3} |
| (d) | Own station device to be turned on for one scan when the instruction completes. If the instruction is completed with an error, (d)+1 is also turned on. | — | Bit | ANYBIT_ARRAY (Number of elements: 2) |
| EN | Execution condition | — | Bit | BOOL |
| ENO | Execution result | — | Bit | BOOL |

*1 In the case of the ST language and the FBD/LD language, U displays as Un.

*2 Since the operands (s2) to (s4) are not used for the FX5-CCLIEF, specify dummy devices.

*3 Digit specified bit type label cannot be used.

■Applicable devices

| Operand | Bit | Word | | | Double word | | Indirect specification | Constant | | | Others (U) |
|---------|-----------------------------|---------------------------|-------|---|-------------|----|------------------------|----------|---|----|------------|
| | X, Y, M, L, SM, F, B, SB, S | T, ST, C, D, W, SD, SW, R | U□\G□ | Z | LC | LZ | | K, H | E | \$ | |
| (U) | — | ○ | — | — | — | — | ○ | ○ | — | — | ○ |
| (s1) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (s2) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (s3) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (s4) | — | ○ | — | — | — | — | ○ | — | — | — | — |
| (d) | ○*1 | ○*2 | — | — | — | — | — | — | — | — | — |

*1 S cannot be used.

*2 T, ST, and C cannot be used.


■Control data

| Device | Item | Description | Setting range | Set by | | | | | | |
|--------|-------------------|---|---------------|--------|---|-----|-----|---|--------------------|------|
| (s1)+0 | Completion status | The instruction completion status is stored. • 0: Normal • Other than 0: Error (error code) | — | System | | | | | | |
| (s1)+1 | Setting flag | b15 ... b13 b12 b11 b10 b9 b8 b7 ... b0 <table border="1" style="margin-left: 20px;"> <tr> <td style="width: 20px;">0</td> <td style="width: 20px;">(3)</td> <td style="width: 20px;">0</td> <td style="width: 20px;">(2)</td> <td style="width: 20px;">(1)</td> <td style="width: 20px;">0</td> </tr> </table> (1) Input setting for data link error (bit 8) • 0: Cleared • 1: Held (2) Output setting for CPU STOP (bit 9) • 0: Held • 1: Cleared (3) Output setting for CPU error (bit 12) • 0: Cleared • 1: Held | 0 | (3) | 0 | (2) | (1) | 0 | Shown on left side | User |
| 0 | (3) | 0 | (2) | (1) | 0 | | | | | |

Processing details

- Set the parameters to the FX5-CCLIEF.

[Own station]




- The execution of the G(P).CCPASET instruction and whether it has been completed normally or completed with an error can be checked with the completion device (d) or completion status indication device (d)+1.


| Device | Operation |
|---|--|
| Completion device (d) | The device turns on during the END processing for the scan in which the G(P).CCPASET instruction is completed, and turns off during the next END processing. |
| Completion status indication device (d)+1 | The device turns on or off depending on the completion status of the G(P).CCPASET instruction. When completed normally: The device does not change (remains off). When completed with an error: The device turns on during the END processing for the scan in which the G(P).CCPASET instruction is completed, and turns off during the next END processing. |

• The following figure shows the operation at completion of the G(P).CCPASET instruction.

■ When completed normally



■ When completed with an error



Operation error

| Error code ((s1)+0) | Description |
|---------------------|---|
| D000H to DFFFH | Refer to Page 122 List of Error Codes. |

■ Program using module FB

Program as follows when using the module FB

- Devices used

| Device | Description |
|-------------------------------|--|
| M181 | Baton pass status of own station |
| M184 to M186 | Bit-type input output label for module FB (Refer to the following table for the setting.) |
| D2741 | Word-type input output label for module FB (Refer to the following table for the setting.) |
| D2710, D2720, D2730 and D2740 | Dummy device |

- Instance name of module FB

| Name of module FB | Instance name |
|--------------------------|---------------|
| M+FX5CCLIEF_SetParameter | SetParameter |


- FX5-CCLIEF module label

| Module label name | Module No. |
|-------------------|------------|
| FX5CCLIEF_1 | No.1 |

- Label to be used

| Label name | Item | Setting value/setting device |
|-------------------------------|------------------------------------|------------------------------|
| ■ Input label | | |
| i_bEN | Execution command | — |
| i_stModule | Module label | FX5CCLIEF_1 |
| i_uTotalStations | Total number of device stations | — |
| i_u605NetworkConfigurationSet | Network configuration setting data | — |
| i_u8ReservedStationSet | Reserved station setting data | — |
| i_u8ErrInvalidStationSet | Error invalid station setting data | — |
| ■ Output label | | |
| o_bENO | Execution status | M184 |
| o_bOK | Normal completion | M185 |
| o_bErr | Abnormal end | M186 |
| o_uErrId | Error code | D2741 |
| ■ Public label | | |
| pbi_bCPU_StopOutputSet | CPU STOP output setting | On |

- Program



Add the processing program when completed successfully and completed with an error after the program above.

Operating procedure

The procedure of parameter settings using the G(P).CCPASET instruction is as follows.

- 1.** Before setting parameters using the G(P).CCPASET instruction, set the following item in the network parameters of GX Works3.
 - Network Number: Set the desired value.
 - Setting Method: Set the desired value.
 - Parameter Setting Method: Select "Program".
- 2.** Create a G(P).CCPASET instruction program.
- 3.** Write parameters and programs to the FX5 CPU module through GX Works3.
- 4.** Execute the G(P).CCPASET instruction.


Setting the station number to own station

G(P).UINI

This instruction sets the station number to the intelligent device station (own station) whose station number has not yet been set.

| Ladder | ST |
|--------|---|
| | <pre>ENO:=G_UINI(EN,Un,s,d); ENO:=GP_UINI(EN,Un,s,d);</pre> |

FBD/LD



("G_UINI", "GP_UINI" enters □.)

Setting data

■Description, range, data type

| Operand | Description | Range | Data type | Data type (label) |
|-------------------|--|--|------------------------|---|
| (U) ^{*1} | Position number of the module connected | <ul style="list-style-type: none"> ■FX5UJ CPU module 1H to 8H ■FX5U/FX5UC CPU module 1H to 10H | 16-bit unsigned binary | ANY16 |
| (s) | Own station head device where control data is stored | Refer to Page 103 Control data. | Device name | ANY16 ^{*2} |
| (d) | Own station device to be turned on for one scan when the instruction completes. If the instruction is completed with an error, (d)+1 is also turned on. | — | Bit | ANYBIT_ARRAY (Number of elements: 2) |
| EN | Execution condition | — | Bit | BOOL |
| ENO | Execution result | — | Bit | BOOL |

*1 In the case of the ST language and the FBD/LD language, U displays as Un.

*2 Digit specified bit type label cannot be used.

■Applicable devices

| Operand | Bit | Word | | | | Double word | | Indirect specification | Constant | | | Others (U) |
|---------|-----------------------------|---------------------------|-------|---|----|-------------|------|------------------------|----------|----|---|------------|
| | X, Y, M, L, SM, F, B, SB, S | T, ST, C, D, W, SD, SW, R | U□\G□ | Z | LC | LZ | K, H | | E | \$ | | |
| (U) | — | ○ | — | — | — | — | ○ | ○ | — | — | ○ | |
| (s) | — | ○ | — | — | — | — | ○ | — | — | — | — | |
| (d) | ○ ^{*1} | ○ ^{*2} | — | — | — | — | — | — | — | — | — | |

*1 S cannot be used.

*2 T, ST, and C cannot be used.


Control data

| Device | Item | Description | Setting range | Set by |
|----------------|-------------------------------|---|---------------|--------|
| (s)+0 | — | Not used | — | System |
| (s)+1 | Completion status | The instruction completion status is stored. • 0: Normal • Other than 0: Error (error code) | — | System |
| (s)+2 | Change target specification | 0001H (fixed) | 0001H | User |
| (s)+3 | Station number of own station | Specifies the station number to be set. | 1 to 120 | User |
| (s)+4 to (s)+9 | — | Not used | — | System |

Processing details

- Set the station number to the intelligent device station.

[Own station]




- The execution of the G(P).UINI instruction and whether it has been completed normally or completed with an error can be checked with the completion device (d) or completion status indication device (d)+1.


| Device | Operation |
|---|--|
| Completion device (d) | The device turns on during the END processing for the scan in which the G(P).UINI instruction is completed, and turns off during the next END processing. |
| Completion status indication device (d)+1 | The device turns on or off depending on the completion status of the G(P).UINI instruction. When completed normally: The device does not change (remains off). When completed with an error: The device turns on during the END processing for the scan in which the G(P).UINI instruction is completed, and turns off during the next END processing. |

- The following figure shows the operation at completion of the G(P).UINI instruction.

■When completed normally



■When completed with an error




Operation error

| Error code ((s)+1) | Description |
|--------------------|---|
| D000H to DFFFH | Refer to Page 122 List of Error Codes. |

Program example

The following program is for setting the station number stored in R0 of the FX5 CPU module into the intelligent device station when the switch on the CPU module is set to RUN.

- System configuration



- Devices used


| Device | Description |
|--------------|---|
| SB0046 | Station number setting status of own station |
| M192 | Completion device |
| M193 | Completion status indication device |
| D600 to D609 | Control data of the GP.UINI instruction (For the set value, refer to the following figure.) |
| R0 | Station number storage device |

- Control data

| Device | Item | Set value |
|----------------|--------------|-------------------------------|
| (s)+0 | D600 | Not used |
| (s)+1 | D601 | Completion status |
| (s)+2 | D602 | Change target specification |
| (s)+3 | D603 | Station number of own station |
| (s)+4 to (s)+9 | D604 to D609 | Not used |

• Program

Write the following program to the FX5 CPU module.



■ Program using module FB

Program as follows when using the module FB

• Devices used

| Device | Description |
|-------------------------------|--|
| SB0046 | Station number setting status of own station |
| M191 to M193 | Bit-type input output label for module FB (Refer to the following table for the setting.) |
| D603, D610 | Word-type input output label for module FB (Refer to the following table for the setting.) |
| D2710, D2720, D2730 and D2740 | Dummy device |
| R0 | Station number storage device |

• Instance name of module FB

| Name of module FB | Instance name |
|--------------------------|---------------|
| M+FX5CCLIEF_StationNoSet | StationNoSet |


• FX5-CCLIEF module label

| Module label name | Module No. |
|-------------------|------------|
| FX5CCLIEF_1 | No.1 |

• Label to be used

| Label name | Item | Setting value/setting device |
|-----------------|------------------------|------------------------------|
| ■Input label | | |
| i_bEN | Execution command | — |
| i_stModule | Module label | FX5CCLIEF_1 |
| i_uSetStationNo | Setting station number | R0 (D603) |
| ■Output label | | |
| o_bENO | Execution status | M191 |
| o_bOK | Normal completion | M192 |
| o_bErr | Abnormal end | M193 |
| o_uErrId | Error code | D610 |

• Program



Add the processing program when completed successfully and completed with an error after the program above.

Operating procedure

The procedure of station number setting using the G(P).UINI instruction is as follows.

- 1.** Before setting parameters using the G(P).UINI instruction, set the following item in the network parameters of GX Works3.
 - Network Number: Set the desired value.
 - Setting Method: Select "Program".
 - Parameter Setting Method: Set the desired value.
- 2.** Create a G(P).UINI instruction program.
- 3.** Write parameters and programs to the FX5 CPU module through GX Works3.
- 4.** Execute the G(P).UINI instruction.

Precautions

- The station number set by the G(P).UINI instruction is cleared when the FX5 CPU module is powered off and on or reset.
- The G(P).UINI can be executed on the intelligent device station with no station number setting.
- If the station number set by the G(P).UINI instruction is already used for another station, the instruction is completed with an error. Set a unique station number. Note that such error cannot be detected before data link start (e.g. absence of the master station).

9 PROGRAMMING

This chapter describes programming and startup examples of CC-Link IE Field Network.

9.1 Procedure for Creating Programs

Cyclic transmission program

This is a program that performs the cyclic transmission in the master station (station No. 0) and intelligent device station (station No. 1).

Parameter settings

The parameter settings required to create a program are shown below.

- Network configuration setting (set in the master station)

| STA# | Station Type | RX/RX Setting | | | RWw/RWr Setting | | |
|------|----------------------------|---------------|-------|------|-----------------|-------|------|
| | | Points | Start | End | Points | Start | End |
| 0 | Master station | — | — | — | — | — | — |
| 1 | Intelligent device station | 384 | 0000 | 017F | 1024 | 0000 | 03FF |

- Link refresh setting (set in the master station and intelligent device station)


| No. | Link side | | | | CPU side | | | |
|-----|-----------|--------|--------|-------|----------|------|--------|-------|
| | Start | End | Points | Units | Start | End | Points | Units |
| 1 | RX0 | RX17F | 384 | Bit | B0 | B17F | 384 | Bit |
| 2 | RY0 | RY17F | 384 | Bit | B200 | B37F | 384 | Bit |
| 3 | RWr0 | RWr3FF | 1024 | Word | W0 | W3FF | 1024 | Word |
| 4 | RWw0 | RWw3FF | 1024 | Word | W400 | W7FF | 1024 | Word |

Program example


This is a program that sends the value of D0 to D3 in the master station (station No. 0) to the D100 to D103 of the intelligent device station (station No. 1) through cyclic transmission. (B0 and B200 are used for a handshake to the CPU module.)

| Device | Description |
|--------|--|
| M0 | Sending request |
| M10 | Communication ready flag (for station No. 1) |
| M11 | Communication ready flag (for station No. 0) |
| N0 | Nesting |
| D0 | Sending data (sending station) |
| D100 | Sending data (receiving station) |

- Sending station (station No. 0)



• Receiving station (station No. 1)




Precautions

For a cyclic transmission program, establish an interlock using the following link special relay (SB).

- Data link error status of own station (SB0049)

Ex.

Interlock example




Transient transmission program

This is a program that reads D300 to D304 in the master station (station No. 0) to D800 to D804 of the intelligent device station (station No. 1) using the GP.READ instruction.

• Devices used

| Device | Description |
|--------------|---|
| X20 | Control data set command |
| X21 | Read command |
| M0 | Completion device (normal) |
| M1 | Completion device (error) |
| D1000 | Error completion type |
| D1002 | Own station channel |
| D1003 | Target station CPU type |
| D1004 | Target network number |
| D1005 | Target station number |
| D1007 | Number of resends |
| D1008 | Arrival monitoring time |
| D1009 | Read data length |
| D300 to D304 | Master station device where the data to be read is stored |
| D800 to D804 | Own station device for storing the read data |

• Program



■ Program using module FB

Program as follows when using the module FB.

- Devices used

| Device | Description |
|--------------|---|
| X20 | Control data set command |
| X21 | Read command |
| M0 | Completion device (normal) |
| M1 | Completion device (error) |
| M2 | Execution status |
| D1002 | Own station channel |
| D1003 | Target station CPU type |
| D1004 | Target network number |
| D1005 | Target station number |
| D1007 | Number of resends |
| D1008 | Arrival monitoring time |
| D1009 | Read data length |
| D1010 | Error code |
| D300 to D304 | Master station device where the data to be read is stored |
| D800 to D804 | Own station device for storing the read data |

- Instance name of module FB

| Name of module FB | Instance name |
|------------------------|---------------|
| M+FX5CCLIEF_DeviceRead | DeviceRead_2 |


- FX5-CCLIEF module label

| Module label name | Module No. |
|-------------------|------------|
| FX5CCLIEF_1 | No.1 |

- Label to be used

| Label name | Item | Setting value/setting device |
|-------------------|---|------------------------------|
| ■Input label | | |
| i_bEN | Execution command | — |
| i_stModule | Module label | FX5CCLIEF_1 |
| i_u2TargetAddress | First word: target station network number | 0 (D1003) |
| | Second word: Target station number | 1 (D1004) |
| i_uDataLength | Read data length | 5 words (D1009) |
| i_s32TargetDevice | Target station read device | D300 |
| i_uChannel | Own station channel | 2 (D1002) |
| ■Output label | | |
| o_bENO | Execution status | M2 |
| o_bOK | Normal completion | M0 |
| o_bErr | Abnormal end | M1 |
| o_uErrId | Error code | D1010 |
| o_uReadData | Read data storage device | D800 |

• Program



Add the processing program when read is completed and when completed successfully and completed with an error after the program above.

Precautions

For a transient transmission program, establish an interlock using the following link special relay (SB).

- Baton pass status of own station (SB0047)

Ex.

Interlock example



10 TROUBLESHOOTING

This chapter describes troubleshooting of CC-Link IE Field Network.

10.1 Checking with LEDs

This section describes troubleshooting using LED.

Error status can be determined by status of the RUN LED and the ERR LED.

| RUN LED | ERR LED | Error status ^{*1} | Description |
|---------|--------------|----------------------------|---|
| Off | On, flashing | Major error | An error such as hardware failure or memory failure. The module stops operating. |
| On | Flashing | Moderate error | An error, such as parameter error, which affect module operation. The module stops operating. |
| On | On | Minor error | An error such as communication failure. The module continues operating. |

*1 When multiple errors occur, the error status is displayed in the order of major, moderate, and minor.

If the RUN LED turns off

When the RUN LED turns off after powering on the FX5-CCLIEF module, check the following.

| Item to check | Action |
|---|---|
| Is the FX5-CCLIEF module mounted correctly? | Securely connect the FX5-CCLIEF module on the CPU module. |

If the above action does not solve the problem, perform the module communication test to check for hardware failure.

( Page 115 Module communication test)

If the ERR LED turns on or is flashing

If the ERR LED is turned on or flashing, check the following items.

| Item to check | Action |
|---|---|
| Does any error occur in the module diagnostics? | Take the actions displayed on the window. |

If the above actions do not solve the problem, perform the following tests to check for an error.

- Module communication test ( Page 115 Module communication test)
- Cable test ( Page 119 Cable Test)

If the D. LINK LED turns off or is flashing

If the D. LINK LED is turned off or flashing, check the following items.

| Item to check | Action |
|--|--|
| Is the master station connected to the network? | Check if the master station is performing data link using CC-Link IE Field Network diagnostics. (☞ Page 116 Checking the Network Status) |
| Do the used Ethernet cables conform to the Ethernet standard? | Replace the cables with an Ethernet cable that conforms to the standard. (☞ Page 15 Performance Specifications) |
| Does the station-to-station distance meet the specifications? | Set the station-to-station distance within range. (☞ Page 15 Performance Specifications) |
| Does the cabling condition (bending radius) meet the specifications? | Refer to the manual for the Ethernet cable, and correct the bending radius. |
| Is any Ethernet cable disconnected? | Replace the Ethernet cable. |
| Is a switching hub connected in ring topology? | Configure the network in ring topology without a switching hub. |
| Are other stations connected to the FX5-CCLIEF module operating normally? | Power off and on other stations. |
| Is the switching hub used operating normally? | <ul style="list-style-type: none"> • Check if the switching hub conforms to the standard. (☞ Page 15 Performance Specifications) • Power off and on the switching hub. |
| Check that the cables are not connected as described below. <ul style="list-style-type: none"> • Both P1 and P2 are connected to the same switching hub. • The network is incorrectly configured in ring topology. | Correct the wiring. When the system does not contain a switching hub, take the following action: <ul style="list-style-type: none"> • Disconnect an Ethernet cable (either P1 or P2) connected to any station on the network. The network topology will become a line topology and data link will start. When the system contains a switching hub, take any of the following actions: <ul style="list-style-type: none"> • Disconnect one Ethernet cable connected to the switching hub and power off and on the hub. (Repeat this operation until data link starts over the network.) • When data link starts over the network, check the network configuration using CC-Link IE Field Network diagnostics. |
| Are station numbers unique? | Change the duplicated station number. |

If the above actions do not solve the problem, perform the following tests to check for an error.

- Module communication test (☞ Page 115 Module communication test)
- Cable test (☞ Page 119 Cable Test)

If the L ERR LED is turned on

If the L ERR LED is turned on, check the following items.

| Item to check | Action |
|--|--|
| Are the Ethernet cables used operating normally? | <ul style="list-style-type: none">• Check if the Ethernet cable conforms to the standard. (☞ Page 15 Performance Specifications)• Check if the station-to-station distance is set within range. (☞ Page 15 Performance Specifications)• Check if the Ethernet cables are not disconnected. |
| Is the switching hub used operating normally? | <ul style="list-style-type: none">• Check if the switching hub conforms to the standard. (☞ Page 15 Performance Specifications)• Power off and on the switching hub. |
| Are other stations connected to the FX5-CCLIEF module operating normally? | Power off and on other stations. |
| Is "Module Operation Mode" under "Application Settings" of the master station set to "Online"? | Set the master station mode to online. |
| Is there any source of noise near the module or cables? | Change the location of the module or cables. |
| Is the loopback function enabled for the master station? | When the loopback function is enabled, check if the ring topology is correctly configured for the port where the L ERR LED is on. |

If the above actions do not solve the problem, perform troubleshooting for when communication is unstable. (☞ Page 121 When communication is unstable)

If the LINK LED turns off

If the LINK LED is turned off, check the following items.

| Item to check | Action |
|---|--|
| Do the used Ethernet cables conform to the Ethernet standard? | Replace the cables with an Ethernet cable that conforms to the standard. (☞ Page 37 Ethernet cable) |
| Does the station-to-station distance meet the specifications? | Set the station-to-station distance within range. (☞ Page 15 Performance Specifications) |
| Does the cabling condition (bending radius) meet the specifications? | Refer to the manual for the Ethernet cable, and correct the bending radius. |
| Is any Ethernet cable disconnected? | Replace the Ethernet cable. |
| Is the switching hub used operating normally? | <ul style="list-style-type: none">• Check if the switching hub conforms to the standard. (☞ Page 37 Hub)• Power off and on the switching hub. |
| Are other stations connected to the FX5-CCLIEF module operating normally? | Power off and on other stations. |

If the above actions do not solve the problem, perform the following tests to check for an error.

- Module communication test (☞ Page 115 Module communication test)
- Cable test (☞ Page 119 Cable Test)

10.2 Checking the Module Status

Module communication test

The module communication test checks the hardware of the FX5-CCLIEF. Select this mode to check the module hardware when communication of FX5-CCLIEF is unstable.

The following table lists the tests performed.

| Test item | Description |
|---|---|
| H/W test | Checks whether the microcomputer and RAM can be accessed normally. |
| Internal self-loopback test | Checks whether the communication function of the module can be performed normally. |
| External self-loopback check | Checks the connection failure by self-loopback check of the cable. |
| External self-loopback communication test | Checks whether the communication can be performed normally with the cable connected between two connectors. |

■ Procedure

1. Set the following item to "Module Communication Test".

 Navigation window ⇒ [Parameter] ⇒ [Module Information] ⇒ Target module ⇒ [Module Parameter] ⇒ [Application Settings] ⇒ [Module Operation Mode]

2. Connect P1 and P2 of the FX5-CCLIEF with an Ethernet cable.

3. Write the module parameters to the FX5 CPU module.

4. Reset or power off and on the FX5 CPU module to start the module communication test.

Point

- Do not access the buffer memory during the test. Doing so may cause the test to fail.
- Do not perform a module communication test while connected to another station. The operation of the other station may fail.

■ Checking the status and result of module communication test

The test status and result can be checked with LED display of the module.

| Test status | LED display |
|---------------------|---|
| Test in progress | The dot matrix LED displays "UCT". |
| Normal completion | The dot matrix LED displays "OK". |
| Abnormal completion | The ERR LED turns on and the dot matrix LED displays "ERR" and error number alternately at intervals of 1 second. |

■ Error number when the test abnormally ended

The dot matrix LED displays the error number with the form of "Port number Error number".

For example, "1 3" is displayed when error No. 3 occurs in P1.

If the module communication test fails, check the following.

| Error number | Description | Action |
|--------------|---|---|
| 1 | Internal self-loopback test failure | Consult your local Mitsubishi Electric representative. |
| 2 | External self-loopback communication test connection error | Check the Ethernet cable connection or replace the Ethernet cable, and perform the test again. If the test fails again, please consult your local Mitsubishi Electric representative. |
| 3 | External self-loopback communication test communication error | Replace the Ethernet cable and perform the test again. If the test fails again, please consult your local Mitsubishi Electric representative. |

Precautions


When "0" is displayed as the port number, the H/W test may have failed. Consult your local Mitsubishi Electric representative.

10.3 Checking the Network Status

Perform the CC-Link IE Field Network diagnostics to check the network status and error details or to perform an operation test for troubleshooting.

Diagnostic items

The following table lists items of the FX5-CCLIEF that can be diagnosed by the CC-Link IE Field Network diagnostics.



| Item | Restrictions | Reference |
|---|--|-----------|
| (1) Selected Station Communication Status Monitor | Displays the communication status of the own station. If an error has occurred in the module, the diagnostics information such as cause of error and corrective action is displayed. | Page 118 |
| (2) Cable Test | Tests the connection status of the station-to-station cable connected to P1 or P2 of the own station. | Page 119 |
| (3) Remote Operation | Performs remote operations (such as RUN, STOP, or RESET operations) to the FX5 CPU module of the own station. | Page 119 |


Starting diagnostics

This section describes how to use the CC-Link IE Field Network diagnostics.


1. Connect the engineering tool to the FX5 CPU module.
2. Start the CC-Link IE Field Network diagnostics.

[Diagnostics] ⇒ [CC-Link IE Field Diagnostics]

3. The status of the own station is displayed on the "Selected Station Communication Status Monitor".
The status of the own station is displayed on the top of "Selected Station Communication Status Monitor".
If an error occurs, a button indicating the error such as [PORT2 Communication Error] is displayed in "Selected Station Communication Status Monitor". Click the button to check the error details and actions.




4. Cable test and remote operation can be performed by clicking the "Operation Test" or "Selected Station Operation" on the bottom right of the window. (Page 119 Cable Test, Page 119 Remote Operation)



Selected Station Communication Status Monitor

The status of the own station is displayed.

■When an error occurs




| No. | Description |
|-----|--|
| (1) | Displays the operating status. <ul style="list-style-type: none"> • Station No.□: Normal operation • Station No.□ Error (yellow): Error (Data link is continued.) • Station No.□ Error (red): Error (Data link is stopped.) |
| (2) | Displays a mode. |
| (3) | Displays a MAC address. |
| (4) | Click this button to check error details. Take actions following the description displayed in "Error Factor" and "Troubleshooting". |
| (5) | Displays LED on/off status of the own station module. (☞ Page 17 LED display) |
| (6) | Displays status of the cables connected to P1 and P2. |

Cable Test

Cable test checks if the Ethernet cables are properly connected.
Only the Ethernet cable connected to P1 or P2 of the own station is tested.

Procedure



1. Click the [Cable Test] button in the "CC-Link IE Field Diagnostics" window.
"Cable Test" window is displayed.
2. Click the [Execute Test] button.
If an error occurs, take actions according to the error message.


10

Remote Operation

This function executes remote operations (such as RUN, STOP, and RESET operations) to the own station from the engineering tool.

Procedure

To perform remote operations, follow the steps below.



1. Click the [Remote Operation] button in the "CC-Link IE Field Diagnostics" window.
"Remote Operation" window is displayed.
2. Select a remote operation (RUN, STOP, PAUSE, or RESET) to be performed in "Operation" for FX5 CPU module. *1
3. Click the [Execute] button to perform the remote operation.

*1 To perform remote RESET, preset "Remote Reset Setting" under "Operation Related Setting" to "Enable" in the CPU Parameters.

10.4 Troubleshooting for Each Symptom

This section describes troubleshooting method by symptom. Perform these troubleshooting if data link cannot be performed even though no error is detected in the intelligent device station. If an error has occurred in the intelligent device station, identify the cause of error using the engineering tool. (☞ Page 116 Checking the Network Status)

When cyclic transmission cannot be performed

The following lists the actions to be taken if cyclic transmission to the master station cannot be performed.

| Item to check | Action |
|--|---|
| Is the D. LINK LED of the master or intelligent device station turned off or flashing? | Perform troubleshooting for when the D. LINK LED turns off or is flashing. (☞ Page 113 If the D. LINK LED turns off or is flashing) |
| Do the station numbers set in "Network Configuration Settings" under "Basic Settings" of the master station match those set for corresponding device stations? | Correct station numbers. |
| Is the range set in "Refresh Setting" of "Basic Settings" correct? | Correct the range setting in "Refresh Setting" of "Basic Settings". (☞ Page 40 Refresh setting) |
| Is any used device in "Refresh Setting" of "Basic Settings" overlapped with that of another module? | Correct the range setting in "Refresh Setting" of "Basic Settings". (☞ Page 40 Refresh setting) |
| Is the station number of the intelligent device station duplicated with any of the other stations? | Change the duplicated station number. |
| Is the module parameter of the I/O module connected to the CPU module written? | Correct the [Parameter] ⇒ [Module Information] settings. |

If the above action does not solve the problem, perform the module communication test to check for hardware failure. (☞ Page 115 Module communication test)

When transient transmission cannot be performed

The following lists the actions to be taken if transient transmission cannot be performed with the target station, and the engineering tool cannot perform monitoring.

| Item to check | Action |
|--|--|
| Is the D. LINK LED of the master or intelligent device station turned off? | Perform troubleshooting for when the D. LINK LED turns off or is flashing. (☞ Page 113 If the D. LINK LED turns off or is flashing) |
| Is the baton pass status of the destination normal? | In the CC-Link IE Field Network diagnostics, identify the cause of the error and take action. (☞ Page 116 Checking the Network Status) |
| Are the following control data of the dedicated instruction correct? <ul style="list-style-type: none"> • CPU type of the target module • Target network number • Target station number | Correct the control data of the dedicated instruction. |
| Is the station number of the intelligent device station duplicated with any of the other stations? | Change the duplicated station number. |

If the above actions do not solve the problem, perform the following tests to check for an error.

- Module communication test (☞ Page 115 Module communication test)

When a station is disconnected from the network

The following is the action to be taken when a station in data link is disconnected.

| Item to check | Action |
|---|--|
| Is the ambient temperature for the module within the specified range? | Keep the ambient temperature within the specified range by taking action such as removing heat source. |

If the above actions do not solve the problem, perform the following tests to check for an error.

- Module communication test (☞ Page 115 Module communication test)
- Cable test (☞ Page 119 Cable Test)

When a station is repeatedly disconnected and reconnected

The following lists the actions to be taken when a station in data link is repeatedly disconnected and reconnected.

| Item to check | Action |
|--|--|
| Are 1000BASE-T-compliant Ethernet cable used? | Replace the cables with 1000BASE-T-compliant Ethernet cables. ( Page 37 Ethernet cable) |
| Is the station-to-station distance 100 m or less? | Change the station-to-station distance to 100 m or less. |
| Does the cabling condition (bending radius) meet the specifications? | Refer to the manual for the Ethernet cable, and correct the bending radius. |
| Is any Ethernet cable disconnected? | Replace the Ethernet cable. |
| Is the switching hub used in the system operating normally? | <ul style="list-style-type: none"> • Check if a 1000BASE-T-compliant switching hub is used. ( Page 37 Hub) • Power off and on the switching hub. |

If the above actions do not solve the problem, perform the following tests to check for an error.

- Module communication test ( Page 115 Module communication test)
- Cable test ( Page 119 Cable Test)

When communication is unstable

The following lists the actions to be taken when link scan time or transmission delay time is long or when a transient transmission timeout occurred.

| Item to check | Action |
|--|--|
| Is the L ERR LED of the master or intelligent device station turned on? | Perform troubleshooting for when the L ERR LED turns on. ( Page 114 If the L ERR LED is turned on) |
| Is the ambient temperature for the module within the specified range? | Keep the ambient temperature within the specified range by taking action such as removing heat source. |
| Is any error shown in "Selected Station Communication Status Monitor" of CC-Link IE Field Network diagnostics? | If an error is identified at P1 or P2, perform a cable test and a module communication test. |
| Is there any noise affecting the system? | Check the wiring condition. |

If the above actions do not solve the problem, perform the following tests to check for an error.

- Module communication test ( Page 115 Module communication test)
- Cable test ( Page 119 Cable Test)

10.5 List of Error Codes

This section lists the error codes, error details and causes, and action for errors that occur in the processing for data communication between FX5-CCLIEF and external devices or caused by processing requests from the FX5 CPU module on the own station.

| Error code | Error details and causes | Action |
|------------|--|--|
| D000H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D001H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D003H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D004H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D00FH | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D03AH | A station that does not support the SLMP function was found. | Check whether the station supports the function. If the station does not support the used function, replace it with a station with the latest version. |
| D080H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D081H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D082H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D083H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D0A0H | Transmission response wait timeout has occurred in transient transmission. | <ul style="list-style-type: none"> When the own station, target station, or relay station detected an error, identify the cause of the error and take action. Lower the transient transmission usage frequency, and then perform again. When "Communication Mode" in "Application Settings" of the master station (submaster station) is set to "High-Speed", change it to "Normal" and retry the operation. |
| D0A1H | Transmission completion wait timeout has occurred in transient transmission. | <ul style="list-style-type: none"> Lower the transient transmission usage frequency, and then perform again. Check if the switching hub and the cables at the request source are connected properly. Connect the cable to the other port, and retry the operation. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D0A2H | Transmission processing wait timeout has occurred in transient transmission. | <ul style="list-style-type: none"> Lower the transient transmission usage frequency, and then perform again. Check if the switching hub and the cables at the request source are connected properly. |
| D0A3H | Send processing of the transient transmission has failed. | <ul style="list-style-type: none"> When the own station, target station, or relay station detected an error, identify the cause of the error and take action. Correct the target station number of transient data, and retry the operation. |

| Error code | Error details and causes | Action |
|------------|--|--|
| D0A4H | Transient transmission failed. | <ul style="list-style-type: none"> Lower the transient transmission usage frequency, and then perform again. Check if the switching hub and the cables at the request source are connected properly. Connect the cable to the other port, and retry the operation. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D0A5H | Transient transmission failed. | <ul style="list-style-type: none"> Lower the transient transmission usage frequency, and then perform again. Check if the switching hub and the cables at the request source are connected properly. Connect the cable to the other port, and retry the operation. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D0A6H | Transient transmission failed. | <ul style="list-style-type: none"> Lower the transient transmission usage frequency, and then perform again. Check if the switching hub and the cables at the request source are connected properly. Connect the cable to the other port, and retry the operation. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D0A8H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D0A9H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D0E1H | The reserved station setting of the own station is incorrect. | <ul style="list-style-type: none"> In the network configuration settings of the master station (submaster station), cancel the reserved station setting. Change the station number of the own station to a station number that is not specified as a reserved station. |
| D0E2H | The station number of own station is already used for the other station. | <ul style="list-style-type: none"> Set a unique station number. After change, power off and on or reset all stations where the error was detected. |
| D0F0H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D100H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D101H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D110H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D200H | When the transient transmission was executed, data was received twice. | <ul style="list-style-type: none"> Check the network status using the CC-Link IE Field Network diagnostics of the engineering tool, and take action. Check if the switching hub and the cables at the request source are connected properly. |
| D201H | The header information of transient transmission is incorrect. | Correct the header information at the request source, and retry the operation. |
| D202H | The send buffer is full. | <ul style="list-style-type: none"> Lower the transient transmission usage frequency, and then perform again. When "Communication Mode" in "Application Settings" of the master station (submaster station) is set to "High-Speed", change it to "Normal" and retry the operation. Check if the switching hub and the cables at the request source are connected properly. |
| D204H | The network number of transient transmission is incorrect. | Correct the network number at the request source, and retry the operation. |
| D205H | The target station number of transient transmission is incorrect. | Correct the target station number at the request source, and retry the operation. |
| D206H | The network number of transient transmission is incorrect. | Correct the network number at the request source, and retry the operation. |

| Error code | Error details and causes | Action |
|------------|---|---|
| D207H | In transient transmission, the number of relay to other networks exceeded seven. | Change the system configuration so that the number of relay stations may be seven or less. |
| D208H | The network number of transient transmission is incorrect. | Correct the network number at the request source, and retry the operation. |
| D209H | The target station number of transient transmission is incorrect. | Correct the target station number at the request source, and retry the operation. |
| D20AH | The target station number of transient transmission is incorrect. | Correct the target station number at the request source, and retry the operation. |
| D20BH | When there was no master station, specified master station was specified for transient transmission. | Correct the target station number at the request source, and retry the operation. |
| D20CH | When there was no master station, current master station was specified for transient transmission. | Correct the target station number at the request source, and retry the operation. |
| D20DH | Transmission completion wait timeout has occurred in transient data transmission. | <ul style="list-style-type: none"> • Check the network status using the CC-Link IE Field Network diagnostics of the engineering tool, and take action. • When the own station, target station, or relay station detected an error, identify the cause of the error and take action. • Lower the transient transmission usage frequency, and then perform again. • When "Communication Mode" in "Application Settings" of the master station (submaster station) is set to "High-Speed", change it to "Normal" and retry the operation. • Check if the switching hub and the cables at the request source are connected properly. |
| D20EH | The header information of transient transmission is incorrect. | Correct the header information at the request source, and retry the operation. |
| D20FH | In transient transmission, the command which cannot be requested to all or a group of stations was executed with all stations specification or group specification. | Check that the command can be requested to all or a group of stations at the request source, and retry the operation. |
| D210H | The target station number of transient transmission is incorrect. | Correct the header information at the request source, and retry the operation. |
| D211H | Transient transmission was performed when the station number of the own station has not been set yet. | Set the station number by the parameters, and perform transient transmission again. |
| D212H | Transient transmission failed. | <ul style="list-style-type: none"> • Check if the switching hub and the cables at the request source are connected properly. • Connect the cable to the other port on the request source, and retry the operation. • Lower the transient transmission usage frequency, and then perform again. |
| D213H | The command of transient transmission is incorrect. | <ul style="list-style-type: none"> • Correct the request command at the request source, and retry the operation. • Check whether the module supports the function. If the module does not support the used function, replace it with a module with the latest version. |
| D214H | The data length of transient transmission is incorrect. | Correct the data length at the transient request source, and retry the operation. |
| D216H | The command of transient transmission is incorrect. | Correct the request command at the request source, and retry the operation. |
| D217H | The command of transient transmission is incorrect. | Correct the request command at the request source, and retry the operation. |
| D218H | The number of read/write data of transient transmission is incorrect. | Correct the number of read or write device data at the request source, and retry the operation. |
| D219H | The attribute code of transient transmission is incorrect. | Correct the attribute code at the request source, and retry the operation. |
| D21AH | The access code of transient transmission is incorrect. | Correct the access code at the request source, and retry the operation. |
| D21BH | A transient transmission error was detected. | <ul style="list-style-type: none"> • Abnormal transient data were issued from the CPU module. • Replace the CPU module and retry the operation. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D21DH | The network number of transient transmission is incorrect. | <ul style="list-style-type: none"> • A cable test cannot be executed for a different network. Correct "Testing Station Setting", and execute the cable test again. • Transient data that cannot be sent to a different network were received. Correct the network number or the target station number at the request source, and retry the operation. |
| D21EH | The target station number of transient transmission is incorrect. | <ul style="list-style-type: none"> • A communication test cannot be executed on a relay sending station. Correct "Target Station" setting, and execute the communication test again. • Transient data of the application type that cannot be executed on the own station were received. Correct the application type or the target station number at the request source, and retry the operation. |

| Error code | Error details and causes | Action |
|------------|---|---|
| D220H | The master station does not exist. | Add the master station to the network. |
| D238H | The send queue is full. | <ul style="list-style-type: none"> • Pause the transient transmission temporarily, and retry the operation. • Lower the transient transmission usage frequency, and then perform again. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D239H | SLMP transmission failed. | <ul style="list-style-type: none"> • Retry the operation after a while. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D23AH | The subheader in the SLMP data is incorrect. | Correct the subheader information at the request source, and retry the operation. |
| D23BH | The network number in the SLMP data is incorrect. | Correct the network number at the request source, and retry the operation. |
| D23CH | The target station number in the SLMP data is incorrect. | Correct the station number at the request source and retry the operation. |
| D240H | The network number specification of the dedicated instruction is incorrect. | Execute again after correcting the network number at the request source. |
| D242H | The command code of the dedicated instruction is incorrect. | Execute again after correcting the command code at the request source. |
| D243H | The channel specified in the dedicated instruction is incorrect. | Execute again after correcting the used channel within the allowable range at the request source. |
| D244H | The transient data is incorrect. | <ul style="list-style-type: none"> • Correct the transient data at the request source, and retry the operation. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D245H | The target station number of the dedicated instruction is incorrect. | Execute again after correcting the target station number at the request source. |
| D246H | The transient data is incorrect. | <ul style="list-style-type: none"> • Correct the transient data at the request source, and retry the operation. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D247H | When the dedicated instruction was executed, response from the target station was received twice. | <ul style="list-style-type: none"> • Check the network status using the CC-Link IE Field Network diagnostics of the engineering tool, and take action. • Check if the switching hub and the cables at the request source are connected properly. |
| D248H | The transient data is incorrect. | <ul style="list-style-type: none"> • Correct the transient data at the request source, and retry the operation. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D249H | The target station's CPU type of the dedicated instruction is incorrect. | Execute again after correcting the CPU type of the target station at the request source. |
| D24AH | The arrival monitoring time of the dedicated instruction is incorrect. | <ul style="list-style-type: none"> • Execute again after correcting the arrival monitoring time at the request source. • When the own station, target station, or relay station detected an error, identify the cause of the error and take action. • Lower the transient transmission usage frequency, and then perform again. • When "Communication Mode" in "Application Settings" of the master station (submaster station) is set to "High-Speed", change it to "Normal" and retry the operation. • Check if the switching hub and the cables at the request source are connected properly. |
| D24BH | The number of resends specified in the dedicated instruction is incorrect. | <ul style="list-style-type: none"> • Execute again after correcting the number of resends at the request source. • When the own station, target station, or relay station detected an error, identify the cause of the error and take action. • Lower the transient transmission usage frequency, and then perform again. • When "Communication Mode" in "Application Settings" of the master station (submaster station) is set to "High-Speed", change it to "Normal" and retry the operation. • Check if the switching hub and the cables at the request source are connected properly. |
| D24CH | The network number specification of the dedicated instruction is incorrect. | Execute again after correcting the network number at the request source. |
| D24DH | The channel specified in the dedicated instruction is incorrect. | <ul style="list-style-type: none"> • Set 1 to 2 for the target channel number in the control data when executing the SEND instruction. |
| D24EH | Target station setting error in the dedicated instruction | <ul style="list-style-type: none"> • The value set for the control block of the dedicated instruction is out of range. Execute again after correcting the value. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D24FH | The dedicated instruction was executed when the station number of the own station has not been set yet. | <ul style="list-style-type: none"> • Specify the station number using the network parameter, and execute the instruction again. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |

| Error code | Error details and causes | Action |
|------------|---|---|
| D251H | When the dedicated instruction was executed, arrival check error has occurred. | <ul style="list-style-type: none"> Execute again after increasing the number of resends at the request source. When the own station, target station, or relay station detected an error, identify the cause of the error and take action. Lower the transient transmission usage frequency, and then perform again. When "Communication Mode" in "Application Settings" of the master station (submaster station) is set to "High-Speed", change it to "Normal" and retry the operation. Check if the switching hub and the cables at the request source are connected properly. |
| D252H | Transmission completion wait timeout has occurred when the dedicated instruction was executed. | <ul style="list-style-type: none"> Check the network status using the CC-Link IE Field Network diagnostics of the engineering tool, and take action. Execute again after increasing the number of resends at the request source. Lower the transient transmission usage frequency, and then perform again. When "Communication Mode" in "Application Settings" of the master station (submaster station) is set to "High-Speed", change it to "Normal" and retry the operation. Correct the number of link dedicated instructions that have been simultaneously executed within the range. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D253H | A response timeout has occurred when the dedicated instruction was executed. | <ul style="list-style-type: none"> Check the network status using the CC-Link IE Field Network diagnostics of the engineering tool, and take action. Execute again after increasing the number of resends at the request source. Lower the transient transmission usage frequency, and then perform again. Correct the number of link dedicated instructions that have been simultaneously executed within the range. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D254H | A dedicated instruction which the target station does not support was executed. | <ul style="list-style-type: none"> Change the target station at the station that executed the SEND instruction. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D255H | The target station number of the dedicated instruction is incorrect. | <ul style="list-style-type: none"> Execute again after correcting the target station number in the control data. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D256H | The execution/error completion type of the dedicated instruction is incorrect. | <ul style="list-style-type: none"> Execute again after correcting the execution/error completion type in the control data. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D258H | The control station does not exist when the dedicated instruction was executed to the specified control station or current control station. | <ul style="list-style-type: none"> Execute again after correcting the target station number in the control data. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D25AH | The dedicated instruction was executed specifying the channel in use. | <ul style="list-style-type: none"> Retry the operation after a while. Change the channels used by own station or the target station's channel in the control data. |
| D25BH | The dedicated instruction was executed specifying the channel in use. | Change the channels used by own station or the target station's channel in the control data. |
| D25DH | The transient data is incorrect. | <ul style="list-style-type: none"> Correct the transient data at the request source, and retry the operation. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D26BH | The network number setting of the CCPASET instruction execution station is incorrect. | Set "Network Number" under "Network Number" of "Required Settings" to a value within 1 to 239. |
| D280H | The request command of transient transmission is incorrect. | Correct the request command at the request source, and retry the operation. |
| D281H | Transient reception failed. | <ul style="list-style-type: none"> Check the network status using the CC-Link IE Field Network diagnostics of the engineering tool, and take action. When the target station or the relay station is overloaded and cannot receive transient data, send the data to the target/relay station after the load on the station is reduced. |
| D282H | The receive queue is full. | <ul style="list-style-type: none"> Pause the transient transmission temporarily, and retry the operation. Lower the transient transmission usage frequency, and then perform again. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D283H | Transient transmission failed. | <ul style="list-style-type: none"> Check the network status using the CC-Link IE Field Network diagnostics of the engineering tool, and take action. Connect the cable to the other port on the request source, and retry the operation. Lower the transient transmission usage frequency, and then perform again. |
| D284H | The target execution module in the SLMP data is incorrect. | Correct the target execution module in the SLMP header, and retry the operation. |

| Error code | Error details and causes | Action |
|------------|--|--|
| D2A0H | The receive buffer is full. | <ul style="list-style-type: none"> • Check the network status using the CC-Link IE Field Network diagnostics of the engineering tool, and take action. • When the target station or the relay station is overloaded and cannot receive transient data, send the data to the target/relay station after the load on the station is reduced. |
| D2A1H | The send buffer is full. | <ul style="list-style-type: none"> • Lower the transient transmission usage frequency, and then perform again. • Check if the switching hub and the cables at the request source are connected properly. |
| D2A2H | Transmission completion wait timeout has occurred in transient transmission. | <ul style="list-style-type: none"> • Lower the transient transmission usage frequency, and then perform again. • When "Communication Mode" in "Application Settings" of the master station (submaster station) is set to "High-Speed", change it to "Normal" and retry the operation. • Check if the switching hub and the cables at the request source are connected properly. • Correct the number of link dedicated instructions that have been simultaneously executed within the range. |
| D2A3H | The data length in the transient transmission frame is incorrect. | Correct the number of data (frame length) at the request source, and retry the operation. |
| D2A4H | The header information in the transient transmission frame is incorrect. | Correct the header information at the request source, and retry the operation. |
| D2A5H | The target station number in the transient transmission frame is incorrect. | Correct the target station number at the request source, and retry the operation. |
| D2A6H | The request source number in the transient transmission frame is incorrect. | Correct the request source number at the request source, and retry the operation. |
| D2A7H | The header information in the transient transmission frame is incorrect. | Correct the header information at the request source, and retry the operation. |
| D2A8H | The header information in the transient transmission frame is incorrect. | Correct the header information at the request source, and retry the operation. |
| D2A9H | The target network number in the transient transmission frame is incorrect. | Correct the target network number at the request source, and retry the operation. |
| D2AAH | The target station number in the transient transmission frame is incorrect. | Correct the target station number at the request source, and retry the operation. |
| D2ABH | The request source network number in the transient transmission frame is incorrect. | Correct the network number of the request source at the request source, and retry the operation. |
| D2ACH | The request source station number in the transient transmission frame is incorrect. | Correct the station number of the request source at the request source, and retry the operation. |
| D2ADH | The data length in the transient transmission frame is incorrect. | Correct the number of data (frame length) at the request source, and retry the operation. |
| D2AEH | The target station number in the transient transmission frame is incorrect. | The own station received transient data addressed to another station. Correct the network and target station numbers, and retry the operation. |
| D2AFH | The own station number was specified as the target station number of transient transmission. | Transient data transmission addressed to the own station was requested. Check the network number and target station number, and retry the operation. |
| D2B0H | Transient transmission failed. | <ul style="list-style-type: none"> • Check if the switching hub and the cables at the request source are connected properly. • Connect the cable to the other port on the request source, and retry the operation. • Lower the transient transmission usage frequency, and then perform again. |
| D2B1H | The receive queue is full. | <ul style="list-style-type: none"> • Pause the transient transmission temporarily, and retry the operation. • Lower the transient transmission usage frequency, and then perform again. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D605H | A network parameter error was detected. | <ul style="list-style-type: none"> • Write the network parameters to the CPU module again. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D606H | A network parameter error was detected. | <ul style="list-style-type: none"> • Write the network parameters to the CPU module again. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D607H | A network parameter error was detected. | <ul style="list-style-type: none"> • Write the network parameters to the CPU module again. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D609H | A network parameter error was detected. | <ul style="list-style-type: none"> • Write the network parameters to the CPU module again. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D60DH | An error was detected in the network module. | <ul style="list-style-type: none"> • Take measures to reduce noise. • Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |

| Error code | Error details and causes | Action |
|------------|--|---|
| D60EH | An error was detected in the network module. | <ul style="list-style-type: none"> • Take measures to reduce noise. • Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D60FH | An error was detected in the network module. | <ul style="list-style-type: none"> • Take measures to reduce noise. • Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D610H | An error was detected in the network module. | <ul style="list-style-type: none"> • Take measures to reduce noise. • Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D62AH | A network parameter error was detected. | <ul style="list-style-type: none"> • Write the network parameters to the CPU module again. • Correct the data link faulty station setting, and retry the operation. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D62BH | A network parameter error was detected. | <ul style="list-style-type: none"> • Write the network parameters to the CPU module again. • Correct the output status setting for CPU STOP, and retry the operation. • If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D62DH | Data link start failed. | <p>Remove any of the following causes, and retry the operation.</p> <ul style="list-style-type: none"> • Station number unassigned • CPU module error on the own station • Station type mismatch • Master station lost • Station number of the own station out of the range • Own station number duplication • Own station reserved • Parameter error • Parameter communication in progress • Parameter not received • Link stop instruction |
| D637H | The UINI instruction was executed at a station where the station number has been already set by parameter. | Execute again after setting "Setting Method" under "Station Number" in "Required Settings" to "Program". |
| D639H | After setting a station number with the UINI instruction, the instruction was executed again. | Station number setting with the UINI instruction is limited to one time only. Execute again after resetting the CPU module. |
| D721H | Link start/stop was requested from another station during link start/stop processing. | Retry the operation after the stop or restart of data link is completed. |
| D722H | Link start/stop was requested from the own station during link start/stop processing. | Retry the operation after the stop or restart of data link is completed. |
| D726H | The request command of transient transmission is incorrect. | Correct the request command at the request station, and retry the operation. |
| D727H | Link start was requested from a station other than the station which had requested link stop. | <ul style="list-style-type: none"> • Data link start was instructed from a station different from the one that had instructed the data link stop. Instruct data link start and data link stop from the same station. • The method of the data link start differs from that of the data link stop. Instruct the data link start using the same method as the data link stop. (Ex. Data link is stopped using the CC-Link IE Field Network diagnostics, and the data link is started using a program.) • Data link start has failed. Forcibly restart the data link. |
| D728H | Data link startup instruction was executed to the station which is performing data link. | Execute the data link startup instruction to the station where data link had been stopped. |
| D729H | Link stop of the own station was instructed in the station with no station number setting. | Specify the station number using the UINI instruction, and execute the instruction again. |
| D800H | An error was detected in the network module. | <ul style="list-style-type: none"> • Take measures to reduce noise. • Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D806H | The receive queue is full. | <ul style="list-style-type: none"> • Lower the transient transmission usage frequency, and then perform again. • Check if the switching hub and the cables are connected properly. |
| D807H | An error was detected in the network module. | <ul style="list-style-type: none"> • Take measures to reduce noise. • Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |

| Error code | Error details and causes | Action |
|------------|---|---|
| D80AH | A network parameter error was detected. | <ul style="list-style-type: none"> Write the network parameters to the CPU module again. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D80BH | A network parameter error was detected. | <ul style="list-style-type: none"> Write the network parameters to the CPU module again. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D80CH | A network parameter error was detected. | <ul style="list-style-type: none"> Write the network parameters to the CPU module again. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D80DH | A network parameter error was detected. | <ul style="list-style-type: none"> Write the network parameters to the CPU module again. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D80EH | A network parameter error was detected. | <ul style="list-style-type: none"> Write the network parameters to the CPU module again. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D80FH | A network parameter error was detected. | <ul style="list-style-type: none"> Write the network parameters to the CPU module again. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D812H | A network parameter error was detected. | <ul style="list-style-type: none"> Write the network parameters to the CPU module again. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D813H | A network parameter error was detected. | <ul style="list-style-type: none"> Write the network parameters to the CPU module again. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D814H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D816H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D819H | An error occurred in the CPU module. | <ul style="list-style-type: none"> Replace the CPU module. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D81AH | A stop error occurred in the CPU module. | Check the error and take action in "Module Diagnostics" of the engineering tool. |
| D827H | The communication RAM is incorrect. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| D902H | The online test data is incorrect. | <ul style="list-style-type: none"> Correct the data at the station that started the online test, and retry the operation. If the error occurs again even after taking the above action, please consult your local Mitsubishi representative. |
| D90DH | During execution of the cable test, the test was retried. | After completion of the cable test, retry the operation. |
| DA00H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| DA01H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| DA10H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |
| DA11H | An error was detected in the network module. | <ul style="list-style-type: none"> Take measures to reduce noise. Execute the module communication test. If the error occurs again even after taking the above action, hardware failure is a possible cause. Consult your local Mitsubishi Electric representative. |

10.6 List of Parameter Numbers

This section lists the parameter numbers displayed in the module diagnostics.

| Item | | | Parameter No. | |
|--------------------------|--|--------------------------|---|-------|
| Required Settings | Station Type | Station Type | 7700H | |
| | Network Number | Network Number | 7100H | |
| | Station Number | Setting Method | 7100H | |
| | | Station No. | 7100H | |
| Parameter Setting Method | Setting Method of Basic/Application Settings | 7100H | | |
| Basic Settings | Refresh Setting | | 7401H | |
| Application Settings | Supplementary Cyclic Settings | I/O Maintenance Settings | Output Hold/Clear Setting during CPU STOP | A050H |
| | | | Data Link Error Station Setting | A050H |
| | | | Output Mode upon CPU Error | 7101H |
| | Interrupt Settings | | | A014H |
| | Parameter Name | | | 7311H |
| | Module Operation Mode | | | 7100H |

APPENDIX

Appendix 1 Standards

Certification of UL, cUL standards

The FX5-CCLIEF supports UL (UL, cUL) standards.

UL, cUL file number: E95239

For models that support UL standards, please consult your local Mitsubishi representative.

Compliance with EC Directive (CE marking)

This note does not guarantee that an entire machine produced in accordance with the contents of this note will comply with the following standards.

Compliance to EMC Directive and LVD Directive of the entire mechanical module should be checked by the user/manufacturer. For more details, please consult your local Mitsubishi representative.

Requirement for compliance with EMC Directive

The following products have shown compliance through direct testing (of the identified standards below) and design analysis (through the creation of a technical construction file) to the European Directive for Electromagnetic Compatibility (2014/30/EU) when used as directed by the appropriate documentation.

Attention

This product is designed for use in industrial applications.

Product compatibility

Type: Programmable controller (open type equipment)

Models: FX5 manufactured

| Electromagnetic compatibility (EMC) directive | Remarks |
|---|---|
| from May 1st, 2016 FX5-CCLIEF EN61131-2:2007 Programmable controllers - Equipment requirements and tests | Compliance with all relevant aspects of the standard. EMI • Radiated emission • Conducted emission EMS • Radiated electromagnetic field • Fast transient burst • Electrostatic discharge • High-energy surge • Voltage drops and interruptions • Conducted RF • Power frequency magnetic field |


Caution for compliance with EC Directive

Caution for when the FX5-CCLIEF is used

When the FX5-CCLIEF is used, attach a ferrite core and make 3 turns within approximately 200 mm from the power cable connectors. (Ferrite core used in tests by Mitsubishi: ZCAT3035-1330 manufactured by TDK Co.)


Caution for when the Ethernet port is used

- Use a shielded twisted pair cable for the 1000BASE-T cable. Strip a part of the jacket of the shielded twisted pair cable as shown below and ground as much of the exposed shield as possible to both sides of the cable.
- Attach a ferrite core and make 1 turn at both ends of the cable. (Ferrite core used in tests by Mitsubishi: ZCAT3035-1330 manufactured by TDK Co.)



Noise filter (power supply line filter)

- Fit a noise filter onto the power supply cable. (Noise filter: TDK-Lambda RSHN-2020 was used for Mitsubishi's test.)
- Separate the input cable (power source side) away from the output cable (device side). If the input cable and output cable are bundled together or laid close to each other, noise from the output cable may be induced to the input cable where noise is removed by the noise filter. Ground the noise filter with the shortest possible grounding cable.



Compliance with UKCA marking

The requirements for compliance with UKCA marking are the same as that with EC directive (CE marking).

Appendix 2 Buffer Memory

The buffer memory is used to exchange data between the FX5-CCLIEF and the FX5 CPU module. Buffer memory values are reset to default when the FX5 CPU module is reset or the system is powered off.

List of buffer memory addresses

| Address (decimal) | Address (hexadecimal) | Name | | Read, write |
|-------------------|-----------------------|-------------------------|----------------------------|---|
| 0 to 23 | 0000H to 0017H | Link device area | Remote input (RX) | Read, write |
| 24 to 1023 | 0018H to 03FFH | | Not used | |
| 1024 to 1047 | 0400H to 0417H | | Remote output (RY) | Read |
| 1048 to 2047 | 0418H to 07FFH | | Not used | |
| 2048 to 3071 | 0800H to 0BFFH | | Remote register (RWw) | Read |
| 3072 to 10239 | 0C00H to 27FFH | | Not used | |
| 10240 to 11263 | 2800H to 2BFFH | | Remote register (RWr) | Read, write |
| 11264 to 18431 | 2C00H to 47FFH | | Not used | |
| 18432 to 18463 | 4800H to 481FH | | Link special relay (SB) | <ul style="list-style-type: none"> • 18432 to 18434 for read and write • 18435 to 18463 for read only |
| 18464 to 18975 | 4820H to 4A1FH | | Link special register (SW) | <ul style="list-style-type: none"> • 18464 to 18511 for read and write • 18512 to 18975 for read only |
| 18976 to 20511 | 4A20H to 501FH | System area | | |
| 20512 | 5020H | Own station information | Manufacturer code | Read |
| 20513 | 5021H | | Model type | Read |
| 20514 | 5022H | | Model code | Read |
| 20515 | 5023H | | Version | Read |
| 20516 to 32767 | 5024H to 7FFFH | System area | | |



- Do not write data to "System area". Doing so may cause malfunction of the programmable controller system.
- If the value in an area of one word in size becomes equal to or higher than 65536, the count stops at 65535 (FFFFH).

Details of buffer memory addresses

Link device area

The RX, RY, RWw, and RWr values are stored.

■Remote input (RX) (Un\G0 to Un\G23)

The RX value is stored.

| Address | b15 | b14 | b13 | b12 | b11 | b10 | b9 | b8 | b7 | b6 | b5 | b4 | b3 | b2 | b1 | b0 |
|---------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| Un\G0 | RXF | RXE | RXD | RXC | RXB | RXA | RX9 | RX8 | RX7 | RX6 | RX5 | RX4 | RX3 | RX2 | RX1 | RX0 |
| ⋮ | | | | | | | | | | | | | | | | |
| Un\G23 | RX17 F | RX17 E | RX17 D | RX17 C | RX17 B | RX17 A | RX17 9 | RX17 8 | RX17 7 | RX17 6 | RX17 5 | RX17 4 | RX17 3 | RX17 2 | RX17 1 | RX17 0 |

Each bit corresponds to 1 bit of RX.

■Remote output (RY) (Un\G1024 to Un\G1047)

The RY value is stored.

| Address | b15 | b14 | b13 | b12 | b11 | b10 | b9 | b8 | b7 | b6 | b5 | b4 | b3 | b2 | b1 | b0 |
|----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| Un\G1024 | RYF | RYE | RYD | RYC | RYB | RYA | RY9 | RY8 | RY7 | RY6 | RY5 | RY4 | RY3 | RY2 | RY1 | RY0 |
| ⋮ | | | | | | | | | | | | | | | | |
| Un\G1047 | RY17 F | RY17 E | RY17 D | RY17 C | RY17 B | RY17 A | RY17 9 | RY17 8 | RY17 7 | RY17 6 | RY17 5 | RY17 4 | RY17 3 | RY17 2 | RY17 1 | RY17 0 |

Each bit corresponds to 1 bit of RY.

■Remote register (RWw) (Un\G2048 to Un\G3071)

The RWw value is stored.

| Address | b15 | b14 | b13 | b12 | b11 | b10 | b9 | b8 | b7 | b6 | b5 | b4 | b3 | b2 | b1 | b0 |
|----------|--------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| Un\G2048 | RWw0 | | | | | | | | | | | | | | | |
| Un\G2049 | RWw1 | | | | | | | | | | | | | | | |
| ⋮ | | | | | | | | | | | | | | | | |
| Un\G3071 | RWw3FF | | | | | | | | | | | | | | | |

■Remote register (RWr) (Un\G10240 to Un\G11263)

The RWr value is stored.

| Address | b15 | b14 | b13 | b12 | b11 | b10 | b9 | b8 | b7 | b6 | b5 | b4 | b3 | b2 | b1 | b0 |
|-----------|--------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| Un\G10240 | RWr0 | | | | | | | | | | | | | | | |
| Un\G10241 | RWr1 | | | | | | | | | | | | | | | |
| ⋮ | | | | | | | | | | | | | | | | |
| Un\G11263 | RWr3FF | | | | | | | | | | | | | | | |

■Link special relay (SB) (Un\G18432 to Un\G18463)

The SB value is stored.

| Address | b15 | b14 | b13 | b12 | b11 | b10 | b9 | b8 | b7 | b6 | b5 | b4 | b3 | b2 | b1 | b0 |
|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| Un\G18432 | SBF | SBE | SBD | SBC | SBB | SBA | SB9 | SB8 | SB7 | SB6 | SB5 | SB4 | SB3 | SB2 | SB1 | SB0 |
| ⋮ | | | | | | | | | | | | | | | | |
| Un\G18463 | SB1F F | SB1F E | SB1F D | SB1F C | SB1F B | SB1F A | SB1F 9 | SB1F 8 | SB1F 7 | SB1F 6 | SB1F 5 | SB1F 4 | SB1F 3 | SB1F 2 | SB1F 1 | SB1F 0 |

Each bit corresponds to 1 bit of SB.



■Link special register (SW) (Un\G18464 to Un\G18975)

The SW value is stored.

| Address | b15 | b14 | b13 | b12 | b11 | b10 | b9 | b8 | b7 | b6 | b5 | b4 | b3 | b2 | b1 | b0 |
|-----------|-------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| Un\G18464 | SW0 | | | | | | | | | | | | | | | |
| Un\G18465 | SW1 | | | | | | | | | | | | | | | |
| : | | | | | | | | | | | | | | | | |
| Un\G18975 | SW1FF | | | | | | | | | | | | | | | |

Own station information

The information of the own station on the network is stored.

■Own station (network card) information (Un\G20512 to Un\G20515)

| Address | Name | Description |
|-----------|-------------------|---------------------------------|
| Un\G20512 | Manufacturer code | Stores own station information. |
| Un\G20513 | Model type | |
| Un\G20514 | Model code | |
| Un\G20515 | Version | |

Appendix 3 List of Link Special Relay (SB)

The link special relay (SB) is turned on/off depending on various factors during data link. Any error status of the data link can be checked by using or monitoring it in the program.

Application of link special relay (SB)

By using link special relay (SB), the status of CC-Link IE Field Network can be checked from HMI (Human Machine Interfaces) as well as the engineering tool.

Refresh of link special relay (SB)

To use link special relay (SB), set them in "Refresh Setting" in the parameter so that they are refreshed to the devices of the FX5 CPU module. (☞ Page 40 Refresh setting)

Ranges turned on/off by users and by the system

The following ranges correspond to when the link special relay areas (SB) are assigned from SB0000 to SB01FF.

- Turned on/off by users: SB0000 to SB001F
- Turned on/off by the system: SB0020 to SB01FF

List of link special relay (SB)

The following table lists the link special relay areas (SB) when they are assigned from SB0000 to SB01FF.



Do not turn on or off areas whose numbers are not on the list of link special relay (SB). Doing so may cause malfunction of the programmable controller system.

| No. | Name | Description |
|--------|---|---|
| SB0000 | Link startup of own station | Starts data link (cyclic transmission) of the own station. Off : Startup not requested On : Startup requested (valid at rising edge) (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • For SB0000 to SB0001, only one of the areas can be turned on. |
| SB0001 | Link stop of own station | Stops data link (cyclic transmission) of the own station. Off : Stop not requested On : Stop requested (valid at rising edge) (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • For SB0000 to SB0001, only one of the areas can be turned on. |
| SB0006 | Clear communication error count | Clears the link special register areas related to communication errors (SW0068 to SW006B, SW0074 to SW0077, SW007C to SW007F) to 0. Off : Clear not requested On : Clear requested (valid while on) |
| SB0030 | RECV instruction execution request flag CH1 | Stores the data reception status of own station channel 1. Off : No data received On : Data received (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB0031 | RECV instruction execution request flag CH2 | Stores the data reception status of own station channel 2. Off : No data received On : Data received (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB0040 | Network type of own station | Stores the network type of the own station. On : CC-Link IE Field Network |
| SB0043 | Module operation mode of own station | Stores the module operation mode of the own station. Off : Online mode On : Other than online mode |

| No. | Name | Description |
|--------|---|--|
| SB0046 | Station number setting status of own station | Stores the station number setting status. Off : Station number set On : Station number not set If parameters are set using the engineering tool, this relay is always OFF. |
| SB0047 | Baton pass status of own station | Stores the baton pass status (transient transmission availability) of the own station. Off : Normal On : Error When this relay is turned on, the cause of the error can be checked with 'Baton pass status of own station' (SW0047) and 'Cause of baton pass interruption' (SW0048). Depending on the link refresh timing, the update of 'Baton pass status of own station' (SW0047) and 'Cause of baton pass interruption' (SW0048) may be offset by one sequence scan. |
| SB0049 | Data link error status of own station | Stores the data link error status of the own station. Off : Normal On : Error When this relay is turned on, the cause of the error can be checked with 'Cause of data link stop' (SW0049). Depending on the link refresh timing, the update of 'Cause of data link stop' (SW0049) may be offset by one sequence scan. (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB004A | CPU minor error status of own station | Stores the minor error occurrence status of the CPU module on the own station. Off : No minor error On : Minor error |
| SB004B | CPU moderate/major error status of own station | Stores the moderate/major error occurrence status of the CPU module on the own station. Off : No moderate/major error On : Moderate/major error |
| SB004C | CPU operating status of own station | Stores the operating status of the CPU module on the own station. Off : RUN On : STOP, PAUSE, or moderate/major error |
| SB004D | Received parameter error | Stores the status of received parameter. Off : Normal On : Error |
| SB004F | Station number status of the operating station | Stores the setting method of the station number set. Off : Set by parameters On : Set by program |
| SB0050 | Link startup request accept status of own station | Stores the acceptance status of 'Link startup of own station' (SB0000). Off : Not accepted (SB0000 is off.) On : Accepted (SB0000 is on.) (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB0051 | Link startup completion status of own station | Stores the status of link startup processing requested with 'Link startup of own station' (SB0000). Off : Link startup not completed (SB0000, SB0050 are off.) On : Link startup completed (SB0000, SB0050 are on.) (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB0052 | Link stop request accept status of own station | Stores the acceptance status of 'Link stop of own station' (SB0001). Off : Not accepted (SB0001 is off.) On : Accepted (SB0001 is on.) (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB0053 | Link stop completion status of own station | Stores the link stop processing status requested with 'Link stop of own station' (SB0001). Off : Not completed (SB0001, SB0052 are off.) On : Completed (SB0001, SB0052 are on.) (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB006A | PORT1 link-down status of own station | Stores the link down status of the own station P1 side. Off : Link-up On : Link-down The time that link-up starts after power-on or Ethernet cable connection may vary. Normally link-up takes several seconds. Depending on device status on the line, link-up processing may be repeated, resulting in longer link-up time. |

| No. | Name | Description |
|--------|--|--|
| SB006B | PORT2 link-down status of own station | Stores the link down status of the own station P2 side. Off : Link-up On : Link-down The time that link-up starts after power-on or Ethernet cable connection may vary. Normally link-up takes several seconds. Depending on device status on the line, link-up processing may be repeated, resulting in longer link-up time. |
| SB006C | PORT1 current error frame reception status of own station | Stores whether the error frame is currently received at the P1 side of the own station. Off : Not received On : Currently receiving |
| SB006D | PORT2 current error frame reception status of own station | Stores whether the error frame is currently received at the P2 side of the own station. Off : Not received On : Currently receiving |
| SB006E | PORT1 error frame detection of own station | Stores whether the error frame was received at the P1 side of the own station from power-on to the present. Off : Not received On : Received |
| SB006F | PORT2 error frame detection of own station | Stores whether the error frame was received at the P2 side of the own station from power-on to the present. Off : Not received On : Received |
| SB007B | Input data status of data link faulty station | Stores the setting status in "Data Link Error Station Setting" of the own station. Off : Clear On : Hold |
| SB007D | Hold/clear status setting for CPU STOP | Stores the setting status in "Output Setting During CPU STOP" of the own station. Off : Hold On : Clear |
| SB00A1 | Baton pass error status of master station | Stores the baton pass status of the master station (master operating station). Off : Normal On : Error (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB00B1 | Data link error status of master station | Stores the data link status of the master station (master operating station). Off : Normal On : Error (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB00F1 | CPU operating status of master station | Stores the operating status of the CPU module on the master station (master operating station). Off : RUN or STEP-RUN state On : STOP state, PAUSE state, or moderate/major error (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB0101 | CPU moderate/major error status of master station | Stores the moderate/major error occurrence status of the CPU module on the master station (master operation station). Off : No moderate/major error On : Moderate/major error (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB0111 | CPU minor error status of master station | Stores the minor error occurrence status of the CPU module on the master station (master operating station). Off : No minor errors, or a moderate/major error being occurred On : Minor error (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB0121 | PORT1 current error frame reception status of master station | Stores whether the error frame is currently received at the P1 side of the master station (master operating station). Off : Not received On : Currently receiving (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |

| No. | Name | Description |
|--------|--|---|
| SB0131 | PORT2 current error frame reception status of master station | Stores whether the error frame is currently received at the P2 side of the master station (master operating station). Off : Not received On : Currently receiving (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB0141 | PORT1 error frame detection of master station | Stores whether the error frame was received at the P1 side of the master station (master operating station) from power-on to the present. Off : Not received On : Received (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SB0151 | PORT2 error frame detection of master station | Stores whether the error frame was received at the P2 side of the master station (master operating station) from power-on to the present. Off : Not received On : Received (Conditions) • This relay is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |

Appendix 4 List of Link Special Register (SW)

The link special register (SW) stores the information during data link as a numerical value. Error locations and causes can be checked by using or monitoring the link special register (SW) in programs.

Application of link special register (SW)

By using link special register (SW), the status of CC-Link IE Field Network can be checked from HMI (Human Machine Interfaces) as well as the engineering tool.

Refresh of link special register (SW)

To use link special register (SW), set them in "Refresh Setting" under "Basic Settings" so that they are refreshed to the devices of the FX5 CPU module. (📖 Page 40 Refresh setting)

Range where data are stored by users and range where data are stored by the system

The following ranges are allocated when the link special register areas (SW) are assigned from SW0000 to SW01FF.

- Stored by users: SW0000 to SW001F
- Stored by the system: SW0020 to SW01FF

List of link special register (SW)

The following table lists the link special register areas (SW) when they are assigned from SW0000 to SW01FF.



Do not write any data to an area whose number is not on the list of link special register (SW). Doing so may cause malfunction of the programmable controller system.

| No. | Name | Description |
|--------|---|--|
| SW0030 | Link dedicated instructions processing result CH1 | Stores the processing results of the link dedicated instruction that used channel 1 of the own station. 0: Completed normally 1 or greater: Completed with an error (Error code is stored.) |
| SW0031 | Link dedicated instructions processing result CH2 | Stores the processing results of the link dedicated instruction that used channel 2 of the own station. 0: Completed normally 1 or greater: Completed with an error (Error code is stored.) |
| SW0040 | Network number | Stores the network number of the own station. Range: 1 to 239 |
| SW0042 | Station number | Stores the station number of the own station. Range: 1 to 120, 255 (station number unassigned) |
| SW0043 | Mode status of own station | Stores the module operation mode setting or communication mode of the own station. 0: Online mode 2: Offline mode B: Module communication test mode |
| SW0046 | Module type | Stores the hardware status of the own station. <div style="text-align: center;"> </div> Model type (b1, b0) 00: Module 01: Board 10: Display |
| SW0047 | Baton pass status of own station | Stores the baton pass status (transient transmission availability) of the own station. 0: Data link in progress 2: Baton pass in progress 3: Baton pass being terminated 4: Test in progress 5: Offline |

A

| No. | Name | Description |
|--------|--|---|
| SW0048 | Cause of baton pass interruption | Stores the cause of interruption in the communication (baton pass) of the own station. 00H: At normal communication or power-on 30H: Cable disconnection 33H: Disconnection or return in progress 40H: Offline mode 41H: Module communication test |
| SW0049 | Cause of data link stop | Stores the cause which stopped the data link of the own station. 00H: At normal communication or power-on 01H: Stop requested 02H: Monitoring time timeout 11H: Station number of the own station out of the range 12H: Reserved station setting of the own station 13H: Own station number duplication 16H: Station number unassigned 18H: Parameter error 19H: Parameter communication in progress 1AH: Station type mismatch 20H: CPU module moderate error, major error |
| SW004A | Data link stop request station | Stores the station number of the station that performed the data link stop request for the own station. Range: 125 (Master station) The data link stop request is performed by 'System link stop' (SB0003). (Conditions) • This register is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SW004B | CPU status of own station | Stores the status of the own station. 00H: No module mounted 01H: STOP (normal) 02H: STOP (moderate/major error) 03H: STOP (minor error) 04H: RUN (normal) 05H: RUN (minor error) 07H: PAUSE 0EH: Reset in progress 0FH: Initial processing |
| SW004C | Parameter setting status | Stores the status of parameter settings. 0: Normal 1 or greater: Error definition (Error code is stored.) (Conditions) • This register is enabled when 'Received parameter error' (SB004D) is on. |
| SW0050 | Link startup result of own station | Stores the results when data link is started by 'Link startup of own station' (SB0000). 0: Normal 1 or greater: Error definition (Error code is stored.) When 'Link startup of own station' (SB0000) is turned off, the stored error definition is cleared. (Conditions) • This register is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SW0051 | Link stop result of own station | Stores the results when data link is stopped by 'Link stop of own station' (SB0001). 0: Normal 1 or greater: Error definition (Error code is stored.) When 'Link stop of own station' (SB0001) is turned off, the stored error definition is cleared. (Conditions) • This register is enabled when 'Baton pass status of own station' (SB0047) is off. • When 'Baton pass status of own station' (SB0047) is turned on (error), data prior to error is held. |
| SW0064 | Connection status of own station | Stores the connection status of the own station. 00H: Normal (communication in progress on P1 and P2) 01H: Normal (communication in progress on P1, cable disconnected on P2) 04H: Normal (loopback communication in progress on P1, cable disconnected on P2) 10H: Normal (cable disconnected on P1, communication in progress on P2) 11H: Disconnecting (cable disconnected on P1 and P2) 12H: Disconnecting (cable disconnected on P1, establishing line on P2) 21H: Disconnecting (establishing line on P1, cable disconnected on P2) 22H: Disconnecting (establishing line on P1 and P2) 40H: Normal (cable disconnected on P1, loopback communication in progress on P2) |
| SW0068 | PORT1 line error occurrence rate maximum value | Stores the occurrence rate (maximum value) of received error frames at the P1 side of the own station. (Unit: %) When 'Clear communication error count' (SB0006) is turned on, the stored value for the occurrence rate is cleared. |

| No. | Name | Description |
|--------|--|--|
| SW0069 | PORT1 line error occurrence rate present value | Stores the occurrence rate (present value) of received error frames at the P1 side of the own station. (Unit: %) When 'Clear communication error count' (SB0006) is turned on, the stored value for the occurrence rate is cleared. |
| SW006A | PORT2 line error occurrence rate maximum value | Stores the occurrence rate (maximum value) of received error frames at the P2 side of the own station. (Unit: %) When 'Clear communication error count' (SB0006) is turned on, the stored value for the occurrence rate is cleared. |
| SW006B | PORT2 line error occurrence rate present value | Stores the occurrence rate (present value) of received error frames at the P2 side of the own station. (Unit: %) When 'Clear communication error count' (SB0006) is turned on, the stored value for the occurrence rate is cleared. |
| SW0074 | PORT1 cable disconnection detection count | Stores the cumulative count that was detected for cable disconnections at the P1 side. When 'Clear communication error count' (SB0006) is turned on, the stored value for the number of errors is cleared. When FFFFH (maximum value 65535) is counted, the value returns to 0 and the module continues to count. |
| SW0075 | PORT1 receive error detection count | Stores the cumulative count that error data was received at the P1 side. The count stores only error data that is not transmitted to all stations. When 'Clear communication error count' (SB0006) is turned on, the stored value for the number of errors is cleared. When FFFFH (maximum value 65535) is counted, counting stops. |
| SW0076 | PORT1 total number of received data (lower 1 word) | Stores the cumulative count that data was received at the P1 side. When 'Clear communication error count' (SB0006) is turned on, the stored value for the number of errors is cleared. When FFFFFFFFH (maximum value 4294967295) is counted, counting stops. |
| SW0077 | PORT1 total number of received data (upper 1 word) | |
| SW007C | PORT2 cable disconnection detection count | Stores the cumulative count that was detected for cable disconnections at the P2 side. When 'Clear communication error count' (SB0006) is turned on, the stored value for the number of errors is cleared. When FFFFH (maximum value 65535) is counted, the value returns to 0 and the module continues to count. |
| SW007D | PORT2 receive error detection count | Stores the cumulative count that error data was received at the P2 side. The count stores only error data that is not transmitted to all stations. When 'Clear communication error count' (SB0006) is turned on, the stored value for the number of errors is cleared. When FFFFH (maximum value 65535) is counted, counting stops. |
| SW007E | PORT2 total number of received data (lower 1 word) | Stores the cumulative count that data was received at the P2 side. When 'Clear communication error count' (SB0006) is turned on, the stored value for the number of errors is cleared. When FFFFFFFFH (maximum value 4294967295) is counted, counting stops. |
| SW007F | PORT2 total number of received data (upper 1 word) | |



Appendix 5 Processing Time

I/O response time

The calculation formula for the response time of the intelligent device station is as follows:

$$R_{io} = (\text{Number of RX/RY points}) \times 0.16 + (\text{Number of RWw/RWr points}) \times 5.5 + 430 + K_a [\mu\text{s}]$$

The above formula calculates the average response time when auto refresh of the same number of points as the number of RX/RY and RWw/RWr points is performed.

- R_{io} : I/O response time of the intelligent device station
- Number of RX/RY points: The number of points set in "RX/RY Setting" of network configuration setting of the master station
- Number of RWw/RWr points: The number of points set in "RWw/RWr Setting" of network configuration setting of the master station
- K_a : The value to add when auto refresh of the intelligent function module is performed (=140)

FROM/TO processing time

For the processing time of the FROM/TO instruction, refer to the following manual.

 MELSEC iQ-F FX5 Programming Manual (Instructions, Standard Functions/Function Blocks)

Appendix 6 Added and Changed Functions

The functions added or changed with the FX5-CCLIEF and engineering tool, and supported firmware version of the FX5-CCLIEF and CPU module, and engineering tool software version are given below.

The firmware version of the FX5-CCLIEF can be confirmed with the system monitor. The firmware version of CPU module can be confirmed with module diagnosis (CPU diagnosis). For details, refer to the following manuals.

📖 GX Works3 Operating Manual

📖 MELSEC iQ-F FX5S/FX5UJ/FX5U/FX5UC User's Manual (Hardware)

Refer to the 📖 GX Works3 Operating Manual for details on the software version.

| FX5U/FX5UC CPU module | | | | |
|--------------------------|------------------------------------|------------------------------------|--------------------|---|
| Add/Change Function | Supported version | | | Reference |
| | Firmware version of the CPU module | Firmware version of the FX5-CCLIEF | Engineering tool | |
| Firmware update function | "1.240" and above | "1.005" and above | "1.075D" and above | MELSEC iQ-F FX5 User's Manual (Application) |



INDEX

0 to 9

32-bit data assurance 24

A

Access to devices and link devices 20
Automatic return 20

C

Cable test 20,119
Cascade connection 33
CC-Link IE Field Network diagnostics 20,116
Communications with different networks 20
Communications with the master station 20
Communications within the same network 20
Configuration in which data link cannot be performed
. 34
Cyclic data integrity assurance 20
Cyclic transmission program 107
Cyclic transmission stop and restart 20

D

Data link error station setting 42
Device Assignment Method 40
Diagnostic items 116
Diagnostics of own network 20
Diagnostics of the module 20

F

Firmware update function. 21

G

G(P).CCPASET 96
G(P).UINI 102
GP.READ 49
GP.RECV 90
GP.SEND 79
GP.SREAD 57
GP.SWRITE 72
GP.WRITE 63

I

I/O Maintenance Settings. 42
Input status setting for data link error. 20
Interlock program 24,25
Interrupt request to CPU module. 21
Interrupt Settings 42

L

Link dedicated instructions 46

M

Maximum number of link points per network 15
Mode selection for cyclic transmission 20
Module communication test 20,115
Module Operation Mode 42,45

N

Network Number 38
Network topology 32

O

Other dedicated instructions 47
Output hold/clear setting during CPU STOP 42
Output Mode upon CPU Error 42
Output status setting for CPU STOP 20
Output status setting for CPU stop error 20

P

Parameter Name 42,45
Parameter Setting Method 38

R

Refresh Setting 40
Remote operation 119

S

Selected station communication status
monitor 118
SLMP communication 20
Station Number 38
Station number and connection position 33
Station number setting using a program 21
Station Type. 38
Station-based block data assurance 24
Supplementary Cyclic Settings 42

T

Transient transmission program 109

W

Wiring products 37

MEMO

REVISIONS

| Revision date | Revision | Description |
|---------------|----------|---|
| May 2016 | A | First edition |
| October 2019 | B | ■Added models FX5UJ CPU module ■Added or modified parts SAFETY PRECAUTIONS, RELEVANT MANUALS, TERMS, Section 2.1, 2.2, 2.3, Chapter 3, Section 4.2, 6.2, 7.3, Chapter 8, Section 8.2, 8.3, 9.1, 10.4, Appendix 5, TRADEMARKS |
| August 2020 | C | ■Added or modified parts SAFETY PRECAUTIONS, WARRANTY |
| April 2021 | D | ■Added or modified parts RELEVANT MANUALS, TERMS, Section 4.1, Appendix 6, TRADEMARKS |
| April 2022 | E | ■Added or modified parts RELEVANT MANUALS, TERMS, Section 2.1, Chapter 3, Appendix 1, 6 |

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

© 2016 MITSUBISHI ELECTRIC CORPORATION

WARRANTY

Please confirm the following product warranty details before using this product.

1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company. However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place. Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 2. Failure caused by unapproved modifications, etc., to the product by the user.
 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
 5. Relay failure or output contact failure caused by usage beyond the specified life of contact (cycles).
 6. Failure caused by external irresistible forces such as fires or abnormal voltages, and failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 7. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
 8. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued.
Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not available after production is discontinued.

3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

6. Product application

- (1) In using the Mitsubishi MELSEC programmable controller, the usage conditions shall be that the application will not lead to a major accident even if any problem or fault should occur in the programmable controller device, and that backup and fail-safe functions are systematically provided outside of the device for any problem or fault.
- (2) The Mitsubishi programmable controller has been designed and manufactured for applications in general industries, etc. Thus, applications in which the public could be affected such as in nuclear power plants and other power plants operated by respective power companies, and applications in which a special quality assurance system is required, such as for railway companies or public service purposes shall be excluded from the programmable controller applications.
In addition, applications in which human life or property that could be greatly affected, such as in aircraft, medical applications, incineration and fuel devices, manned transportation, equipment for recreation and amusement, and safety devices, shall also be excluded from the programmable controller range of applications. However, in certain cases, some applications may be possible, providing the user consults their local Mitsubishi representative outlining the special requirements of the project, and providing that all parties concerned agree to the special circumstances, solely at the user's discretion.
- (3) Mitsubishi shall have no responsibility or liability for any problems involving programmable controller trouble and system trouble caused by DoS attacks, unauthorized access, computer viruses, and other cyberattacks.

TRADEMARKS

Anywire and AnyWireASLINK are either registered trademarks or trademarks of Anywire Corporation.

The company names, system names and product names mentioned in this manual are either registered trademarks or trademarks of their respective companies.

In some cases, trademark symbols such as [™] or [®] are not specified in this manual.

Manual number: JY997D64201E

Model: FX5-U-CCIEF-E

Model code: 09R733

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.